

ACARS PRINTER - REMOVAL/INSTALLATION

EFFECTIVITY: AIRCRAFT WITH ACARS INSTALLED

1. General

- A. This section gives the procedures to remove/install the ACARS printer.
- B. The ACARS printer is installed on the control pedestal.
- C. The procedures in this section are given in the sequence below. The tasks identified with (♦) are part of the Scheduled Maintenance Requirements Document (SMRD).

TASK NUMBER	DESCRIPTION	EFFECTIVITY
23-22-02-000-801-A	ACARS PRINTER - REMOVAL	AIRCRAFT WITH ACARS INSTALLED
23-22-02-400-801-A	ACARS PRINTER - INSTALLATION	AIRCRAFT WITH ACARS INSTALLED

TASK 23-22-02-000-801-A

EFFECTIVITY: AIRCRAFT WITH ACARS INSTALLED

2. ACARS PRINTER - REMOVAL

A. General

(1) This task gives the procedures to remove the ACARS printer.

B. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
223/224		Cockpit

C. Tools and Equipment

Not Applicable

D. Auxiliary Items

Not Applicable

E. Consumable Materials

Not Applicable

F. Expandable Parts

Not Applicable

G. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit

H. Preparation

SUBTASK 841-002-A


- (1) On the circuit breaker panel, open the ACARS PRT circuit breaker and attach a DO-NOT-CLOSE tag to it (Location Tip: 115 V AC/ACARS PTR).

I. Removal [\(Figure 401\)](#)

SUBTASK 020-002-A

- (1) Disengage the Dzus (2) fasteners on the ACARS printer (3).
- (2) Move the printer (2) away from its location on the control pedestal to get access to the electrical connector (1).
- (3) Disconnect the electrical connector (1).

EFFECTIVITY: AIRCRAFT WITH ACARS
ACARS Printer - Removal/Installation
Figure 401



EM145AMM231455A.DGN

TASK 23-22-02-400-801-A

EFFECTIVITY: AIRCRAFT WITH ACARS INSTALLED

3. ACARS PRINTER - INSTALLATION

A. General

(1) This task gives the procedures to install the ACARS printer.

B. References

REFERENCE	DESIGNATION
AMM TASK 23-22-02-700-801-A/500	ACARS PRINTER - OPERATIONAL TEST

C. Zones and Accesses

ZONE	PANEL/DOOR	LOCATION
223/224		Cockpit

D. Tools and Equipment

Not Applicable

E. Auxiliary Items

Not Applicable

F. Consumable Materials

Not Applicable

G. Expandable Parts

Not Applicable

H. Persons Recommended

QTY	FUNCTION	PLACE
1	Does the task	Cockpit

I. Installation (Figure 401)

SUBTASK 420-002-A

(1) Connect the cable connector (1) to the printer connector.

(2) Move the printer (3) to its location on the control pedestal.

(3) Engage the dzus (2) fasteners on the printer (3).

J. Follow-on

SUBTASK 842-002-A

(1) On the circuit breaker panel, close the ACARS PRT circuit breaker and remove the DO-NOT-CLOSE tag from it (Location Tip: 115 V AC/ACARS PTR).

(2) Do the ACARS printer operational test ([AMM TASK 23-22-02-700-801-A/500](#)).