

UF_MB_add_actions [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Registers custom Internal Open API applications for the NX menubar.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_add_actions
(
    UF_MB_action_t action_table [ ]
)
```

<code>UF_MB_action_t</code>	<code>action_table []</code>	Input	NULL terminated array of <code>UF_MB_action_t</code> records containing action name, function address, and callback argument.
-----------------------------	-------------------------------	-------	---

UF_MB_add_styler_actions [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Associates a UIStyler dialog to an associated action specified in a Menuscript file. The dialog file must be generated from the UIStyler and must be located in the "application" directory underneath the directory which has been added to the file `$UGII_BASE_DIR/ugii/menu/custom_dirs.dat`.

For example, on an NT system, you could specify `d:\my_application` as your directory.

The actions structure provides the binding of callbacks and client data to the dialog. You may associate multiple dialogs in your actions structure provided that the list is NULL terminated.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_add_styler_actions
(
    UF_MB_styler_actions_p_t actions
)
```

<code>UF_MB_styler_actions_p_t</code>	<code>actions</code>	Input	Action definition of menubar dialog(s)
---------------------------------------	----------------------	-------	--

UF_MB_ask_button_id (view source)

Defined in: uf_mb.h

Overview

Gets the button's ID.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_ask_button_id
(
    char * button_name,
    int * button_id
)
```

char *	button_name	Input	Name of the button
int *	button_id	Output	Button Identification

UF_MB_ask_button_sensitivity (view source)

Defined in: uf_mb.h

Overview

Gets the button's sensitivity. Note that this function is intended for customized Manuscript buttons only. The NX buttons are insensitive when running any NXOpen program and are returned to their normal sensitivity state when the NXOpen program completes.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_ask_button_sensitivity
(
    int button_id,
    UF_MB_state_p_t state
)
```

int	button_id	Input	Button Identification
UF_MB_state_p_t	state	Output	Button sensitivity can be one of the following: UF_MB_ON UF_MB_OFF

UF_MB_ask_button_type_name [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Returns the name of a button type. If the specified type corresponds to the type of a menubar button, `type_name` is returned as a pointer to the button type name, and the function returns 0; otherwise the function `type_name` points to the string "UNKNOWN" and the return value is `UF_err_bad_parameter_number_1`.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_ask_button_type_name
(
    UF_MB_button_type_t type,
    char ** type_name
)
```

<code>UF_MB_button_type_t</code>	type	Input	The type of a menu bar button.
<code>char **</code>	type_name	Output to <code>UF_*free*</code>	The name of the button type.

UF_MB_ask_double_resource [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Locates the requested resource in the X Resource Database. If it is found, its value is set to the value found. If the resource is not found, value is set to the default. 0 is returned unless there are any argument or exception errors.

NOTE: This function is only available on Unix.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_ask_double_resource
(
    const char * name,
    double defvalue,
    double * value
)
```

)

const char *	name	Input	The name of the resource to be located.
double	defvalue	Input	The default value for the resource if not found.
double *	value	Output	The value of the resource.

UF_MB_ask_int_resource [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Locates the requested resource in the X Resource Database. If it is found, its value is set to the value found. If the resource is not found, value is set to the default. 0 is returned unless there are any argument or exception errors.

NOTE: This function is only available on Unix.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_ask_int_resource
(
    const char * name,
    int defvalue,
    int * value
)
```

const char *	name	Input	The name of the resource to be located.
int	defvalue	Input	The default value for the resource if not found.
int *	value	Output	The value of the resource.

UF_MB_ask_logical_resource [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Locates the requested resource in the X Resource Database. If it is found, its value is set to the value found. If the resource is not found, value is set to the default. 0 is returned unless there are any argument or exception errors.

NOTE: This function is only available on Unix.

Environment
Internal

Required License(s)
gateway

```
int UF_MB_ask_logical_resource
(
    const char * name,
    logical defvalue,
    logical * value
)
```

const char *	name	Input	The name of the resource to be located.
logical	defvalue	Input	The default value for the resource if not found.
logical *	value	Output	The value of the resource.

UF_MB_ask_string_resource [\(view source\)](#)

Defined in: uf_mb.h

Overview
Locates the requested resource in the X Resource Database. If it is found, its value is set to the value found. If the resource is not found, value is set to the default. 0 is returned unless there are any argument or exception errors.

NOTE: This function is only available on Unix.

Environment
Internal

Required License(s)
gateway

```
int UF_MB_ask_string_resource
(
    const char * name,
    const char * defvalue,
    char value [ ]
)
```

const char *	name	Input	The name of the resource to be located.
const char *	defvalue	Input	The default value for the resource if not found.
char	value []	Output	The value of the resource.

UF_MB_ask_toggle_state [\(view source\)](#)

Defined in: uf_mb.h

Overview

Gets a toggle button's current state.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_ask_toggle_state
(
    int button_id,
    UF_MB_state_t * state
)
```

int	button_id	Input	Button ID
UF_MB_state_t *	state	Output	The button's sensitivity can be one of the following: UF_MB_ON UF_MB_OFF

UF_MB_init_application_data [\(view source\)](#)

Defined in: uf_mb.h

Overview

Initializes the custom application data. This routine should be called before calling UF_MB_register_application.

Return

void

Environment

Internal

History

Introduced in V18.0

Required License(s)

gateway

```
int UF_MB_init_application_data
(
    UF_MB_application_p_t app_data
)
```

UF_MB_application_p_t	app_data	Input / Output	Pointer to application data structure.
---------------------------------------	-----------------	----------------	--

UF_MB_load_resource_file [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Loads a resource file. Locates the requested resource file in the vendor, site, or user application directory (specified by one of the following environment variables: `UGII_UGOPEN_VENDOR_DIR`, `UGII_UGOPEN_SITE_DIR`, or `UGII_UGOPEN_USER_DIR`), loads it into a new, temporary XrmDatabase, and then merges it into the master XrmDatabase for the display connection (i.e. the application session). The merge automatically destroys the temporary database.

NOTE: This function is only available on Unix.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_load_resource_file
(
    const char * resource_file
)
```

<code>const char *</code>	resource_file	Input	The name of the vendor resource file to be loaded. The name does not include the path.
---------------------------	----------------------	-------	--

UF_MB_register_application [\(view source\)](#)

Defined in: `uf_mb.h`

Overview

Register the user application defined by the application button.

Environment

Internal

Required License(s)

gateway

```
int UF_MB_register_application
(
    UF_MB_application_p_t app
)
```

<code>UF_MB_application_p_t</code>	app	Input	User application data containing name of application to register.
------------------------------------	------------	-------	---

UF_MB_set_button_sensitivity (view source)

Defined in: uf_mb.h

Overview
Sets the button's sensitivity.

Environment
Internal

Required License(s)
gateway

```
int UF_MB_set_button_sensitivity
(
    int button_id,
    UF_MB_state_t state
)
```

int	button_id	Input	Button ID
UF_MB_state_t	state	Input	The button's sensitivity can be set to one of the following states: UF_MB_ON UF_MB_OFF

UF_MB_set_toggle_state (view source)

Defined in: uf_mb.h

Overview
Sets the state of a toggle button.

Environment
Internal

Required License(s)
gateway

```
int UF_MB_set_toggle_state
(
    int button_id,
    UF_MB_state_t state
)
```

int	button_id	Input	Button ID
UF_MB_state_t	state	Input	Sets the toggle buttons state on or off. Use one of the following constants:

UF_MB_ON
UF_MB_OFF