

ARMv8-A Foundation Platform

Version 10.3

User Guide



ARMv8-A Foundation Platform

User Guide

Copyright © 2012–2017 ARM Limited or its affiliates. All rights reserved.

Release Information

Document History

Issue	Date	Confidentiality	Change
A	10 October 2012	Non-Confidential	First release.
B	01 May 2013	Non-Confidential	Minor updates. Directory structure changed.
C	13 November 2013	Non-Confidential	Memory maps added. Update for Foundation Model v2.
D	24 June 2014	Non-Confidential	Minor updates. Update for v2.1.
E	28 November 2014	Non-Confidential	Update for v9.1. Added virtiop9 control.
F	28 February 2015	Non-Confidential	Update for v9.2.
G	31 May 2015	Non-Confidential	Update for v9.3.
H	31 August 2015	Non-Confidential	Update for v9.4.
I	30 November 2015	Non-Confidential	Update for v9.5.
J	29 February 2016	Non-Confidential	Update for v9.6.
K	31 May 2016	Non-Confidential	Update for v10.0.
L	31 August 2016	Non-Confidential	Update for v10.1.
M	11 November 2016	Non-Confidential	Update for v10.2.
N	17 February 2017	Non-Confidential	Update for v10.3.

Non-Confidential Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of ARM. **No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.**

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED “AS IS”. ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, ARM makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, third party patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word “partner” in reference to ARM’s customers is not intended to create or refer to any partnership relationship with any other company. ARM may make changes to this document at any time and without notice.

If any of the provisions contained in these terms conflict with any of the provisions of any signed written agreement covering this document with ARM, then the signed written agreement prevails over and supersedes the conflicting provisions of these terms. This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

Words and logos marked with ® or ™ are registered trademarks or trademarks of ARM Limited or its affiliates in the EU and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow ARM's trademark usage guidelines at <http://www.arm.com/about/trademark-usage-guidelines.php>

Copyright © 2012–2017, ARM Limited or its affiliates. All rights reserved.

ARM Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

LES-PRE-20349

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Unrestricted Access is an ARM internal classification.

Product Status

The information in this document is Final, that is for a developed product.

Web Address

<http://www.arm.com>

Contents

ARMv8-A Foundation Platform User Guide

Preface

About this book	7
-----------------------	---

Chapter 1

Introduction

1.1 Platform introduction	1-10
1.2 ARMv8 64-bit architecture overview	1-11
1.3 Software requirements	1-12
1.4 Platform overview	1-13

Chapter 2

Getting Started

2.1 Verifying the installation	2-17
2.2 The example program	2-18
2.3 Using Linux	2-19

Chapter 3

Programming Reference

3.1 ARMv8-A Foundation Platform memory map	3-21
3.2 Clock and timer	3-24
3.3 Interrupt maps	3-25
3.4 System register block	3-27
3.5 Command-line overview	3-29
3.6 CLCD window	3-31
3.7 Web interface	3-34
3.8 UARTs	3-35
3.9 Multicore configuration	3-36

3.10	<i>Semihosting overview</i>	3-37
------	-----------------------------------	------

Preface

This preface introduces the *ARMv8-A Foundation Platform User Guide*.

It contains the following:

- [About this book on page 7.](#)

About this book

This document describes the ARMv8-A Foundation Platform for the ARMv8-A architecture. It is an aid for hardware and software developers in developing ARMv8-A products.

Using this book

This book is organized into the following chapters:

Chapter 1 Introduction

This chapter describes the ARMv8-A Foundation Platform for the ARMv8-A architecture.

Chapter 2 Getting Started

This chapter describes validation and testing on the ARMv8-A Foundation Platform.

Chapter 3 Programming Reference

This chapter describes the ARMv8-A Foundation Platform.

Glossary

The ARM Glossary is a list of terms used in ARM documentation, together with definitions for those terms. The ARM Glossary does not contain terms that are industry standard unless the ARM meaning differs from the generally accepted meaning.

See the [ARM Glossary](#) for more information.

Typographic conventions

italic

Introduces special terminology, denotes cross-references, and citations.

bold

Highlights interface elements, such as menu names. Denotes signal names. Also used for terms in descriptive lists, where appropriate.

`monospace`

Denotes text that you can enter at the keyboard, such as commands, file and program names, and source code.

`monospace`

Denotes a permitted abbreviation for a command or option. You can enter the underlined text instead of the full command or option name.

`monospace italic`

Denotes arguments to monospace text where the argument is to be replaced by a specific value.

`monospace bold`

Denotes language keywords when used outside example code.

<and>

Encloses replaceable terms for assembler syntax where they appear in code or code fragments. For example:

```
MRC p15, 0, <Rd>, <CRn>, <CRm>, <Opcode_2>
```

SMALL CAPITALS

Used in body text for a few terms that have specific technical meanings, that are defined in the *ARM glossary*. For example, IMPLEMENTATION DEFINED, IMPLEMENTATION SPECIFIC, UNKNOWN, and UNPREDICTABLE.

Feedback

Feedback on this product

If you have any comments or suggestions about this product, contact your supplier and give:

- The product name.
- The product revision or version.
- An explanation with as much information as you can provide. Include symptoms and diagnostic procedures if appropriate.

Feedback on content

If you have comments on content then send an e-mail to errata@arm.com. Give:

- The title *ARMv8-A Foundation Platform User Guide*.
- The number ARM DUI0677N.
- If applicable, the page number(s) to which your comments refer.
- A concise explanation of your comments.

ARM also welcomes general suggestions for additions and improvements.

Note

ARM tests the PDF only in Adobe Acrobat and Acrobat Reader, and cannot guarantee the quality of the represented document when used with any other PDF reader.

Other information

- [ARM Developer](#).
- [ARM Information Center](#).
- [ARM Technical Support Knowledge Articles](#).
- [Support and Maintenance](#).
- [ARM Glossary](#).

Chapter 1

Introduction

This chapter describes the ARMv8-A Foundation Platform for the ARMv8-A architecture.

It contains the following sections:

- [1.1 Platform introduction on page 1-10.](#)
- [1.2 ARMv8 64-bit architecture overview on page 1-11.](#)
- [1.3 Software requirements on page 1-12.](#)
- [1.4 Platform overview on page 1-13.](#)

1.1 Platform introduction

The ARMv8-A Foundation Platform is an enabling platform for the ARMv8-A architecture.

It is a simple platform model capable of running bare-metal semi-hosted applications and booting a full operating system, with processor cluster, RAM, and some basic I/O devices such as Universal Asynchronous Receiver/Transmitters (UARTs), block storage, and network support. It also contains a simple web interface to indicate the status of the platform. It is supplied as a platform with configuration of the simulation from the command line and control using peripherals in the platform.

The processors in this platform are not based on any existing processor design, but conform to the ARMv8-A architectural specifications. This means that you can use the platform for confirming software functionality, but you must not rely on the accuracy of cycle counts, low-level component interactions, or other hardware-specific behavior

Related concepts

[3.7 Web interface on page 3-34.](#)

1.2 ARMv8 64-bit architecture overview

The ARMv8 architecture is both an extension and a successor to the ARMv7-A architecture. The first release of the ARMv8 architecture covers the A-profile only.

The ARMv8-A architecture extends the existing 32-bit architecture by introducing two execution states:

- A 32-bit state called AArch32.
- A 64-bit state called AArch64.

A number of changes have been made to the AArch32 functionality, but it remains compatible with the ARMv7-A architecture. Code conforming to AArch32 can run on ARMv7-A devices. In ARMv8, the A32 (ARM®) and T32 (Thumb®) instruction sets have some new instructions relative to the ARMv7-A *Instruction Set Architecture* (ISA).

The AArch64 state introduces a new fixed-length 32-bit instruction set called A64, while maintaining support for the same architectural capabilities as ARMv7-A, such as TrustZone® and Virtualization.

AArch64 has four Exception levels, 0-3, that replace the eight processor modes in ARMv7-A.

The least privileged, EL0, is equivalent to user-mode.

EL1 is equivalent to kernel-mode.

EL2 is used for hypervisors.

The highest privilege level, EL3, is used for the TrustZone security monitor.

Like ARMv7-A, AArch32 includes 13 general registers, R0-12, the Program Counter, R15, and two banked registers that contain the Stack Pointer, R13, and Link Register, R14. The User and System modes share these 16 registers and a *Program Status Register* (PSR). The new general purpose registers are all 64-bits wide to handle larger addresses, so 32-bit accesses use the lower halves of registers and either ignore or zero out the upper halves. The AArch32 registers map onto the lower halves of the AArch64 registers, and this permits AArch32 exceptions to be taken in AArch64 at a higher Exception level.

The two forms of instruction operate on either 32-bit or 64-bit values within the 64-bit general-purpose register file. Where a 32-bit instruction form is selected, the following holds true:

- The upper 32 bits of the source registers are ignored.
- The upper 32 bits of the destination registers are set to zero.
- Condition flags, where set by the instruction, are computed from the lower 32 bits.

For more information about the ARMv8-A architecture, see the [ARM® Architecture Reference Manual](#).

1.3 Software requirements

This section describes the host software that is required to run the ARMv8-A Foundation Platform.

Operating Systems

- Redhat Enterprise Linux version 6.x for 64-bit Intel architectures.
- Ubuntu 12.04 or later for 64-bit Intel architectures.
- Microsoft Windows 7 64-bit.

Note

Currently, there is no support for running the platform on other operating systems. However, the platform runs on any recent x86 64-bit Linux OS provided glibc v2.3.2, or higher, and libstdc++ 6.0.0, or higher, are present.

UART Output

For the *Universal Asynchronous Receiver/Transmitter* (UART) output to be visible, both `xterm` and `telnet` must be installed on the host, and be specified in your `PATH`.

1.4 Platform overview

This section describes the features and limitations of the Foundation Platform, and the types of network support that are provided.

This section contains the following subsections:

- [1.4.1 Features and network support of the Foundation Platform on page 1-13.](#)
- [1.4.2 Limitations of the Foundation Platform on page 1-15.](#)

1.4.1 Features and network support of the Foundation Platform

The ARMv8-A Foundation Platform has numerous features and two types of network support.

The platform provides:

- An ARMv8-A cluster model containing 1-4 cores that implements:
 - ARMv8.0, ARMv8.1, and ARMv8.2.
 - AArch64 at all Exception levels.
 - AArch32 support at EL0 and EL1.
 - Little and big endian at all Exception levels.
 - Generic timers.
 - Self-hosted debug.
 - GICv2, and optional GICv3 memory-mapped processor interfaces and distributor.
- 8GB of RAM.

————— **Note** —————

The platform simulates up to 8GB of RAM.

To simulate a system with 4GB of RAM, you require a host with at least 8GB of RAM.

To simulate a system with 8GB of RAM, you require a host with at least 12GB of RAM.

- Four PL011 UARTs connected to xterms.
- Platform peripherals including a Real-time clock, Watchdog timer, Real-time timer, and Power controller.
- Secure peripherals including a Trusted watchdog, Random number generator, Non-volatile counters, and Root-key storage.
- A network device model that is connected to host network resources.
- A block storage device that is implemented as a file on the host.
- A small system register block with LEDs and switches visible using a web server.
- Host filesystem access that is implemented as Plan 9 filesystem.
- A CLCD that allows GUI visualization.
- Debug capabilities through the use of a CADI server.

Caches are modeled as stateless and there are no write buffers. This gives the effect of perfect memory coherence on the data side. The instruction side has a variable size prefetch buffer so requires correct barriers to be used in target code to operate correctly.

The platform runs as fast as possible unless all the cores in the cluster are *Wait for Interrupt* (WFI) or *Wait for Exception* (WFE). In the case of WFE, the platform idles until an interrupt or external event occurs.

The Foundation Platform has been revised to support the ARM *Trusted Base System Architecture* (TBSA) and *Server Base System Architecture* (SBSA). Several peripheral devices have been added, with corresponding changes to the memory map. It has also been updated to align more closely with peripherals present in the Versatile™ Express baseboard and the ARM Fast Models.

Software that is written to target the previous versions of the platform work unmodified on the platform using the default `--no-gicv3` configuration option. Only software that uses the early blocks of RAM is likely to require some adjustments.




Figure 1-1 Block diagram of ARMv8-A Foundation Platform

Note

The behavior of the address decoding block depends on whether the `--secure-memory` command-line option is used.

The platform provides the following types of network support:

NAT, IPv4 based

NAT, IPv4-based networking provides limited IP connectivity by using user-level IP services. This requires no extra privileges to set up or use, but has inherent limitations. System-level services, or services conflicting with those services on the host, can be provided using port remapping.

Bridged

Bridged networking requires the setup of an ethernet bridge device to bridge between the ethernet port on the host and the network interface that the platform provides. This usually requires administrator privileges. See the documentation in the Linux bridge-utils package for more information.

The ARMv8-A Foundation Platform uses ARM Fast Model technology and forms part of a comprehensive suite of modeling solutions for ARM processors. These modeling solutions are available in the portfolio of models that are delivered through the ARM Fast Models product. For more information, see the *Fast Models User Guide*.

Related references

[3.1 ARMv8-A Foundation Platform memory map](#) on page 3-21.

1.4.2 Limitations of the Foundation Platform

There are some restrictions that apply to the ARMv8-A Foundation Platform.

- Write buffers are not modeled.
- Interrupts are not taken at every instruction boundary.
- Caches are modeled as stateless.
- There is no Trace or other plug-in support.
- There is no support for Thumb2EE.
- There is no support for the ARMv8 cryptography extensions.
- ARM does not offer direct customer support for the Foundation Platform. For technical support use the ARM Connected Community, <http://community.arm.com>.

Chapter 2

Getting Started

This chapter describes validation and testing on the ARMv8-A Foundation Platform.

It contains the following sections:

- [2.1 Verifying the installation on page 2-17.](#)
- [2.2 The example program on page 2-18.](#)
- [2.3 Using Linux on page 2-19.](#)

2.1 Verifying the installation

The Foundation Platform is available only as a prebuilt platform binary.




Figure 2-1 Hierarchy of installed files

The installation directory contents are:

examples

Includes a C version and .axf file of the Hello World program. It also includes the Makefile and the example source code for the device tree, foundation-platform.dts.

Foundation_Platform

The ARMv8-A Foundation Platform executable file.

libMAXCOREInitSimulationEngine.so.2

Helper library required by the platform.

libarmctmodel.so

Code translation library.

FoundationPlatform_Readme.txt

Short summary of this user guide.

DUI0677<revision>_armv8_a_fp_ug.pdf

This document.

LES-PRE-20164-V8_0_Foundation_Platform.txt

End-user license agreement.

Related tasks

[2.2.1 Running the example program on page 2-18.](#)

2.2 The example program

You can use the example program that is supplied to confirm that the ARMv8-A Foundation Platform is working correctly.

This section contains the following subsections:

- [2.2.1 Running the example program on page 2-18.](#)
- [2.2.2 Troubleshooting the example program on page 2-18.](#)

2.2.1 Running the example program

This section describes how to run the example program.

Run the platform with the following command line:

Procedure

1. `./Foundation_Platform --image hello.axf`
2. Add `--quiet` to suppress everything except for the output from the example program.

You receive a similar output to the following:

```
terminal_0: Listening for serial connection on port 5000
terminal_1: Listening for serial connection on port 5001
terminal_2: Listening for serial connection on port 5002
terminal_3: Listening for serial connection on port 5003
Simulation is started
Hello, 64-bit world!
Simulation is terminating. Reason: Simulation stopped
```

The example demonstrates that the platform initializes correctly as it loads and executes the example program. It also demonstrates that the semihosting calls to print output and stop the platform work properly.

2.2.2 Troubleshooting the example program

You can encounter common error messages when running the example program.

- If you attempt to run the example program on a 32-bit Linux host, it gives an error similar to the following:

```
./Foundation_Platform: /lib64/ld-linux-x86-64.so.2: bad ELF interpreter: No such file or directory
```

- If `libstdc++` is not installed on your system, you get the following error on startup:

```
./Foundation_Platform: error while loading shared libraries: libstdc++.so.6: cannot open shared object file
```

- If your system `glibc` is too old, or your `libstdc++` is too old, you get the following messages:

```
./Foundation_Platform: /usr/lib64/libstdc++.so.6: version `GLIBCXX_3.4' not found
(required by Foundation_Platform)
./Foundation_Platform: /lib64/libc.so.6: version `GLIBC_2.3.2' not found (required by
Foundation_Platform)
./Foundation_Platform: /lib64/libc.so.6: version `GLIBC_2.2.5' not found (required by
Foundation_Platform)
```

`libstdc++` and `glibc` are normally part of your core OS installation.

2.3 Using Linux

You can also use Linux with the ARMv8-A Foundation Platform.

For information on configuring and building the arm64 port of Linux to run on the ARMv8-A Foundation Platform, see the Linaro website at <http://www.linaro.org/engineering/armv8>.

Chapter 3

Programming Reference

This chapter describes the ARMv8-A Foundation Platform.

It contains the following sections:

- [3.1 ARMv8-A Foundation Platform memory map on page 3-21.](#)
- [3.2 Clock and timer on page 3-24.](#)
- [3.3 Interrupt maps on page 3-25.](#)
- [3.4 System register block on page 3-27.](#)
- [3.5 Command-line overview on page 3-29.](#)
- [3.6 CLCD window on page 3-31.](#)
- [3.7 Web interface on page 3-34.](#)
- [3.8 UARTs on page 3-35.](#)
- [3.9 Multicore configuration on page 3-36.](#)
- [3.10 Semihosting overview on page 3-37.](#)

3.1 ARMv8-A Foundation Platform memory map

This section describes the memory map for the ARMv8-A Foundation Platform.

The following list shows the Secure and Non-secure access permissions that are enabled by using the `--(no-)secure-memory` parameter.

Table 3-1 Access permissions

	<code>--no-secure-memory</code>	<code>--secure-memory</code>
S	Secure and Non-secure accesses are permitted.	Secure access is permitted, Non-secure access aborts.
S/NS	Secure and Non-secure accesses are permitted.	Secure and Non-secure accesses are permitted.

The following table shows the global memory map for the ARMv8-A Foundation Platform. This map is based on the Versatile Express RS2 memory map with extensions.

Note

- Unless you use the `--quiet` command-line option, areas of memory that are highlighted in the table return a warning to the console, together with RAZ/WI access behavior. This rule is applicable to Foundation Model v2 and Foundation Platform v9.
- Writes are ignored.
- Accesses from Foundation Model v1 cause an abort exception.

Note

The Security column in the following table applies to the Foundation Model v2 and Foundation Platform v9 only.

Table 3-2 ARMv8-A Foundation Platform memory map

Start address	End address	Foundation v1 peripheral	Foundation v2 and v9 peripherals	Size	Security (v2 and v9 only)
0x00_0000_0000	0x00_03FF_FFFF	RAM	Trusted Boot ROM, secureflash	64MB	S
0x00_0400_0000	0x00_0403_FFFF	RAM	Trusted SRAM	256KB	S
0x00_0600_0000	0x00_07FF_FFFF	RAM	Trusted DRAM	32MB	S
0x00_0800_0000	0x00_0BFF_FFFF	-	NOR flash, flash0	64MB	S/NS
0x00_0C00_0000	0x00_0FFF_FFFF	-	NOR flash, flash1	64MB	S/NS
0x00_1800_0000	0x00_19FF_FFFF	-	VRAM	32MB ^a	-
0x00_1A00_0000	0x00_1AFF_FFFF	Ethernet, SMSC 91C111	Ethernet, SMSC 91C111	16MB	S/NS
0x00_1C01_0000	0x00_1C01_FFFF	System Registers	System Registers	64KB	S/NS
0x00_1C02_0000	0x00_1C02_FFFF	-	System Controller, SP810	64KB	S/NS
0x00_1C04_0000	0x00_1C07_FFFF	-	Warning + RAZ/WI	-	-
0x00_1C09_0000	0x00_1C09_FFFF	UART0, PL011	UART0, PL011	64KB	S/NS
0x00_1C0A_0000	0x00_1C0A_FFFF	UART1, PL011	UART1, PL011	64KB	S/NS

^a 8MB of VRAM is replicated 4 times in memory.

Table 3-2 ARMv8-A Foundation Platform memory map (continued)

Start address	End address	Foundation v1 peripheral	Foundation v2 and v9 peripherals	Size	Security (v2 and v9 only)
0x00_1C0B_0000	0x00_1C0B_FFFF	UART2, PL011	UART2, PL011	64KB	S/NS
0x00_1C0C_0000	0x00_1C0C_FFFF	UART3, PL011	UART3, PL011	64KB	S/NS
0x00_1C0D_0000	0x00_1C0D_FFFF	-	Warning + RAZ/WI	-	-
0x00_1C0F_0000	0x00_1C0F_FFFF	-	Watchdog, SP805	64KB	S/NS
0x00_1C10_0000	0x00_1C10_FFFF	-	Base Platform Power Controller	64KB	S/NS
0x00_1C11_0000	0x00_1C11_FFFF	-	Dual-Timer 0, SP804	64KB	S/NS
0x00_1C12_0000	0x00_1C12_FFFF	-	Dual-Timer 1, SP804	64KB	S/NS
0x00_1C13_0000	0x00_1C13_FFFF	Virtio block device	Virtio block device	64KB	S/NS
0x00_1C14_0000	0x00_1C16_FFFF	-	Virtio Plan 9 for v9, Warning + RAZ/W for v2.1	-	-
0x00_1C17_0000	0x00_1C17_FFFF	-	Realtime Clock, PL031	64KB	S/NS
0x00_1C1A_0000	0x00_1FFF_FFFF	-	Warning + RAZ/W	-	-
0x00_1F00_0000	0x00_1F00_0FFF	-	Non-trusted ROM	4KB	S/NS
0x00_2A43_0000	0x00_2A43_FFFF	-	REFCLK CNTControl, Generic Timer	64KB	S
0x00_2A44_0000	0x00_2A44_FFFF	-	EL2 Generic Watchdog Control	64KB	S/NS
0x00_2A45_0000	0x00_2A45_FFFF	-	EL2 Generic Watchdog Refresh	64KB	S/NS
0x00_2A49_0000	0x00_2A49_FFFF	-	Trusted Watchdog, SP805	64KB	S
0x00_2A4A_0000	0x00_2A4A_FFFF	-	Warning + RAZ/W	-	-
0x00_2A80_0000	0x00_2A80_FFFF	-	REFCLK CNTRead, Generic Timer	64KB	S/NS
0x00_2A81_0000	0x00_2A81_FFFF	-	AP_REFCLK CNTCTL, Generic Timer	64KB	S/NS
0x00_2A82_0000	0x00_2A82_FFFF	-	AP_REFCLK CNTBase0, Generic Timer	64KB	S
0x00_2A83_0000	0x00_2A83_FFFF	-	AP_REFCLK CNTBase1, Generic Timer	64KB	S/NS
0x00_2C00_0000	0x00_2C00_1FFF	-	GIC Physical CPU interface, GICC ^b	8KB	S/NS
0x00_2C00_1000	0x00_2C00_1FFF	GIC Distributor	GIC Distributor ^c	4KB	-
0x00_2C00_2000	0x00_2C00_2FFF	GIC Processor Interface	GIC Processor Interface ^c	4KB	-
0x00_2C00_4000	0x00_2C00_4FFF	GIC Processor Hyp Interface	GIC Processor Hyp Interface ^c	4KB	-
0x00_2C00_5000	0x00_2C00_5FFF	GIC Hyp Interface	GIC Hyp Interface ^c	4KB	-

^b The Foundation Model v2.1 only. Not the Foundation Platform.

^c The Foundation Platform uses the GICv2 memory map by default, or if you use the `--no-gicv3` configuration parameter.

Table 3-2 ARMv8-A Foundation Platform memory map (continued)

Start address	End address	Foundation v1 peripheral	Foundation v2 and v9 peripherals	Size	Security (v2 and v9 only)
0x00_2C00_6000	0x00_2C00_7FFF	GIC Virtual CPU Interface	GIC Virtual CPU Interface ^c	8KB	-
0x00_2C01_0000	0x00_2C01_0FFF	-	GIC Virtual Interface Control, GICH	4KB	S/NS
0x00_2C02_F000	0x00_2C03_0FFF	-	GIC Virtual CPU Interface, GICV	8KB	S/NS
0x00_2C09_0000	0x00_2C09_FFFF	-	Warning + RAZ/W	-	-
0x00_2E00_0000	0x00_2E00_FFFF	-	Non-trusted SRAM	64KB	S/NS
0x00_2F00_0000	0x00_2F00_FFFF	-	GICv3 Distributor GICD ^b	64KB	S/NS
0x00_2F10_0000	0x00_2F1F_FFFF	-	GICv3 Distributor GICR	1MB	S/NS
0x00_7FE6_0000	0x00_7FE6_0FFF	-	Trusted Random Number Generator	4KB	S
0x00_7FE7_0000	0x00_7FE7_0FFF	-	Trusted Non-volatile counters	4KB	S
0x00_7FE8_0000	0x00_7FE8_0FFF	-	Trusted Root-Key Storage	4KB	S
0x00_8000_0000	0x00_FFFF_FFFF	DRAM (0GB - 2GB)	DRAM (0GB - 2GB)	2GB	S/NS
0x08_8000_0000	0x09_FFFF_FFFF	DRAM (2GB - 8GB)	DRAM (2GB - 8GB)	6GB	S/NS

Related references

[3.5 Command-line overview on page 3-29.](#)

3.2 Clock and timer

This section describes the frequencies of the clock and timer.

Cluster `clk_in` frequency parameter
100MHz.

GenericTimer `base_frequency` parameter
100MHz.

3.3 Interrupt maps

You can find information on the SPIs and PPIs on the GIC that the platform assigns.

Note

Shared Peripheral Interrupt (SPI) and Private Peripheral Interrupt (PPI) numbers are mapped onto GIC interrupt IDs as the ARM® Generic Interrupt Controller Architecture Specification describes.

The following table lists the SPI assignments.

Table 3-3 Shared peripheral interrupt assignments

IRQ ID	SPI offset	Device
32	0	Watchdog, SP805
34	2	Dual-Timer 0, SP804
35	3	Dual-Timer 1, SP804
36	4	Realtime Clock, PL031
37	5	UART0, PL011
38	6	UART1, PL011
39	7	UART2, PL011
40	8	UART3, PL011
41	9	MCI, PL180, MCINTRO
46	14	PL111 CLCD
47	15	Ethernet, SMSC 91C111
56	24	Trusted Watchdog, SP085
57	25	AP_REFCLK, Generic Timer, CNTPSIRQ
58	26	AP_REFCLK, Generic Timer, CNTPSIRQ1
59	27	EL2 Generic Watchdog WS0
60	28	EL2 Generic Watchdog WS1
74	42	Virtio block device
75	43	Virtio Plan 9
92	60	cpu0 PMUIRQ
93	61	cpu1 PMUIRQ
94	62	cpu2 PMUIRQ
95	63	cpu3 PMUIRQ

The following table shows the PPI assignments:

Table 3-4 Private Peripheral Interrupt map

PPI	Device
9	Virtual maintenance interrupt
10	Hypervisor timer event
11	Virtual timer event
13	Secure physical timer event
14	Non-secure physical timer event

3.4 System register block

The system register block provides a minimal set of registers.

This component only accepts word writes and aligned reads.

Table 3-5 System register block

Offset	Type	Bits	Register
0x0000	R/O	[31:0]	System ID Register
0x0004	R/W	[7:0]	User Programmable Switches
0x0008	R/W	[7:0]	LEDs
0x00A0	R/W	[31:0]	System configuration data
0x00A4	R/W	[31:0]	System configuration control
0x00A8	R/W	[31:0]	System configuration status

The System ID Register is divided into the following fields:

- ID[31:28] Revision.
 - 0x2 Foundation Platform v9.1-v9.5.
 - 0x3 Foundation Platform v9.6.
- ID[27:16] HBI board number.
 - 0x010 ARMv8-A Foundation Platform, default.
 - 0x020 ARM Base Platform FVP.
- ID[15:12] Build variant. The value depends on the following command-line options:
 - 0x0 Variant A is the Foundation Platform with the GICv2 legacy map, when the `--no-givc3` command-line option is used. This is the default.
 - 0x1 Variant B is the Foundation Platform with the GICv3 64kB memory map, when the `--gicv3` command-line option is used.
- ID[11:8] Platform type:
 - 0x0 Board.
 - 0x1 Model, default.
 - 0x2 Emulator.
 - 0x3 Simulator.
 - 0x4 FPGA.
- ID[7:0] FPGA build.
 - Not used.

The System ID register is not implemented in the Foundation Model v1. All unimplemented registers in the Foundation Model v1 system register block return the value 0xDEADDEAD on reads. You can use this

value to distinguish Foundation Model v1 from both Foundation Model v2 and Foundation Platform v9, and FVP VE Base Platform.

The user-programmable Switches store 8 bits of state that can be read or written by software on the platform. You can configure the startup value, `val`, using `--switches=val`.

You can view and set the switches at run time from the web interface.

The LEDs store 8 bits of state that software can read or write on the platform and can be viewed at runtime from the web interface.

The system configuration control register provides two functions:

- Writing the value `0xC0800000` stops the simulation and returns control to the command line.
- Writing the value `0xC0900000` asserts and then clears the reset pins on all components in the simulation. It resets the system without clearing the contents of the RAMs.

Note

Writes to the system configuration register can take several instructions to complete. Therefore, a write to this register must be followed by a DSB and infinite loop.

The system configuration data and status registers always return 0 on reads, and writes are ignored.

Related concepts

[3.7 Web interface on page 3-34.](#)

3.5 Command-line overview

Command-line arguments provide all platform configuration. Run the platform with `--help` to obtain a summary of the available commands.

The syntax to use on the command line is:

```
./Foundation_Platform [OPTIONS...]
```

Table 3-6 Command-line options

<code>--arm-v8.n</code>	Enable the ARMv8. <i>n</i> version of the architecture, where $0 \leq n \leq 2$. The default is ARMv8.2.
<code>--bigendian</code>	Start processors in big endian mode. The default is little endian.
<code>--block-device=file</code>	Image file to use as persistent block storage.
<code>--cadi-server</code>	Start the CADI server. This allows debuggers to connect to targets in the simulation.
<code>--cores=N</code>	Specify the number of cores, where N ranges 1-4. The default is 1.
<code>--(ns)data=file@address</code>	Raw file to load at an address in Non-secure or Secure memory.
<code>--(no-)gicv3</code>	Enable GICv3 or legacy compatible GICv2 as interrupt controller. The default is <code>--no-gicv3</code> , that is, GICv2 mode.
<code>--help</code>	Display the help message and quit.
<code>--image=file</code>	<i>Executable and Linking Format</i> (ELF) image to load.
<code>--network=(none nat bridged)</code>	Configure mode of network access. The default is none.
<code>--network-bridge=dev</code>	Bridged network device name. The default is ARM0.
<code>--network-mac-address</code>	MAC address to use for networking. The default is 00:02:f7:ef:f6:74.
<code>--network-nat-ports=M</code>	Optional comma-separated list of NAT port mappings in the form: <code>host_port=model_port</code> , for example, 8022=22.
<code>--network-nat-subnet=S</code>	Subnet used for NAT networking. The default is 172.20.51.0/24.
<code>--p9_root_dir</code>	Host folder to be shared with the guest.
<code>--print-port-number</code>	Print the port number that the CADI server is listening to.
<code>--quiet</code>	Suppress any non-simulated output on <code>stdout</code> or <code>stderr</code> .
<code>--(no-)rate-limit</code>	Restrict simulation speed so that simulation time more closely matches real time rather than running as fast as possible. The default is disabled.
<code>--read-only</code>	Mount block device image in read-only mode.
<code>--(no-)secure-memory</code>	Enable or disable separate Secure and Non-secure address spaces. The default is disabled.
<code>--(no-)semihost</code>	Enable or disable semihosting support. The default is enabled.
<code>--semihost-cmd=cmd</code>	A string that is used as the semihosting command line.
<code>--switches=val</code>	Initial setting of switches in the system register block (default: 0).
<code>--uart-start-port=P</code>	Attempt to listen on a free TCP port in the range P to P+100 for each UART. The default is 5000.
<code>--use-real-time</code>	Sets the generic timer registers to report a view of real time as it is seen on the host platform. The generic timer registers are irrespective of how slow or fast the simulation runs.
<code>--version</code>	Display the version and build numbers and quit.
<code>--(no-)visualization</code>	Starts a small web server to visualize platform state. The default is disabled.

You can specify more than one `--image`, `--data`, or `--nsdata` option. The images and data are loaded in the order that they appear on the command line. The simulation starts from the entry point of the last ELF file specified.

Related concepts

[3.9 Multicore configuration on page 3-36.](#)

[3.7 Web interface on page 3-34.](#)

[3.10.1 Semihosting on page 3-37.](#)

3.6 CLCD window

When the model starts, the Foundation Platform CLCD window opens, representing the contents of the simulated color LCD frame buffer. It automatically resizes to match the horizontal and vertical resolution set in the CLCD peripheral registers.

The following figure shows the Foundation Platform CLCD in its default state, immediately after being started:




Figure 3-1 CLCD window at startup

The top section of the CLCD window displays the following status information:

Total Instr

A counter showing the total number of instructions executed.

Total Time

A counter showing the total elapsed time, in seconds.

This is wall clock time, not simulated time.

Rate Limit

This option limits the rate of simulated time when the cores are in WFI, reset, or otherwise idle. Simulation time is restricted so that it more closely matches real time.

Rate Limit is disabled by default. Click the square button to enable it. The text changes from OFF to ON and the colored box becomes lighter red when the Rate Limit is enabled.

Note

You can also control whether the Rate Limit is enabled by using the `--(no-)rate-limit` parameter when instantiating the model.

Instr / sec

Shows the number of instructions executed per second of wall clock time.

Perf Index

The ratio of real time to simulation time. The larger the ratio, the faster the simulation runs. If you enable the Rate Limit feature, the Perf Index approaches unity.

Icons

Icons to represent different processor states.

The following table shows each of the possible icons:

Note

The icons do not appear until you start the simulation.

Table 3-7 Core run state icon descriptions









Icon	State label	Description
	UNKNOWN	Run status unknown, that is, simulation has not started.
	RUNNING	The core is running, is not idle, and is executing instructions.


Table 3-7 Core run state icon descriptions (continued)

Icon	State label	Description
	HALTED	An external halt signal is asserted.
	STANDBY_WFE	The last instruction executed was WFE, and standby mode has been entered.
	STANDBY_WFI	The last instruction executed was WFI and standby mode has been entered.
	IN_RESET	An external reset signal is asserted.
	DORMANT	Partial core power down.
	SHUTDOWN	Complete core power down.

Note

The icons do not appear until you start the simulation.

The large area at the bottom of the window displays the contents of the CLCD buffer. The following figure shows this:

**Figure 3-2 CLCD window active**

You can hide the host mouse pointer by pressing the **Left Ctrl+Left Alt** keys. Press the keys again to redisplay the host mouse pointer. Only the **Left Ctrl** key is operational. The **Ctrl** key on the right-hand side of the keyboard does not have the same effect.

3.7 Web interface

This section describes the syntax to use on the command line.

You can use one of the following options in the command line:

- `./Foundation_Platform --visualization`
- `./Foundation_Platform --no-visualization`

Running the platform with the `--visualization` option, and without the `--quiet` option, shows the additional output:

```
terminal_0: Listening for serial connection on port 5000
terminal_1: Listening for serial connection on port 5001
terminal_2: Listening for serial connection on port 5002
terminal_3: Listening for serial connection on port 5003
Visualization web server started on port 2001
```

The `terminal_n` lines relate to the UARTs.

Go to the address `http://127.0.0.1:2001` with your web browser.

The browser displays a visualization window.




Figure 3-3 Visualization window

The visualization window provides a dynamic view of the state of various parts of the platform and the ability to change the state of platform switches.

Related concepts

[3.8 UARTs on page 3-35.](#)

3.8 UARTs

When the Foundation Platform starts, it initializes four UARTs. For each UART, it searches for a free TCP port to use for telnet access to the UART. It searches by sequentially scanning a range of 100 ports and using the first free port. The start port defaults to 5000 and you can change it using the `--uart-start-port` command-line parameter.

Connecting a terminal or program to the given port displays and receives output from the associated UART and permits input to the UART.

If no terminal or program is connected to the port when data is output from the UART, a terminal is started automatically.

Note

A terminal only starts automatically if the `DISPLAY` environment variable is set and not empty.

UART output

For the UART output to be visible, both `xterm` and `telnet` must be installed on the host, and be specified in your `PATH`.

3.9 Multicore configuration

By default, the platform starts up with a single core that begins executing from the entry point in the last provided ELF image, or address 0 if no ELF images are provided.

You can configure the platform using `--cores=N` to have up to four processor cores. Each core starts executing the same set of images, starting at the same address. The `--visualization` command-line option which is used with the multicore option, results in a visualization window.




Figure 3-4 Multicore option with number of cores = 4

3.10 Semihosting overview

This section describes semihosting and semihosting configuration.

This section contains the following subsections:

- [3.10.1 Semihosting on page 3-37](#).
- [3.10.2 Semihosting configuration on page 3-37](#).

3.10.1 Semihosting

Semihosting enables code running on a platform model to directly access the I/O facilities on a host computer.

The simulator handles semihosting by either:

- Intercepting SVC 0x123456 or 0xAB in AArch32 execution state, depending on whether the processor is in the ARM or Thumb instruction set state.
- Intercepting HLT 0xF000 in AArch64 execution state.

3.10.2 Semihosting configuration

You can use different commands for the semihosting configuration.

The syntax to use on the command line to enable or disable semihosting is as follows:

```
./Foundation_Platform --(no-)semihost
```

The syntax to use on the command line to set the semihosting command-line string is as follows:

```
./Foundation_Platform --semihost-cmd=<command string>
```