

# Robotic Hand

## Instructions

### Default Mode:

The hand imitates all the moves of the glove. It's the default mode of the hand, it'll always come back to this mode.

### Paper, Rock, Scissors Mode:

The playing mode of the hand, the move of the hand will be random. And if it wins, losses or it's a draw it'll make a different position of ending before to come back to the previous mode.

To play this mode keep all the fingers closed except for the little, that has to be stretched, keep that position for a few seconds.

### Win Mode:

On this mode the hand will always win. It doesn't have any position at the end and it'll come back to default mode.

To run this mode, keep all the fingers closed except for the thumb, that has to be stretched, keep that position for a few seconds.

### Lose Mode:

On this mode the hand will always lose. It doesn't have any position at the end and it'll come back to default mode.

To run this mode, keep all the fingers closed except for the index, that has to be stretched, keep that position for a few seconds.