

Number: SOP-BUS-TRANSFER	Use Category: CONTINUOUS	Major Rev: 001 Minor Rev: 001 Page: 1 of 3
Title: Bus Transfers		

1.0 SM-1 TRANSFER TO TR-N1

1.1 **PLACE** CB-N1/1 Sync Selector to **ON**.

NOTE: CB-S1 trip annunciator is expected in this next step.

1.2 **CLOSE** CB-N1/1.

1.3 **VERIFY** CB-N1/1 closed and CB-S1 open.

1.4 **PLACE** CB-S1 in **TRIP**.

1.5 **PLACE** CB-N1/1 Sync Selector to **OFF**.

2.0 SM-2 TRANSFER TO TR-N1

2.1 **PLACE** CB-N1/2 Sync Selector to **ON**.

NOTE: CB-S2 trip annunciator is expected in this next step.

2.2 **CLOSE** CB-N1/2.

2.3 **VERIFY** CB-N1/2 closed and CB-S2 open.

2.4 **PLACE** CB-S2 in **TRIP**.

2.5 **PLACE** CB-N1/2 Sync Selector to **OFF**.

Number: SOP-BUS-TRANSFER	Use Category: CONTINUOUS	Major Rev: 001 Minor Rev: 001 Page: 2 of 3
Title: Bus Transfers		

3.0 SM-3 TRANSFER TO TR-N1

3.1 **PLACE** CB-N1/3 Sync Selector to **ON**.

NOTE: CB-S3 trip annunciator is expected in this next step.

3.2 **CLOSE** CB-N1/3.

3.3 **VERIFY** CB-N1/3 closed and CB-S3 open.

3.4 **PLACE** CB-S3 in **TRIP**.

3.5 **PLACE** CB-N1/3 Sync Selector to **OFF**.

4.0 SH-5 TRANSFER TO TR-N2

3.1 **PLACE** CB-N2/5 Sync Selector to **ON**.

NOTE: CB-S5 trip annunciator is expected in this next step.

3.2 **CLOSE** CB-N2/5.

3.3 **VERIFY** CB-N2/5 closed and CB-S5 open.

3.4 **PLACE** CB-S5 in **TRIP**.

3.5 **PLACE** CB-N2/5 Sync Selector to **OFF**.

Number: SOP-BUS-TRANSFER	Use Category: CONTINUOUS	Major Rev: 001
Title: Bus Transfers		Minor Rev: 001 Page: 3 of 3

4.0 SH-6 TRANSFER TO TR-N2

3.1 **PLACE** CB-N2/6 Sync Selector to **ON**.

NOTE: CB-S6 trip annunciator is expected in this next step.

3.2 **CLOSE** CB-N2/6.

3.3 **VERIFY** CB-N2/6 closed and CB-S6 open.

3.4 **PLACE** CB-S6 in **TRIP**.

3.5 **PLACE** CB-N2/6 Sync Selector to **OFF**.