

Number: SOP-MSIV-OPS	Use Category: CONTINUOUS	Major Rev: 003
Title: MSIV Operations		Minor Rev: 001
		Page: 1 of 1

1.0 OPENING MSIVs

1.1 **VERIFY** MSIV isolation signals reset.

1.2 **PLACE** the following switches in OPEN/SLOW TST;

- MS-V-22A
- MS-V-22B
- MS-V-22C
- MS-V-22D
- MS-V-28A
- MS-V-28B
- MS-V-28C
- MS-V-28D

1.3 WHEN all MSIVs are open,
THEN **PLACE** the following switches in AUTO.

- MS-V-22A
- MS-V-22B
- MS-V-22C
- MS-V-22D
- MS-V-28A
- MS-V-28B
- MS-V-28C
- MS-V-28D