

Number: SOP-RWM-STBY	Use Category: CONTINUOUS	Major Rev: 003
Title: RWM Standby		Minor Rev: 001
		Page: 1 of 1

1.0 STANDBY

- 1.1 **VERIFY** RWM Bypass Key inserted.
- 1.2 **VERIFY** RWM Bypass key in NORMAL.
- 1.3 **DEPRESS** "SYSTEM INITIALIZE".
- 1.4 **DEPRESS** "PROGRAM".