

Number: SOP-RHR-SDC	Use Category: CONTINUOUS	Major Rev: 003 Minor Rev: 001 Page: 1 of 1
Title: RHR System Shutdown Cooling		

1.0 ESTABLISHING

1.1 SDC WITH RHR-A

1.2 SDC WITH RHR-B

2.0 SECURING

CAUTION

Closing RHR-V-53A(B) or RHR-V-3A(B) before stopping the associated RHR pump may result in pumping the RPV to the suppression pool through the minimum flow valve. This procedure may NOT be performed out of order.

2.1 RHR-A

2.1.1 **STOP** RHR-P-2A.

2.1.2 **CLOSE** RHR-V-53A.

2.1.3 **CLOSE** RHR-V-6A.

2.2 RHR-B

2.2.1 **STOP** RHR-P-2B.

2.2.2 **CLOSE** RHR-V-53B.

2.2.3 **CLOSE** RHR-V-6B.