

| (Type) | Format | Name | Description |
|--------|----------------|------------------------------|---|
| .BK | text | Converter backup file | The source .KL file is renamed to extension .BK prior to conversion. |
| .CF | text | Command file | A sequence of KCL commands. |
| .DT | binary or text | Data | A set of data generated by a KAREL program. |
| .ETX | text | Dictionary error text | Contains dictionary error text that has not been compressed. |
| .FTX | text | Dictionary form text | Contains dictionary form text that has not been compressed. |
| .KL | text | KAREL program | A KAREL source program. |
| .LS | text | Listing | A KAREL program listing. Includes line numbers and a data reference table. |
| .PC | binary | Pcode | A translated KAREL program. |
| .SV | binary | System | A set of variable data, servo parameter data, and dynamic mastering data from the controller system. |
| .SVS | text | System variable source | The text form of a system, servo parameter, or dynamic mastering (.SV) file. Generated as a byproduct when a .SV file is printed. |
| .TP | binary | Teach pendant program file | Contains teach pendant program information that, when loaded onto controller memory, can be edited using the teach pendant editor and executed. |
| .TX | text | Dictionary text | Contains system or userdefined text. |
| .UTX | text | Uncompressed dictionary text | Contains system or userdefined text that has not been compressed. |
| .VR | binary | Program variable | A set of variable data associated with a KAREL program |
| .VRS | text | Program variable source | The text form of a program variable (.VR) file. Generated as a byproduct when a .VR file is printed. |
| .XRF | text | Cross reference | Contains cross reference information for KAREL program files. |