

# Honda Pioneer Oil Change

---

This HowTo covers an oil change on a Honda Pioneer 2019 700 Delux. It should apply to other years and models, although part numbers may vary. It should also be noted that these steps were performed on a Pioneer that had already been through the initial 25 hour service at the dealer!

Oil change intervals are ever X miles or Y hours in optimal conditions. Operating in hostile conditions will require more frequent service (you know who you are :- ) ).

## Supplies (OEM except the Oil)

---

- Oil:
- Oil Filter:
  - Filter:
  - Filter O-ring:
  - Filter bolt O-ring:
- Drain Plug:
  - O-ring:
  - Washer:

**Note:** the user manual states that you'll need 3.1 US quarts for for the oil change, however I found that I needed about 3.5 US quarts to reach the half way point on the dip stick (you check the level with the dipstick seated but unscrewed)

Additionally, the manual also states that the o-rings and drain plug washer be replaced at each oil change, however enthusiasts routinely skip replacing these during oil changes based on o-ring / washer damage, YMMV. Regardless, it's a good idea to keep multiple o-rings and washers on hand, as the o-rings are especially prone to damage.

## Tools

---

- 10mm: 4 x bolts protective underbelly cover under the drain bolt
- 12mm: Oil filter bolt
- 16mm: Oil drain plug bolt

## Torque

---

- 4 x Protective underbelly bolts: 9 foot pounds
- Oil filter bolt: 13 foot pounds
- Oil drain plug bolt: 18 foot pounds

## Drain The Oil

---

**Note:** The oil will shoot out of the drain hole about 1 to 1 1/2 feet once the drain plug is removed. As the oil is drained, this will reduce enough that you'll likely have to move the pan closer to the drain hole.

**Note:** When removing the oil filter, unscrew the bolt but leave it in the filter, removing the full filter/bolt/washer/spring assembly as a single unit. If you don't do this, you will likely have to search for the filter washer / spring.

The user manual suggests to place the transmission in drive, 4x4 in differential lock and apply the parking break. Basically, all the things that can help prevent the vehicle from rolling while you are working on it!

I chose to jack the Pioneer at the front (place the jack under the brush guard, see owners manual), and use jack stands at the frame jack points near the front wheels. This may not be necessary, I'll have to try without next time, but made it easier the first time.

First step, remove the seat. You'll access the oil fill cap, dipstick (driver side) and filter (passenger side) under the front seat. Unscrew the fill cap. Proceed to the underside of the passenger side.

The oil drain bolt is located inside an access small panel that is located under the Pioneer, center behind the front bench. There are 4 x 10mm bolts. Remove the bolts and slide the cover out towards the driver side. (I took this opportunity to clean debris out of the area).

The oil drain bolt is the larger bolt, 16mm. When fully removed, the oil will shoot out more than a foot and will slowly decrease, meaning you'll need to occasionally move the drain pan.

While the oil is draining, remove the filter. The filter is located under the dust cover on the front passenger side (beside the battery compartment). As mentioned above, I would recommend leaving the bolt in the filter while removing everything as a unit. I didn't do this the first time, removing the bolt first. The result was both spring and washer ended up in the belly pan, taking a good bit of digging to locate.

The oil filter can be removed by using a 12mm wrench / socket. Once the bolt is completely loose, use a flat bladed screw driver to **gently** pry the filter cover away from the crankcase (by gently, I mean it shouldn't require any effort). Once the cover is loose, pull the entire unit out as one and disassemble on your clean workspace (you'll need to reuse the washer, spring, cover and bolt)

## Reinstall the Filter

---

Before installing the new oil filter, you'll want to replace the o-rings located on the filter bolt and filter cover (again, you decide if the o-rings need to be replaced, FYI they are cheap at your local dealer). When replacing o-rings, always make sure to lubricate them with the same oil, i.e. dip your finger in the oil and coat the o-ring!

Assemble the filter as follows: **filter -> washer -> spring -> filter cover -> filter bolt**

Next you'll want to hand thread the filter bolt before using a wrench. Unfortunately, I wasn't able to do this. I couldn't get the bolt to turn with my thumb and forefinger. I ended up having to trust that my very **light** use of the wrench wasn't cross threading the bolt. I believe that this is due to the bolt passing through 2 tight seals on the filter (friction when trying to twist the bolt). You won't have a lot of room for two hands!

Once you have the filter cap snug, tighten to 13 foot pounds.

## Reinstall the Oil Drain Bolt

---

Replace the o-ring and washer on the drain bolt and hand tighten. Once hand tightened, torque to 18 foot pounds.

## Reinstall Access Panel

---

Replace the access panel (the longer flange goes towards the rear). Hand tighten the 4 bolts and then torque to 9 foot pounds.

## Fill the Oil

---

Start by filling the oil with 3 US quarts.