

36-22-71-991-00800-00-B / SHEET 2/2 - Right Wing Loop
'A'- Fault Location Zone and Access Table (Open Circuit)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				5.10	16.73	4037				
054				6.33	20.77	4037				
055				7.56	24.80	4037				
056				8.80	28.87	4037				
057				10.03	32.91	4037				
058				11.26	36.94	4037				
059				12.49	40.98	4037				
060				13.73	45.05	4037				
061				14.96	49.08	4037				
062				16.19	53.12	4037				
063				17.42	57.15	4037				
064				18.66	61.22	4037				
065				19.89	65.26	4037				
066				21.12	69.29	4037				
067				22.35	73.33	4037				
068				23.59	77.40	4037				
069				24.82	81.43	4037				
070				26.05	85.47	4037				
071				27.28	89.50	4037				
072				28.52	93.57	4037				
073				29.75	97.60	4037				
074				0.46	1.51	7514				
075				1.69	5.54	7514				
076				2.93	9.61	7514				
077				4.16	13.65	7514				
078				5.39	17.68	7514				
079				6.63	21.75	7514				
080				7.86	25.79	7514				
081				9.09	29.82	7514				
082				10.32	33.86	7514				
083				11.56	37.93	7514				
084				12.79	41.96	7514				
085				14.02	46.00	7514				
086				0.78	2.56	108				
087				2.02	6.63	108				
088				3.25	10.66	108				
089				4.48	14.70	108				
090				5.71	18.73	108				
091				6.95	22.80	108				
092				8.18	26.84	108				
093				9.41	30.87	108				
094				10.64	34.91	108				
095				0.98	3.22	102				
096				2.21	7.25	102				
097				3.44	11.29	102				
098				1.10	3.61	102				
099				2.34	7.68	102				
100				3.57	11.71	102				

NOTE:

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN). ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_GFAA_02_00

Figure 36-22-71-991-00800-B- / SHEET 2/2 - Right Wing Loop
'A'- Fault Location Zone and Access Table (Open Circuit)

** ON A/C ALL