

36-22-71-991-00700-00-B / SHEET 2/2 - Left Inner Wing Loop  
'A'- Fault Location Zone and Access Table (Open Circuit)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				2.87	9.42	736				
054				3.91	12.83	736				
055				4.95	16.24	736				
056				0.52	1.71	4018				
057				1.56	5.12	4018				
058				2.60	8.53	4018				
059				3.64	11.94	4018				
060				4.68	15.35	4018				
061				5.72	18.77	4018				
062				6.76	22.18	4018				
063				7.80	25.59	4018				
064				8.84	29.00	4018				
065				9.88	32.41	4018				
066				10.92	35.83	4018				
067				11.96	39.24	4018				
068				13.00	42.65	4018				
069				14.04	46.06	4018				
070				15.08	49.48	4018				
071				16.12	52.89	4018				
072				0.63	2.07	7504				
073				1.67	5.48	7504				
074				2.71	8.89	7504				
075				3.75	12.30	7504				
076				4.79	15.72	7504				
077				5.83	19.13	7504				
078				6.87	22.54	7504				
079				7.91	25.95	7504				
080				8.95	29.36	7504				
081				9.99	32.78	7504				
082				11.03	36.19	7504				
083				12.07	39.60	7504				
084				13.11	43.01	7504				
085				14.15	46.42	7504				
086				15.19	49.84	7504				
087				0.99	3.25	10				
088				2.03	6.66	10				
089				3.07	10.07	10				
090				4.11	13.48	10				
091				5.15	16.90	10				
092				6.19	20.31	10				
093				7.23	23.72	10				
094				8.27	27.13	10				
095				9.31	30.54	10				
096				10.35	33.96	10				
097				0.45	1.48	4				
098				1.49	4.89	4				
099				2.53	8.30	4				
100				3.57	11.71	4				

**NOTE:**

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN). ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L\_TS\_362271\_2\_GDAA\_02\_00

Figure 36-22-71-991-00700-B- / SHEET 2/2 - Left Inner Wing  
Loop 'A'- Fault Location Zone and Access Table (Open Circuit)

\*\* ON A/C ALL