

36-22-71-991-00900-00-B / SHEET 2/2 - Right Inner Wing
Loop 'A'- Fault Location Zone and Access Table (Open Circuit)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				2.31	7.58	745				
054				3.33	10.93	745				
055				4.35	14.27	745				
056				0.65	2.13	4032				
057				1.67	5.48	4032				
058				2.68	8.79	4032				
059				3.70	12.14	4032				
060				4.72	15.49	4032				
061				5.73	18.80	4032				
062				6.75	22.15	4032				
063				7.77	25.49	4032				
064				8.78	28.81	4032				
065				9.80	32.15	4032				
066				10.82	35.50	4032				
067				11.83	38.81	4032				
068				12.85	42.16	4032				
069				13.86	45.47	4032				
070				14.88	48.82	4032				
071				15.90	52.17	4032				
072				0.48	1.57	7512				
073				1.50	4.92	7512				
074				2.52	8.27	7512				
075				3.53	11.58	7512				
076				4.55	14.93	7512				
077				5.56	18.24	7512				
078				6.58	21.59	7512				
079				7.60	24.93	7512				
080				8.61	28.25	7512				
081				9.63	31.59	7512				
082				10.65	34.94	7512				
083				11.66	38.25	7512				
084				12.68	41.60	7512				
085				13.70	44.95	7512				
086				0.24	0.79	106				
087				1.26	4.13	106				
088				2.27	7.45	106				
089				3.29	10.79	106				
090				4.31	14.14	106				
091				5.32	17.45	106				
092				6.34	20.80	106				
093				7.36	24.15	106				
094				8.37	27.46	106				
095				9.39	30.81	106				
096				10.40	34.12	106				
097				0.52	1.71	100				
098				1.54	5.05	100				
099				2.55	8.37	100				
100				3.57	11.71	100				

NOTE:

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN). ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_GHAA_02_00

Figure 36-22-71-991-00900-B- / SHEET 2/2 - Right Inner Wing
Loop 'A'- Fault Location Zone and Access Table (Open Circuit)

** ON A/C ALL