

36-22-71-991-00400-00-A / SHEET 2/2 - Engine 4 Pylon
Loop A Location Zone and Access Panel "Open Circuit"

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				5.29	17.36	109HF4				483AR
054				0.82	2.69	1004				
055				2.16	7.09	1004				
056				3.51	11.52	1004				
057				0.16	0.52	4071				
058				1.51	4.95	4071				
059				2.85	9.35	4071				
060				4.19	13.75	4071				
061				5.54	18.18	4071				
062				6.88	22.57	4071				
063				8.22	26.97	4071				
064				9.57	31.40	4071				
065				10.91	35.79	4071				
066				12.25	40.19	4071				
067				13.60	44.62	4071				
068				14.94	49.02	4071				
069				16.29	53.44	4071				
070				17.63	57.84	4071				
071				18.97	62.24	4071				
072				20.32	66.67	4071				
073				21.66	71.06	4071				
074				23.00	75.46	4071				
075				24.35	79.89	4071				
076				25.69	84.28	4071				
077				27.04	88.71	4071				
078				28.38	93.11	4071				
079				29.72	97.51	4071				
080				0.69	2.26	7636				
081				2.03	6.66	7636				
082				3.37	11.06	7636				
083				4.72	15.49	7636				
084				6.06	19.88	7636				
085				7.40	24.28	7636				
086				8.75	28.71	7636				
087				10.09	33.10	7636				
088				11.44	37.53	7636				
089				12.78	41.93	7636				
090				1.21	3.97	992				
091				2.56	8.40	992				
092				3.90	12.80	992				
093				5.24	17.19	992				
094				6.59	21.62	992				
095				7.93	26.02	992				
096				9.28	30.45	992				
097				10.62	34.84	992				
098				0.93	3.05	980				
099				2.28	7.48	980				
100				3.62	11.88	980				

NOTE:

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN). ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_BZAA_02_00

Figure 36-22-71-991-00400-A- / SHEET 2/2 - Engine 4 Pylon
Loop A Location Zone and Access Panel "Open Circuit"

** ON A/C ALL