

36-22-71-991-00300-00-A / SHEET 2/2 - Engine 3 Pylon  
Loop A Location Zone and Access Panel "Open Circuit"

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				4.16	13.65	109HF3				473AR
054				5.60	18.37	109HF3				473AR
055				0.77	2.53	1006				
056				1.83	6.00	1006				
057				2.90	9.51	1006				
058				3.96	12.99	1006				
059				0.34	1.12	4077				
060				1.40	4.59	4077				
061				2.47	8.10	4077				
062				3.53	11.58	4077				
063				4.60	15.09	4077				
064				5.66	18.57	4077				
065				6.73	22.08	4077				
066				7.79	25.56	4077				
067				8.86	29.07	4077				
068				9.92	32.55	4077				
069				10.98	36.02	4077				
070				12.05	39.53	4077				
071				13.11	43.01	4077				
072				14.18	46.52	4077				
073				15.24	50.00	4077				
074				16.31	53.51	4077				
075				0.94	3.08	7634				
076				2.01	6.59	7634				
077				3.07	10.07	7634				
078				4.14	13.58	7634				
079				5.20	17.06	7634				
080				6.27	20.57	7634				
081				7.33	24.05	7634				
082				8.40	27.56	7634				
083				9.46	31.04	7634				
084				10.52	34.51	7634				
085				11.59	38.02	7634				
086				12.65	41.50	7634				
087				0.81	2.66	994				
088				1.87	6.14	994				
089				2.94	9.65	994				
090				4.00	13.12	994				
091				5.07	16.63	994				
092				6.13	20.11	994				
093				7.20	23.62	994				
094				8.26	27.10	994				
095				9.33	30.61	994				
096				10.39	34.09	994				
097				0.43	1.41	982				
098				1.49	4.89	982				
099				2.56	8.40	982				
100				3.62	11.88	982				

**NOTE:**

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN). ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L\_TS\_362271\_2\_BXAA\_02\_00

Figure 36-22-71-991-00300-A- / SHEET 2/2 - Engine 3 Pylon  
Loop A Location Zone and Access Panel "Open Circuit"

\*\* ON A/C ALL