

36-22-11-991-03400-00-B / SHEET 2/2 - Right Wing, Loop 'B' -
Fault Location Zone and Access Table (Short Circuit/Overheat)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053	2.92	9.58	307HF	0.64	2.10	308HF	1.46	4.79	308HF	622CB/622EB
054	0.18	0.59	308HF	1.01	3.31	308HF	1.83	6.00	308HF	622CB/622EB
055	0.55	1.80	308HF	1.37	4.49	308HF	0.08	0.26	309HF	622CB/622EB
056	0.91	2.99	308HF	1.73	5.68	308HF	0.44	1.44	309HF	622CB/622EB
057	1.27	4.17	308HF	2.10	6.89	308HF	0.81	2.66	309HF	622CB/622EB
058	1.64	5.38	308HF	0.35	1.15	309HF	1.17	3.84	309HF	622GB/622HB
059	2.00	6.56	308HF	0.71	2.33	309HF	1.53	5.02	309HF	622GB/622HB
060	0.25	0.82	309HF	1.08	3.54	309HF	1.90	6.23	309HF	622GB/622HB
061	0.62	2.03	309HF	1.44	4.72	309HF	2.26	7.41	309HF	622GB/622HB
062	0.98	3.22	309HF	1.80	5.91	309HF	2.62	8.60	309HF	622GB/622HB
063	1.34	4.40	309HF	2.17	7.12	309HF	0.27	0.89	310HF	622GB/622HB
064	1.71	5.61	309HF	2.53	8.30	309HF	0.63	2.07	310HF	622GB/622HB
065	2.07	6.79	309HF	0.17	0.56	310HF	0.99	3.25	310HF	622JB/622LB/622NB
066	2.43	7.97	309HF	0.54	1.77	310HF	1.36	4.46	310HF	622JB/622LB/622NB
067	0.08	0.26	310HF	0.90	2.95	310HF	1.72	5.64	310HF	622JB/622LB/622NB
068	0.44	1.44	310HF	1.26	4.13	310HF	2.08	6.82	310HF	622JB/622LB/622NB
069	0.80	2.62	310HF	1.63	5.35	310HF	0.28	0.92	311HF	622JB/622LB/622NB
070	1.17	3.84	310HF	1.99	6.53	310HF	0.64	2.10	311HF	622JB/622LB/622NB
071	1.53	5.02	310HF	0.18	0.59	311HF	1.00	3.28	311HF	622PB/622QB/622RB
072	1.89	6.20	310HF	0.55	1.80	311HF	1.37	4.49	311HF	622PB/622QB/622RB
073	0.09	0.30	311HF	0.91	2.99	311HF	1.73	5.68	311HF	622PB/622QB/622RB
074	0.45	1.48	311HF	1.27	4.17	311HF	2.09	6.86	311HF	622PB/622QB/622RB
075	0.81	2.66	311HF	1.64	5.38	311HF	2.46	8.07	311HF	622PB/622QB/622RB
076	1.18	3.87	311HF	2.00	6.56	311HF	0.34	1.12	312HF	622PB/622QB/622RB
077	1.54	5.05	311HF	2.36	7.74	311HF	0.70	2.30	312HF	622PB/622QB/622RB
078	1.90	6.23	311HF	0.25	0.82	312HF	1.07	3.51	312HF	622TB/622VB
079	2.27	7.45	311HF	0.61	2.00	312HF	1.43	4.69	312HF	622TB/622VB
080	0.15	0.49	312HF	0.97	3.18	312HF	1.79	5.87	312HF	622TB/622VB
081	0.51	1.67	312HF	1.34	4.40	312HF	2.16	7.09	312HF	622TB/622VB
082	0.88	2.89	312HF	1.70	5.58	312HF	2.52	8.27	312HF	622TB/622VB
083	1.24	4.07	312HF	2.06	6.76	312HF	0.31	1.02	313HF	622TB/622VB
084	1.60	5.25	312HF	2.43	7.97	312HF	0.68	2.23	313HF	622TB/622VB
085	1.97	6.46	312HF	0.22	0.72	313HF	1.04	3.41	313HF	623AT
086	2.33	7.64	312HF	0.58	1.90	313HF	1.40	4.59	313HF	623AT
087	0.12	0.39	313HF	0.95	3.12	313HF	1.77	5.81	313HF	623AT
088	0.49	1.61	313HF	1.31	4.30	313HF	0.33	1.08	314HF	623AT
089	0.85	2.79	313HF	1.67	5.48	313HF	0.69	2.26	314HF	623AT
090	1.21	3.97	313HF	0.24	0.79	314HF	1.06	3.48	314HF	483AL/483BL/483CL/483DL
091	1.58	5.18	313HF	0.60	1.97	314HF	1.42	4.66	314HF	483AL/483BL/483CL/483DL
092	0.14	0.46	314HF	0.96	3.15	314HF	0.28	0.92	349HF	483AL/483BL/483CL/483DL
093	0.50	1.64	314HF	1.33	4.36	314HF	0.65	2.13	349HF	483AL/483BL/483CL/483DL
094				2.48	8.14	349HF				
095				8.69	28.51	4065				
096				19.56	64.17	4065				
097				30.43	99.84	4065				
098				10.77	35.33	7556				
099				7.17	23.52	187				
100				3.57	11.71	181				

NOTE: THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).
ALL THE WIRE IDENTIFIERS ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362211_2_EPAA_02_00

Figure 36-22-11-991-03400-B / SHEET 2/2 - Right Wing, Loop 'B'
- Fault Location Zone and Access Table (Short Circuit/Overheat)

** ON A/C ALL