

36-22-71-991-02700-00-B / SHEET 2/2 - Right Wing Loop
'B'- Fault Location Zone and Access Table (Open Circuit)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				1.49	4.89	4065				
054				2.74	8.99	4065				
055				3.99	13.09	4065				
056				5.24	17.19	4065				
057				6.48	21.26	4065				
058				7.73	25.36	4065				
059				8.98	29.46	4065				
060				10.23	33.56	4065				
061				11.48	37.66	4065				
062				12.73	41.77	4065				
063				13.98	45.87	4065				
064				15.22	49.93	4065				
065				16.47	54.04	4065				
066				17.72	58.14	4065				
067				18.97	62.24	4065				
068				20.22	66.34	4065				
069				21.47	70.44	4065				
070				22.71	74.51	4065				
071				23.96	78.61	4065				
072				25.21	82.71	4065				
073				26.46	86.81	4065				
074				27.71	90.91	4065				
075				28.96	95.01	4065				
076				30.21	99.11	4065				
077				0.68	2.23	7556				
078				1.93	6.33	7556				
079				3.18	10.43	7556				
080				4.43	14.53	7556				
081				5.68	18.64	7556				
082				6.93	22.74	7556				
083				8.18	26.84	7556				
084				9.42	30.91	7556				
085				10.67	35.01	7556				
086				11.92	39.11	7556				
087				13.17	43.21	7556				
088				14.42	47.31	7556				
089				0.48	1.57	187				
090				1.72	5.64	187				
091				2.97	9.74	187				
092				4.22	13.85	187				
093				5.47	17.95	187				
094				6.72	22.05	187				
095				7.97	26.15	187				
096				9.22	30.25	187				
097				10.46	34.32	187				
098				0.89	2.92	181				
099				2.14	7.02	181				
100				3.39	11.12	181				

NOTE: THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).
ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING.
THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_GGAA_02_00

Figure 36-22-71-991-02700-B- / SHEET 2/2 - Right Wing Loop
'B'- Fault Location Zone and Access Table (Open Circuit)

** ON A/C ALL