

36-22-71-991-02400-00-A / SHEET 2/2 - Engine 4 Pylon Loop  
'B'- Fault Location Zone and Access Table (Open Circuit)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				5.68	18.64	119HF4				483AR
054				1.20	3.94	68				
055				2.64	8.66	68				
056				4.08	13.39	68				
057				5.52	18.11	68				
058				1.06	3.48	4137				
059				2.49	8.17	4137				
060				3.93	12.89	4137				
061				5.37	17.62	4137				
062				6.81	22.34	4137				
063				8.25	27.07	4137				
064				9.69	31.79	4137				
065				11.13	36.52	4137				
066				12.56	41.21	4137				
067				14.00	45.93	4137				
068				15.44	50.66	4137				
069				16.88	55.38	4137				
070				18.32	60.10	4137				
071				19.76	64.83	4137				
072				21.20	69.55	4137				
073				22.64	74.28	4137				
074				24.07	78.97	4137				
075				25.51	83.69	4137				
076				26.95	88.42	4137				
077				28.39	93.14	4137				
078				29.83	97.87	4137				
079				0.50	1.64	7590				
080				1.94	6.36	7590				
081				3.37	11.06	7590				
082				4.81	15.78	7590				
083				6.25	20.51	7590				
084				7.69	25.23	7590				
085				9.13	29.95	7590				
086				10.57	34.68	7590				
087				12.01	39.40	7590				
088				13.45	44.13	7590				
089				14.88	48.82	7590				
090				16.32	53.54	7590				
091				1.43	4.69	28				
092				2.87	9.42	28				
093				4.31	14.14	28				
094				5.75	18.86	28				
095				7.19	23.59	28				
096				8.63	28.31	28				
097				10.06	33.01	28				
098				0.51	1.67	20				
099				1.95	6.40	20				
100				3.39	11.12	20				

**NOTE:** THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).  
ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING.  
THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L\_TS\_362271\_2\_CAAA\_02\_00

Figure 36-22-71-991-02400-A- / SHEET 2/2 - Engine 4 Pylon  
Loop 'B'- Fault Location Zone and Access Table (Open Circuit)

\*\* ON A/C ALL