

36-22-71-991-02500-00-B / SHEET 2/2 - Left Wing Loop
'B'- Fault Location Zone and Access Table (Open Circuit)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				0.97	3.18	4051				
054				2.17	7.12	4051				
055				3.37	11.06	4051				
056				4.57	14.99	4051				
057				5.77	18.93	4051				
058				6.96	22.83	4051				
059				8.16	26.77	4051				
060				9.36	30.71	4051				
061				10.56	34.65	4051				
062				11.76	38.58	4051				
063				12.95	42.49	4051				
064				14.15	46.42	4051				
065				15.35	50.36	4051				
066				16.55	54.30	4051				
067				17.75	58.23	4051				
068				18.94	62.14	4051				
069				20.14	66.08	4051				
070				21.34	70.01	4051				
071				22.54	73.95	4051				
072				23.74	77.89	4051				
073				24.93	81.79	4051				
074				26.13	85.73	4051				
075				27.33	89.67	4051				
076				28.53	93.60	4051				
077				29.73	97.54	4051				
078				0.48	1.57	7548				
079				1.68	5.51	7548				
080				2.88	9.45	7548				
081				4.08	13.39	7548				
082				5.28	17.32	7548				
083				6.47	21.23	7548				
084				7.67	25.16	7548				
085				8.87	29.10	7548				
086				10.07	33.04	7548				
087				11.27	36.98	7548				
088				12.46	40.88	7548				
089				1.01	3.31	147				
090				2.21	7.25	147				
091				3.41	11.19	147				
092				4.61	15.12	147				
093				5.80	19.03	147				
094				7.00	22.97	147				
095				8.20	26.90	147				
096				9.40	30.84	147				
097				10.60	34.78	147				
098				0.99	3.25	141				
099				2.19	7.19	141				
100				3.39	11.12	141				

NOTE: THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).
ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING.
THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_GCAA_02_00

Figure 36-22-71-991-02500-B- / SHEET 2/2 - Left Wing Loop
'B'- Fault Location Zone and Access Table (Open Circuit)

** ON A/C ALL