

36-22-71-991-02200-00-A / SHEET 2/2 - Engine 2 Pylon Loop
'B'- Fault Location Zone and Access Table (Open Circuit)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053				5.30	17.39	119HF2				463BL
054				0.83	2.72	938				
055				2.17	7.12	938				
056				3.52	11.55	938				
057				4.86	15.94	938				
058				0.75	2.46	4083				
059				2.09	6.86	4083				
060				3.44	11.29	4083				
061				4.79	15.72	4083				
062				6.13	20.11	4083				
063				7.48	24.54	4083				
064				8.82	28.94	4083				
065				10.17	33.37	4083				
066				11.51	37.76	4083				
067				12.86	42.19	4083				
068				14.20	46.59	4083				
069				15.55	51.02	4083				
070				16.90	55.45	4083				
071				18.24	59.84	4083				
072				19.59	64.27	4083				
073				20.93	68.67	4083				
074				22.28	73.10	4083				
075				23.62	77.49	4083				
076				24.97	81.92	4083				
077				26.31	86.32	4083				
078				27.66	90.75	4083				
079				29.00	95.14	4083				
080				30.35	99.57	4083				
081				1.26	4.13	7630				
082				2.60	8.53	7630				
083				3.95	12.96	7630				
084				5.29	17.36	7630				
085				6.64	21.78	7630				
086				7.98	26.18	7630				
087				9.33	30.61	7630				
088				10.67	35.01	7630				
089				12.02	39.44	7630				
090				0.73	2.40	934				
091				2.07	6.79	934				
092				3.42	11.22	934				
093				4.76	15.62	934				
094				6.11	20.05	934				
095				7.45	24.44	934				
096				8.80	28.87	934				
097				10.14	33.27	934				
098				0.70	2.30	930				
099				2.04	6.69	930				
100				3.39	11.12	930				

NOTE:

THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN). ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362271_2_BWAA_02_00

Figure 36-22-71-991-02200-A- / SHEET 2/2 - Engine 2 Pylon
Loop 'B'- Fault Location Zone and Access Table (Open Circuit)

** ON A/C ALL