

DUALSHOCK®4 Wireless Controller

Instruction Manual

Thank you for purchasing the DUALSHOCK®4 Wireless Controller. This high-quality controller is designed to enhance your gaming experience and provide you with hours of comfortable gameplay. This user guide contains all the information you need to get started using your new controller, including instructions for use and maintenance, technical specifications, and answers to frequently asked questions.

Features:

- Wireless connectivity to your PlayStation 4 console
- Integrated touchpad and motion sensors for enhanced gameplay
- Precise and responsive analog sticks and trigger buttons
- Built-in speaker and stereo headset jack for immersive audio
- Rechargeable battery with up to 6 hours of gameplay on a single charge
- Compatible with most PlayStation 4 games

Technical Specifications:

- Input power rating: DC 5 V, 800 mA
- Battery type: Lithium-ion rechargeable battery
- Battery capacity: 1000 mAh
- Wireless protocol: Bluetooth® 2.1+EDR
- Operating distance: Approximately 10 meters
- Dimensions: Approximately 161mm x 57mm x 100mm
- Weight: Approximately 210g

Instructions for Use:

1. Charge your controller using the included USB cable. The controller will automatically turn off when fully charged.
2. Press the PS button on your controller to connect it to your PlayStation 4 console.
3. Use the touchpad and buttons to navigate the PlayStation 4 user interface and launch games.
4. Enjoy immersive gameplay with the responsive analog sticks and trigger buttons.
5. Connect a headset to the controller using the stereo headset jack for enhanced audio.
6. When finished playing, turn off the controller to conserve battery life.

Maintenance:

- Clean your controller regularly with a soft, dry cloth.
- Do not expose your controller to extreme temperatures or moisture.
- Do not drop or expose your controller to impact.
- Store your controller in a cool, dry place when not in use



DALL-E generated image



MidJourney generated image



Actual Image of the product

FAQs:

Q: How do I connect my controller to my PlayStation 4 console?

A: Press the PS button on your controller to connect it to your console.

Q: How long does the battery last on a single charge?

A: The battery can provide up to 6 hours of gameplay on a single charge.

Q: Can I use this controller with other devices?

A: This controller is designed specifically for use with the PlayStation 4 console.

Q: How do I turn off my controller?

A: Press and hold the PS button on your controller until the light bar turns off.

Tips for Optimal Use:

- Customize your controller settings in the PlayStation 4 system settings menu to suit your preferences.
- Connect a headset to the controller for a more immersive gaming experience.
- Experiment with the touchpad and motion sensors to discover new ways to interact with your games.

TROUBLESHOOTING:

Problem: The controller won't turn on.

Solution: Make sure the battery is charged. Connect the controller to a power source using the included USB cable and wait for the battery to charge.

Problem: The controller is not responding.

Solution: Try resetting the controller by using a small pin or paper clip to press the reset button on the back of the controller. Also, make sure the controller is within range of the console.

Problem: The controller is not connecting to the console.

Solution: Try connecting the controller to the console using the included USB cable. Also, make sure the console and controller are both turned on and within range of each other.

Problem: The controller buttons are not responding.

Solution: Make sure the controller is synced to the console and that the game being played is compatible with the controller. Reset the controller if necessary.

Problem: The controller is not charging.

Solution: Make sure the USB cable is properly connected to both the controller and power source. If the problem persists, try using a different USB cable.

Thank you for choosing the DUALSHOCK®4 Wireless Controller by Sony Interactive Entertainment Inc. We hope this troubleshooting guide was helpful.