

Congratulations on your purchase of the Envivo ENV-1359 Mobile/Tablet Speaker. This speaker is designed to provide you with high-quality sound for your mobile devices and tablets, and it is also waterproof, making it ideal for use in a variety of environments.

## Key Features:

- High-quality sound: The Envivo ENV-1359 Mobile/Tablet Speaker is designed to provide you with clear and powerful sound for your mobile devices and tablets.
- Waterproof design: This speaker is waterproof, making it ideal for use in the shower, at the beach, or by the pool.
- Easy to use: The speaker is easy to use - simply connect it to your mobile device or tablet using Bluetooth, and you're ready to go.

## Specifications:

- Bluetooth version: 3.0
- Transmission distance: 10 meters
- Battery capacity: 400mAh
- Play time: up to 4 hours
- Charging time: 2-3 hours
- Waterproof rating: IPX7

## Instructions for Use:

1. Charge the speaker: Before using the Envivo ENV-1359 Mobile/Tablet Speaker for the first time, it is important to fully charge the battery. Use the included USB cable to connect the speaker to a power source, such as a computer or wall adapter. The charging time is approximately 2-3 hours.
2. Turn on the speaker: Once the battery is fully charged, press and hold the power button on the speaker for 3 seconds to turn it on. The LED light on the speaker will flash blue to indicate that it is ready to pair with your mobile device or tablet.
3. Connect the speaker to your mobile device or tablet: On your mobile device or tablet, go to the Bluetooth settings and turn on Bluetooth. Look for the Envivo ENV-1359 Mobile/Tablet Speaker in the list of available devices and select it to connect.
4. Enjoy your music: Once the speaker is connected to your mobile device or tablet, you can start playing your music. Adjust the volume using the controls on your mobile device or tablet, or use the volume buttons on the speaker.

## Maintenance:

To keep your Envivo ENV-1359 Mobile/Tablet Speaker in good condition, it is important to follow these maintenance tips:

1. Keep the speaker clean: Use a soft, dry cloth to clean the speaker and remove any dirt or debris.
2. Avoid extreme temperatures: Do not expose the speaker to extreme temperatures, such as direct sunlight or freezing temperatures.
3. Store the speaker properly: When not in use, store the speaker in a dry, cool place.



DALL-E generated image



MidJourney generated image



Actual Image of the product

## FAQs:

Q: Is the Envivo ENV-1359 Mobile/Tablet Speaker compatible with all mobile devices and tablets?

A: Yes, the speaker is compatible with any mobile device or tablet that has Bluetooth connectivity.

Q: How long does the battery last?

A: The battery can last up to 4 hours of continuous play time.

Q: Can I use the speaker in the shower?

A: Yes, the speaker is waterproof and can be used in the shower.

## Creative Uses:

1. Use the speaker for outdoor activities: The waterproof design makes the Envivo ENV-1359 Mobile/Tablet Speaker ideal for outdoor activities such as camping, hiking, or picnics.
2. Use the speaker in the car: The speaker can be easily connected to your mobile device or tablet, making it a great option for use in the car.
3. Use the speaker for conference calls: The high-quality sound of the Envivo ENV-1359 Mobile/Tablet Speaker makes it ideal for use in conference calls or video chats.

In conclusion, the Envivo ENV-1359 Mobile/Tablet Speaker is a versatile and high-quality speaker that is perfect for use with your mobile devices and tablets. With its waterproof design and easy-to-use features, it is sure to provide you with hours of enjoyment.

## TROUBLESHOOTING:

1. No sound coming out of the speaker
  - Check if the speaker is turned on and properly connected to the device
  - Increase the volume on both the speaker and the device
  - Check if the device's audio output is not muted or set to low volume
2. Poor sound quality
  - Adjust the equalizer settings of the audio device
  - Check if the speaker is too far away from the audio device or if there are any obstacles blocking the signal
  - Try resetting both the speaker and the audio device
3. Compatibility issues
  - Verify if the speaker is compatible with the audio device's operating system or version
  - Try connecting the speaker to a different audio device to verify compatibility
4. Battery concerns
  - Check if the speaker's battery is fully charged
  - Try replacing the batteries with new ones

Disable any power-saving mode on the audio device Thank you for choosing the Envivo ENV-1359 Mobile/Tablet Speaker waterproof. We hope that this troubleshooting guide has helped you solve any issues that you may have encountered.