

Thank you for purchasing the Roomba® j7+ Robot Vacuum Cleaner with Wi-Fi® Connection. This user guide will provide you with all the necessary information to use and maintain your new product. Please read this guide carefully before using the product.

## Features:

- Wi-Fi® Connection: Allows you to control the Roomba® j7+ Robot Vacuum Cleaner through the iRobot Home App
- PrecisionVision Navigation: Efficient cleaning with smart mapping and obstacle avoidance technology
- Edge-Sweeping Brush: Designed to clean edges and corners
- Anti-Allergen System: Captures and traps 99% of pollen, dust mites, and pet allergens
- Dirt Detect Technology: Detects areas with higher dirt concentration and cleans them more thoroughly
- Dual Multi-Surface Rubber Brushes: Adjust to different floor surfaces and pick up more dirt and debris

## Technical Specifications:

- Product Dimensions: 13.4 x 3.6 x 13.4 inches
- Product Weight: 7.9 lbs
- Battery Life: Up to 75 minutes
- Recharge Time: 3 hours
- Dustbin Capacity: 330 ml
- Wi-Fi® Connectivity: 2.4 GHz only
- Compatible with Amazon Alexa and Google Assistant

## Instructions for Use:

1. Charge the Roomba® j7+ Robot Vacuum Cleaner by placing it on the charging dock. The battery indicator will light up when charging and turn off when fully charged.
2. Download the iRobot Home App and connect the Roomba® j7+ Robot Vacuum Cleaner to your Wi-Fi® network.
3. Follow the instructions on the app to schedule cleaning times, customize cleaning preferences, and view cleaning history.
4. The Roomba® j7+ Robot Vacuum Cleaner is designed to work on different floor surfaces such as hardwood, tile, and carpet. It will adjust to the surface automatically.
5. Empty the dirt bin after each use and clean the filter regularly.
6. Use the Edge-Sweeping Brush to clean edges and corners.
7. The Dirt Detect Technology will automatically detect areas with higher dirt concentration and clean them more thoroughly.
8. When the battery is low, the Roomba® j7+ Robot Vacuum Cleaner will return to the charging dock.

## Maintenance:

- Empty the dirt bin after each use and clean the filter regularly.
- Clean the Roomba® j7+ Robot Vacuum Cleaner's sensors and charging contacts with a soft, damp cloth.
- Replace the filter every 2-3 months or as needed.
- Replace the Dual Multi-Surface Rubber Brushes every 6-12 months or as needed.
- Store the Roomba® j7+ Robot Vacuum Cleaner on the charging dock when not in use.



*DALL-E generated image*



*MidJourney generated image*



*Actual Image of the product*

## Tips for Optimal Use:

- Schedule cleaning times to coincide with times when you are not at home to avoid interruption.
- Use the iRobot Home App to customize cleaning preferences such as cleaning areas, power settings, and cleaning frequency.
- Use the Roomba® j7+ Robot Vacuum Cleaner's Dirt Detect Technology to clean high-traffic areas more frequently.
- Use the Edge-Sweeping Brush to clean edges and corners.
- Use Amazon Alexa or Google Assistant to control the Roomba® j7+ Robot Vacuum Cleaner with voice commands.

## FAQ:

Q: How often do I need to replace the filter?

A: The filter should be replaced every 2-3 months or as needed.

Q: How often do I need to replace the Dual Multi-Surface Rubber Brushes?

A: The brushes should be replaced every 6-12 months or as needed.

Q: Can I use the Roomba® j7+ Robot Vacuum Cleaner on carpets?

A: Yes, the Roomba® j7+ Robot Vacuum Cleaner is designed to work on different floor surfaces including carpets.

Q: Can I control the Roomba® j7+ Robot Vacuum Cleaner with my voice?

A: Yes, the Roomba® j7+ Robot Vacuum Cleaner is compatible with Amazon Alexa and Google Assistant.

## Creative Uses:

- Use the Roomba® j7+ Robot Vacuum Cleaner to clean hard-to-reach areas such as under furniture or in tight spaces.
- Use the iRobot Home App to schedule cleaning times when you are away on vacation to ensure your home is clean upon your return.
- Use the Roomba® j7+ Robot Vacuum Cleaner to clean up spilled food or crumbs on the kitchen floor.

Thank you for choosing the Roomba® j7+ Robot Vacuum Cleaner with Wi-Fi® Connection. We hope this user guide has been helpful in using and maintaining your product. If you have any further questions, please consult the iRobot Home App or contact iRobot Customer Support.

## TROUBLESHOOTING:

### Problem 1: Robot vacuum cleaner is not picking up dirt

#### Solution:

1. Check if the dust bin is full, and empty if necessary.
2. Make sure the brushes and filters are not clogged, clean them if necessary.
3. Ensure that the robot is moving properly and not getting stuck.

### Problem 2: Wi-Fi® connection is not working

#### Solution:

1. Check if the robot is connected to the Wi-Fi® network.
2. Restart the router and try connecting again.
3. Reset the robot and try connecting again.

### Problem 3: Robot vacuum cleaner is making loud noises

#### Solution:

1. Check if there is any obstruction in the vacuum's brushes or wheels, remove it if necessary.
2. Inspect the vacuum's filter and clean it if necessary.
3. Check if the brush roll is damaged or faulty and replace it if necessary.

Thank you for choosing the Roomba® j7+ robot vacuum cleaner with Wi-Fi® connection! We hope this troubleshooting guide has been helpful to you. If you have any further questions or concerns, please contact our customer support for assistance.