

User Guide for 10000mAh XiaoMi Power Bank 2S

Congratulations on your purchase of the 10000mAh XiaoMi Power Bank 2S! This user guide will provide you with all the information you need to use and maintain your new power bank.

Features:

- ♦ High capacity 10000mAh battery for extended use
- ♦ Dual USB output ports for charging multiple devices simultaneously.
- ♦ Built-in LED indicator lights to display remaining battery life
- ♦ Slim and lightweight design for easy portability.

Specifications:

- ♦ Model: PLM09ZM
- ♦ Battery type: Li-polymer battery
- ♦ Input voltage: DC 5.0V
- ♦ Output voltage: DC 5.1V
- ♦ Input current: 2.0A
- ♦ Output current: 2.0A (max)
- ♦ Charging time: Approx. 4.2 hours (with 18W charger and standard cable)
- ♦ Dimensions: 147 x 71.2 x 14.2 mm
- ♦ Weight: 240g

Instructions for Use:

1. Charge the power bank using the included USB cable and a 5V/2A charger. The LED indicator lights will blink to indicate charging and turn off when fully charged.
2. Connect your device(s) to the power bank using your own USB cable(s).
3. Press the power button to begin charging. The LED indicator lights will display the remaining battery life.
4. Disconnect your device(s) when charging is complete.

Maintenance:

- ♦ Keep the power bank away from heat, water, and other liquids.
- ♦ Do not disassemble or modify the power bank.
- ♦ Use only the included USB cable or other certified cables to charge the power bank and your devices.
- ♦ Store the power bank in a cool, dry place when not in use.

FAQs:

- Q: How many times can the power bank charge my device?
A: This will depend on the capacity of your device's battery. The 10000mAh XiaoMi Power Bank 2S can fully charge most smartphones 2-3 times.
- Q: Can the power bank charge multiple devices at once?
A: Yes, the dual USB output ports allow you to charge up to two devices simultaneously.
- Q: How long does it take to fully charge the power bank?
A: It takes approximately 4.2 hours to fully charge the power bank with an 18W charger and standard cable.



DALL-E generated image



MidJourney generated image



Actual Image of the product

Tips:

- Use a high-speed charger to reduce charging time.
- Keep the power bank fully charged for emergencies or extended use.
- Use the power bank to charge other portable devices, such as Bluetooth headphones or speakers.

TROUBLESHOOTING:

Problem: The power bank is not charging devices.

Solution: Check if the power bank is charged itself. Check if the cable and device being charged are connected properly. Try using a different cable or device.

Problem: The power bank is not holding charge.

Solution: Charge the power bank fully and avoid leaving it unused for long periods of time. If the problem persists, contact customer service.

Problem: The power bank is overheating.

Solution: Stop using the power bank immediately and let it cool down. Avoid using the power bank in direct sunlight or hot temperatures. If the problem persists, contact customer service.

Problem: The power bank is not turning on.

Solution: Check if the power bank is charged. Try charging the power bank with a different cable or charging port. If the problem persists, contact customer service.

Problem: The power bank is damaged or not working properly.

Solution: Do not attempt to repair the power bank yourself. Contact customer service for assistance.

Thank you for choosing the 10000mAh XiaoMi Power Bank 2S. We hope this troubleshooting guide was helpful in resolving any issues you may have encountered. For further assistance, please contact customer service.