

Article Number: 000124996

 [Print](#)

Dell Latitude 3480 and 3490 Keyboard Guide

Summary: Refer to the guide to the keyboard shortcut functions on the Dell Latitude 3480 and 3490.

Article Content

Symptoms

Keyboard Shortcut Key Functions


The below table is a list of combination short-cut key functions available on the Latitude 3480 and 3490 Notebook




i NOTE: By Toggling **Fn + Esc**, "Function Lock" to **On**, you will not need to use the **Fn** key to activate the various Function key actions

Esc	Fn + Esc Activates Function Key Lock (Function Defined in BIOS Setup)
F1	Fn + F1 Mute Audio
F2	Fn + F2 Decrease Volume
F3	Fn + F3 Increase Volume
F4	Fn + F4 Go back to previous track in Windows Media Player
F5	Fn + F5 Play or Pause track in Windows Media Player
F6	Fn + F6 Skip forward to next track in Windows Media Player
F8	Fn + F8 Toggles between external displays and/or the internal LCD

F9	Fn + F9 Search (Windows 8 onwards)
F10	Fn + F10 Alter Keyboard Illumination Level (Optional)
F11	Fn + F11 Decreases LCD Brightness
F12	Fn + F12 Increases LCD Brightness
PrtScr	Fn + PrtScr Toggle Wireless (Wi-Fi) On/Off
Left Arrow	Fn + ← Activate Home
Right Arrow	Fn + → Activate End
Up Arrow	Fn + ↑ Activate Page Up
Down Arrow	Fn + ↓ Activate Page Down

 **NOTE:** Keyboard Types by Region.
(This should not affect the Function Table above.)

- 80 (United States and Canada)
- 81 (Europe)
- 82 (Brazil)

 **NOTE:** **Note:** If you are experiencing problems with your keyboard, please follow the troubleshooting guide linked below:

- [Keyboard Usage and Troubleshooting Guide](#)

[Back to Top](#)

Cause

Resolution

Article Properties

Affected Product

Dell Latitude 3480/3488, Latitude 3490

Last Published Date

22 Sep 2021

Version

7

Article Type

Solution