


SPI Configuration


Step 1: Enable the SPI port of your Raspberry Pi (If you have enabled it, skip this; if you do not know whether you have done that or not, please continue).

`sudo raspi-config`


5 Interfacing options




P4 SPI




<YES>



<OK>



<Finish>



Step 2: Check that the i2c modules are loaded and active.

```
ls /dev/sp*
```

Then the following codes will appear (the number may be different).

```
/dev/spidev0.0 /dev/spidev0.1
```

Step 3: Install Python module SPI-Py.

```
git clone https://github.com/lthiery/SPI-Py.git
```

```
cd SPI-Py
```

```
sudo python3 setup.py install
```

Note: This step is for python users, if you use C language, please skip.

Copyright Notice

All contents including but not limited to texts, images, and code in this manual are owned by the SunFounder Company. You should only use it for personal study, investigation, enjoyment, or other non-commercial or nonprofit purposes, under the related regulations and copyrights laws, without infringing the legal rights of the author and relevant right holders. For any individual or organization that uses these for commercial profit without permission, the Company reserves the right to take legal action.