

GNSS FW Update Guide

- 1 Disconnecting everything (including CAN, GNSS antenna, RS232) except the Ethernet cable and power cable.
- 2 Perform a hard power cycle by disconnecting and reconnecting the power cable.
- 3 Open a telnet terminal to connect to OBU.
- 4 Enter the `version` command to check current SDK version and GNSS FW version.
 - 4.1 If it returns with **GNSS: N/A**, perform a hard power cycle and try again.
Check the NMEA baud rate with `gnss nmea_speed_sense` command. If it still returns with **Failed to sense NMEA speed**, then the GNSS module is bricked. A RMA will be needed.
 - 4.2 If it returns with **GNSS: 3.5.3-1**, then perform the next step.
- 5 If the Autotalks SDK is below 4.10.0, then upgrade it to a 4.10.0 or above version. Board type should be **pcb201v1**.
- 6 Upload enclosed "**sta8088-3.1.15-atk22016-2.0.0.upg.bin**" to **D:** folder in OBU via a FTP client, e.g Filezilla. (D: is RAM FS)
- 7 Check the NMEA baud rate with `gnss nmea_speed_sense` command.
 - 7.1 If it returns with **Failed to sense NMEA speed**, then perform a hard power cycle and try again.
 - 7.2 If it returns with **Sensed NMEA speed: 230400 bits/s**, then perform the next step.
- 8 Update TESEO FW with the following command. It may take about 40 seconds:
`teseo fw_update D:/sta8088-3.1.15-atk22016-2.0.0.upg.bin 230400 921600 1 0`
`0`