

Electrical Rules Check Report

Class	Document	Message
Warning	101_GridPos1.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	201_GridPos2.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	301_GridPos3.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	401_GridPos4.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	501_GridPos5.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	601_GridPos6.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	701_GridPos7.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	801_GridPos8.SchDoc	Global Power-Object GND at 17200mil,700mil has been reduced to local level by presence of port at 16600mil,800mil
Warning	001_OverViewGridMod1.SchDoc	Nets Wire GND has multiple names (Power Object GND (56), Power Object SHD (24), Sheet Entry Grid Position 1/8-GND(Passive), Sheet Entry Grid Position 2/8-GND(Passive), Sheet Entry Grid Position 3/8-GND(Passive), Sheet Entry Grid Position 4/8-GND(Passive), Sheet Entry Grid Position 5/8-GND(Passive), Sheet Entry Grid Position 6/8-GND(Passive), Sheet Entry Grid Position 7/8-GND(Passive), Sheet Entry Grid Position 8/8-GND(Passive))