

# ENGINE START

- Doors.....CLOSE
- UV lights.....AS REQUIRED
- Battery BATT switch.....ON
- Alternator ALT switch.....ON
- Generator GENE switch.....ON
- AM radio.....ON
- Navigation lights.....AS REQUIRED
- Strobe lights.....AS REQUIRED
- NADIR.....VEILLE
- Radio ATC and REQUEST START-UP.
- Fuel pump POMPE.....ON  
Wait for 20 seconds using stopwatch.
- Starter DEM switch.....ON
- DEM light.....ON
- Turbine IDLE.....25100 RPM
- DEM light.....OUT
- Rotor brake lever.....FORWARD
- Fuel flow lever.....FORWARD until ROTOR
- Turbine and rotor RPM.....WAIT TO SYNC
- Fuel flow lever.....SLOWLY FULLY FORWARD
- Starter switch.....OFF
- Pitot heat switch.....ON
- Trim switch.....ON
- Magnetic brake DEBR. EFF.....ON
- Gyro mode.....GM
- Autopilot master switch.....ON
- Autopilot pitch switch.....ON
- Autopilot yaw switch.....ON

# ENGINE START

- ADI.....UNCAGE
- Standby ADI.....UNCAGE
- Radar altimeter.....ON
- Radar altimeter.....SET ALTITUDE
- DRAX33 RWR.....ON
- NADIR.....TERRE
- Flare dispenser mode.....LE or VE
- Flare dispenser launch quantity.....C/C or SEQ
- Flare dispenser cover.....CLOSE
- Radio [ATC](#) and [REQUEST TAXI](#).

# VIVIANE

- TV monitor.....ON
- VCB IR power switch.....ON
- CTH power swtich.....ON
- VCB mode.....ASS
  - Wait 90 sec before moving camera.
  - Wait 180 sec for cooling to complete.
- Monitor brightness and contrast.....AS REQUIRED
- Turn key.....JOUR
- Master arm.....ON
- VCB mode.....PIL
- Weapon station selector.....AS REQUIRED
- Safety cap LASE.....REMOVE
- Safety cap FIRE.....REMOVE