

- Doors.....CLOSE
- UV lights.....AS REQUIRED
- Battery BATT switch.....ON
- Alternator ALT switch.....ON
- Generator GENE switch.....ON
- AM radio.....ON
- Navigation lights.....AS REQUIRED
- Strobe lights.....AS REQUIRED
- NADIR.....VEILLE
- Radio ATC and REQUEST START-UP.
- Fuel pump POMPE.....ON
Wait for 20 seconds using stopwatch.
- Starter DEM switch.....ON
- DEM light.....ON
- Turbine IDLE.....25100 RPM
- DEM light.....OUT
- Rotor brake lever.....FORWARD
- Fuel flow lever.....FORWARD until ROTOR
- Turbine and rotor RPM.....WAIT TO SYNC
- Fuel flow lever.....SLOWLY FULLY FORWARD
- Starter switch.....OFF
- Pitot heat switch.....ON
- Trim switch.....ON
- Magnetic brake DEBR. EFF.....ON
- Gyro mode.....GM
- Autopilot master switch.....ON
- Autopilot pitch switch.....ON
- Autopilot yaw switch.....ON

- ADI.....**UNCAGE**
- Standby ADI.....**UNCAGE**
- Radar altimeter.....**ON**
- Radar altimeter.....**SET ALTITUDE**
- DRAX33 RWR.....**ON**
- NADIR.....**TERRE**
- Flare dispenser mode.....**LE or VE**
- Flare dispenser launch quantity.....**C/C or SEQ**
- Flare dispenser cover.....**CLOSE**
- Radio **ATC** and **REQUEST TAXI**.

- TV monitor.....ON
- VCB IR power switch.....ON
- CTH power swtich.....ON
- VCB mode.....ASS
 - Wait 90 sec before moving camera.
 - Wait 180 sec for cooling to complete.
- Monitor brightness and contrast.....AS REQUIRED
- Turn key.....JOUR
- Master arm.....ON
- VCB mode.....PIL
- Weapon station selector.....AS REQUIRED
- Safety cap LASE.....REMOVE
- Safety cap FIRE.....REMOVE