

403-2069-024

Sheet 1 of 17

Prepared 1/12/2011 by:  
Lore Eargle

Revision	Date	Change Description
A	4-28-2004	Initial Release.
B	1-10-2008	Removed all references to the hardware key, added registered trademark for NACAT, updated the Nielsen logo, and replaced references to nielsenmedia.com with nielsen.com.
C	10-29-2009	Update EULA
D	1-12-2011	Added references to Nielsen Watermarks detection; added procedures; removed references to Facility Display Setup, which is no longer in the application. Removed references to installing from a CD.

Copyright © 2005 — 2011 The Nielsen Company (US), LLC. All rights reserved. Nielsen and the Nielsen Logo are trademarks or registered trademarks of CZT/ACN Trademarks, L.L.C. NACAT is a trademark or registered trademark of The Nielsen Company (US), LLC.

Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Other company names, products and services may be trademarks or registered trademarks of their respective companies.

This documentation contains proprietary information of The Nielsen Company. Publication, disclosure, copying, or distribution of this document or any of its contents is prohibited, unless consent has been obtained from The Nielsen Company.

The NACAT decoding software is the intellectual property of and proprietary information of The Nielsen Company and is licensed and not sold. Publication, disclosure, copying, or distribution of the software or any of its contents is strictly prohibited.

## **NIELSEN NACAT® End-User Product License Agreement**

IMPORTANT LEGAL NOTICE FROM THE NIELSEN COMPANY (US) LLC (.NIELSEN.): READ THESE TERMS CAREFULLY BEFORE INSTALLING AND USING THE NIELSEN AUDIO CODE ANALYSIS TOOL (.NACAT.). BY DOWNLOADING THIS PRODUCT, YOU ACKNOWLEDGE THAT YOU HAVE READ THIS LICENSE AGREEMENT, THAT YOU UNDERSTAND IT, AND THAT YOU AGREE TO BE BOUND BY ITS TERMS. YOU INDICATE ACCEPTANCE BY SELECTING THE "I ACCEPT THE TERMS IN THE LICENSE AGREEMENT" OPTION ON THE LICENSE AGREEMENT DIALOG. IF YOU ARE NOT WILLING TO BE BOUND BY ALL THE TERMS, SELECT THE "I DO NOT ACCEPT THE TERMS IN THE LICENSE AGREEMENT" OPTION ON THE LICENSE AGREEMENT DIALOG AND THE INSTALL PROCESS WILL NOT CONTINUE. THE TERMS "YOU" AND .YOUR. AS USED HEREIN REFERS TO THE END-USER OF THE PRODUCT AND MAY INCLUDE, NATURAL PERSONS, A CORPORATE ENTITY(IES) AND EMPLOYEES THEREOF.

1. Grant of License. NIELSEN grants YOU a limited, non-exclusive, non-sublicensable, non-transferable, revocable license to install and internally use one copy, in object code form only, of NACAT with which this license is distributed (the "Product") and to use any documentation accompanying the Product ("Documentation") on one personal computer located in the United States and owned by YOU for the sole purpose of gross verification and non-qualitative evaluation of the operation of the Nielsen Audio Video Encoder (.NAVE.) equipment that is owned by YOU as a client of Nielsen (the .Purpose.), provided that: (i) the Product is NOT modified and no derivative works or enhancements are made thereto; (ii) the data resulting from the use of the Product is used solely for the Purpose (iii) all identifying marks, copyright and proprietary notices, are maintained on the Product; (iv) YOU agree to be bound by all the terms, conditions and restrictions of this License Agreement (v) YOU are authorized to accept the terms of this License Agreement or have been authorized as an employee of the owner of the NAVE encoder equipment to accept the terms of this License Agreement, and (vi) YOU are the owner, or an employee of the owner, of the NAVE encoder equipment with which the Product will be used.

2. Ownership. The Product and Documentation are licensed and not sold and YOU have no ownership rights in the Product or the Documentation. Ownership of the Product, Documentation and all intellectual property rights therein and good will associated therewith shall remain at all times with and accrue solely to NIELSEN.

3. Intellectual Property. The Product and Documentation contain material that is protected by United States intellectual property laws, including, Copyright Law, trademark law and/or trade secret law, and by international treaty provisions. All rights not expressly granted to YOU herein are reserved by NIELSEN. No right, title or interest in or to any trademark, service mark, logo or trade name of NIELSEN. or its licensors is granted under this Agreement.

4. Restrictions. Any use of the Product, Documentation or data resulting from the use thereof for other than the Purpose or by any person, business, corporation, government organization or any other entity other than YOU is strictly forbidden and is a violation of this License Agreement. YOU agree that the Product, Documentation and any data or rate of data resulting from use of the Product and/or Documentation is not intended to be and is not necessarily indicative of either the quality of the NAVE encoding technology or of the quality or accuracy of any television audience measurement data ("the Ratings") provided by NIELSEN. NIELSEN shall not be responsible for providing any technical support, bug fixes, error corrections, updates, replacements, enhancements, or conversions of the Product and/or Documentation or for otherwise maintaining the Product and/or Documentation.

YOU may not publish, display, disclose, rent, lease, modify, loan, distribute, modify, create (or allow others to create) enhancements to create derivative works of the Product, Documentation or any part thereof or any data resulting from the use of the Product and/or Documentation. YOU will not and will not allow any third party to use or interpret any data or rate of data resulting from use of the Product and/or Documentation as indicative of either the quality of the NAVE encoding technology or of the quality or accuracy of the Ratings provided by NIELSEN. YOU may not reverse engineer, decompile, translate, adapt, or disassemble the Product, nor shall YOU attempt to create the source code from the object code for the Product. YOU may transfer the Product to other computers YOU own provided that YOU maintain only a single copy of the Product at any given time. YOU may not distribute the Product or Documentation or copies of the Product or Documentation to any third party for any reason without the prior, written consent of NIELSEN.

5. Confidentiality. YOU acknowledge that the Product and Documentation may contain proprietary trade secrets of NIELSEN, and YOU hereby agree to maintain the confidentiality of the Product, Documentation and any data resulting from the use of the Product or Documentation using at least as great a degree of care as YOU use to maintain the confidentiality of confidential information owned by YOU and in no case with less than a reasonable standard of care.

6. Disclaimer of Warranty. THE PRODUCT AND DOCUMENTATION ARE BEING SUPPLIED TO YOU FREE OF CHARGE. ANY INSTALLATION OF OR USE BY YOU OF THE PRODUCT, DOCUMENTATION AND/OR DATA RESULTING FROM THE USE THEREOF IS AT YOUR OWN RISK. THE PRODUCT, DOCUMENTATION AND ANY

DATA RESULTING FROM THE USE THEREOF ARE PROVIDED "AS IS." TO THE MAXIMUM EXTENT PERMITTED BY LAW, NIELSEN, DISCLAIMS ALL WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. NIELSEN DOES NOT WARRANT THAT THE FUNCTIONS CONTAINED IN OR PERFORMED BY THE PRODUCT AND/OR DOCUMENTATION WILL MEET ANY REQUIREMENTS OR NEEDS YOU MAY HAVE, OR THAT THE PRODUCT WILL OPERATE ERROR FREE, OR IN AN UNINTERRUPTED FASHION, OR THAT ANY DEFECTS OR ERRORS IN THE PRODUCT AND/OR DOCUMENTATION WILL BE CORRECTED, OR THAT THE PRODUCT AND/OR DOCUMENTATION IS COMPATIBLE WITH ANY PARTICULAR PLATFORM.

7. Limitation of Liability. IN NO EVENT WILL NIELSEN BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING, WITHOUT LIMITATION, INDIRECT, SPECIAL, PUNITIVE, OR EXEMPLARY DAMAGES FOR LOSS OF BUSINESS, LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF BUSINESS INFORMATION) ARISING OUT OF THE INSTALLATION, USE OF OR INABILITY TO USE THE PRODUCT AND/OR DOCUMENTATION OR FOR ANY CLAIM BY ANY OTHER PARTY, EVEN IF NIELSEN HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO SOME OF THE TERMS ABOVE MAY NOT BE APPLICABLE TO YOU. IN NO EVENT WILL NIELSEN'S LIABILITY EXCEED THE GREATER OF THE AMOUNT PAID FOR THE PRODUCT AND DOCUMENTATION LICENSED UNDER THIS AGREEMENT OR ONE U.S. DOLLAR.

8. Export Restrictions. THIS LICENSE AGREEMENT IS SUBJECT TO ANY LAWS, REGULATIONS, ORDERS, OR OTHER RESTRICTIONS ON THE EXPORT FROM THE UNITED STATES OF AMERICA OF THE PRODUCT OR INFORMATION ABOUT SUCH PRODUCT WHICH MAY BE IMPOSED FROM TIME TO TIME BY THE GOVERNMENT OF THE UNITED STATES OF AMERICA. YOU SHALL NOT EXPORT THE PRODUCT AND/OR DOCUMENTATION OR INFORMATION ABOUT THE PRODUCT AND/OR DOCUMENTATION WITHOUT COMPLIANCE WITH SUCH LAWS, REGULATIONS, ORDERS, OR OTHER RESTRICTIONS.

9. Termination. This License Agreement commences when you accept the terms of the License Agreement as provided herein above and will continue, unless earlier terminated earlier in accordance with the terms hereof. YOU may terminate this License Agreement at any time by returning to NIELSEN all copies of the Product and Documentation in your possession or under your control. Upon the first to occur of either the completion of the Purpose or if YOU no longer own the NAVE encoder equipment, YOU are required to return the Product and Documentation to NIELSEN within thirty (30) calendar days after which time this License Agreement shall terminate. NIELSEN may terminate this License Agreement for any or no reason, including but not limited to NIELSEN's determination that YOU have violated any of the terms of this License Agreement. Upon notification of termination, YOU agree to return to NIELSEN all copies of the Product and Documentation. All provisions relating to confidentiality, proprietary rights and non-disclosure shall survive the termination of this License Agreement.

10. General. This License Agreement shall be construed, interpreted and governed by the laws of the State of Illinois without regard to conflicts of law provisions thereof. The exclusive forum for any disputes arising out of or relating to this License Agreement shall be an appropriate federal or state court sitting in the state of Illinois, USA. This License Agreement shall constitute the entire Agreement between the parties hereto. Any waiver or modification of this License Agreement shall only be effective if it is in writing and signed by both parties hereto. If any part of this License Agreement is found invalid or unenforceable by a court of competent jurisdiction, the remainder of this License Agreement shall be interpreted so as to reasonably effect the intention of the parties. This Agreement is the entire agreement between YOU and NIELSEN relating to its subject matter. It supersedes all prior or contemporaneous oral or written communications, proposals, representations and warranties and prevails over any conflicting or additional terms of any quote, order, acknowledgment, or other communication between the parties relating to its subject matter during the term of this Agreement. No modification of this Agreement will be binding, unless in writing and signed by an authorized representative of each party.

# Contents

- Overview ..... 3
  - Customer Support..... 3
  - System Requirements..... 3
  - Incompatibilities & Performance Anomalies ..... 3
- Setting Up the NACAT Application ..... 5
  - Installing NACAT..... 5
  - Setting Up the Audio Input..... 5
- Using NACAT ..... 8
  - Editing Preferences..... 9
- Uninstalling NACAT ..... 10
- NACAT Window Description ..... 11
- Troubleshooting Tips..... 13



## Overview

NACAT®—Nielsen Audio Code Analysis Tool—is software that captures audio, decodes Nielsen audio codes, and logs and displays the information to the user. The Nielsen EVS department uses the NACAT application for monitoring, assisting in troubleshooting, and verifying NAVE encoder installations.

## Customer Support

Telephone: 800-537-4872  
Email: [Encoders@Nielsen.com](mailto:Encoders@Nielsen.com)

## System Requirements

For the best NACAT software performance, the PC on which it runs should have the following configuration.

- Microsoft® Windows XP® operating system or a later version
- Pentium or greater processor
- Minimum of 128 MB RAM memory
- 15 MB of hard disk space for the application
- 20 MB of hard disk space for log files (Periodic maintenance of these files may be required.)



A typical log file requires approximately 2 MB of hard disk space/day..

- “Line” level audio input (-10dBV consumer IHF input level)

## Incompatibilities & Performance Anomalies

NACAT has **not** been fully qualified on all configurations of operating software and computer hardware and you may experience anomalies with your particular configuration. Please contact the Encoder Support Group to report any NACAT abnormalities you experience.

A performance anomaly was noted when using this software on a Compaq® C610 laptop using the port replicator. When using a laptop, it is recommended that it should have a direct Line-input to the sound card instead of connecting through a port replicator.

Microphone input to the sound card as an audio source is not recommended and is not supported.

The selected audio alert WAV file is played using the WaveOut resource of the systems sound device. It has been noted that on certain PCs, the WaveOut resource is mixed with the Recording Input resource of the sound device. Depending on the characteristics of the wave file, this anomaly affects the proper decoding of the NAES II codes. If this occurs, try using the default Alarm.wav file that is included with the application.



# Setting Up the NACAT Application

Follow the install instructions and then perform the setup procedure.

## Installing NACAT

Use this procedure to install the NACAT application to a hard drive.

1. Do one of the following:

If...	Do this:
An existing version of NACAT is already installed	<ol style="list-style-type: none"> <li>1. Uninstall the current version of <b>NACAT</b>. See page 10, "Uninstalling NACAT."</li> <li>2. Go to step 2.</li> </ol>
NACAT is not installed.	Go to step 2.

2. Double-click **NACAT.exe**.
3. Follow the prompts.
4. Start the NACAT application and do one of the following:

If...	Do this:
NACAT launches	Go to "Setting Up the Audio Input."
NACAT does not launch.	<ol style="list-style-type: none"> <li>1. Click the Microsoft Windows <b>Start</b> button.</li> <li>2. Browse to <b>Programs &gt; Nielsen Media Research &gt; NACAT &gt; Launch VC Redistributable</b>. An application installs the missing, required Visual C runtime libraries.</li> <li>3. Go to Setting Up the Audio Input.</li> </ol>

## Setting Up the Audio Input

Before using the NACAT application, you need to select and adjust the volume level of the input source. The Line In is the only supported recording input. Connecting to the left audio is necessary and it is not necessary to connect to the right.



**Do not use the microphone input; the frequency response of the microphone input could adversely affect the code detection performance of the NACAT application.**

1. After installing the NACAT application, connect an audio line level input source to the Line In port on the sound card.
2. Start the NACAT application. When the application starts up for the first time, a configuration dialog appears.
3. Check the default values and do one of the following:

To...	Do this:
Accept the current values	Click <b>Cancel</b> and go to step 5.
Change the preferences	<ol style="list-style-type: none"> <li>1. See Editing Preferences.</li> <li>2. Go to step 5.</li> </ol>


4. Play an audio file while doing the steps that follow.
5. On the **Tool** menu, select **Recording Control**.
6. On the **Options** menu in the **Recording Control** window, select **Properties**.
7. Ensure the **Stereo Mix** check box is selected.

**Figure 1 – Audio Properties Window**




8. Click **OK**.
9. On the **Recording Control** window, ensure the **Stereo Mix** check box is the only box that is checked.

**Figure 2 – Recording Control Window**



10. Adjust the volume level for **Stereo Mix** so, on the main NACAT window, each waveform in **Right Channel** and **Left Channel** is within its green lines, as shown below. See Figure 3.

**Figure 3 - Waveforms Showing Correct Audio Adjustment**



11. Close the **Recording Control** panel.

## Using NACAT

This procedure is based on the assumption that you have connected the device running the audio signal to the Line In port of the PC running the NACAT application.

There is a log file for each session and type of code found during the session: NAES II and Nielsen Watermarks.

1. Open the **NACAT** application.
2. On the NACAT main window, click **Start**. The NACAT main window displays the following. For an example and more details, see NACAT Window Description.
  - **Audio wave section**—waveforms for the left and right channels.
  - **Session information section**—time stamp and type of code detected.
  - **History section**—running log of details for the detected audio codes.
3. To transfer the NAES II and Nielsen Watermarks logs files, do the following:
  - a. Connect to the FTP server by typing the following command in the Windows Explorer address bar:

<ftp://mediasynca:6syn4Abc@rgp.nmrcf.com/MediaSync>

- b. Enter the following:

Parameter	Entry
Host name	rgp.nmrcf.com
User ID	mediasynca
Password	6syn4Abc
Directory	MediaSync

- c. Copy the NACAT log files that you want to transfer.



You can use any FTP application to transfer the files.

## Editing Preferences

Changing the values in the Setup window is optional.

1. On the **Tool** menu, select **Setup**.
2. On the **Setup** window, do any of the following as needed or keep the defaults.

To change the...	Do this:
Location where the log files are created and stored	<ol style="list-style-type: none"> <li>3. Click the <b>Log file folder</b> field.</li> <li>4. Click the ellipsis (3 dots).</li> <li>5. Browse to a new location for the log files and select it.</li> <li>6. Click <b>OK</b>.</li> </ol>
Color in which the Program Content code details appear in the Session Information and the History sections on the main window	<ol style="list-style-type: none"> <li>1. Click the PC (Program Content) text color field.</li> <li>2. Click the ellipsis.</li> <li>3. Select a color and click <b>OK</b>.</li> </ol>
Color in which the Final Distributor code details appear in the Session Information and the History sections on the main window	<ol style="list-style-type: none"> <li>1. Click the FD (Final Distributor) text color field.</li> <li>2. Click the ellipsis.</li> <li>3. Select a color and click <b>OK</b>.</li> </ol>
Maximum amount of time that can pass without any codes detected before an alert is issued	<ol style="list-style-type: none"> <li>1. Click the No code warning delay (secs) field.</li> <li>2. Select one of the periods in the drop-down menu.</li> </ol>
Whether an audio alert sounds or not when Final Distributor codes are missing	<p>Click the <b>No FD code audio alert</b> field and do one of the following:</p> <ul style="list-style-type: none"> <li>▪ Select <b>Yes</b> to trigger an audio alert when the No code warning delay period is exceeded. The alarm stops when the NACAT detects a FD code in the audio or when the user clicks Stop.</li> <li>▪ Select <b>No</b> to not sound an alert when the No code warning delay period is exceeded.</li> </ul>
Maximum amount of time that can pass without Final Distributor codes detected before an alert is issued	<ol style="list-style-type: none"> <li>1. Click the No FD code warning delay (minutes) field.</li> <li>2. Select one of the periods in the drop-down menu.</li> </ol>
Sound of the audio alert (see the note below)	<ol style="list-style-type: none"> <li>1. Click the No FD code audio file (WAV) field.</li> <li>2. Click the ellipsis (3 dots).</li> <li>3. Browse to a file in the WAV format on the PC hard drive.</li> <li>4. Click <b>Open</b>.</li> </ol>



The selected audio alert WAV file plays through the WaveOut resource of the system sound device. On certain PCs, the WaveOut resource is mixed with the recording input resource of the sound device. Depending on the characteristics of the wave file, this anomaly affects the proper decoding of the NAES II codes. If this occurs, use the Alarm.wav file included with the application.

## Uninstalling NACAT


Use the **Add/Remove** command in Microsoft Windows **Control Panel** to uninstall the NACAT application.

A message may appear indicating that one or more of the OLE objects did not properly uninstall. This message is harmless and requires no action.

# NACAT Window Description

When the NACAT application is started, the main window appears.

Figure 4 - NACAT Main Window Sections



The main window includes the following components. Refer to the numbers, 1 through 5, in Figure 4.

1. **LED display**—flashes to indicate that a Source Identification (SID) code has been received.
2. **Start/stop button**—starts the NACAT monitoring session and stops it.
3. **Audio wave display**—displays the right and left channels of the incoming audio.
4. **Session information**—displays the following information found in the signal:
  - **Program Content SID**—displays the SID, date, time, and Daylight Saving Time (DST) status for the program content.
    - **N2**—indicates the code is NAES II code.
    - **NW**—indicates the code is Nielsen Watermarks code.
  - **Final Distributor SID**—displays the SID, Date, Time, and the DST status for the Final Distributor for NAES II and Nielsen Watermarks codes.
  - **System Status**—displays messages and warnings during an active monitoring session.
  - **Session Duration**—displays the monitoring period for this session.

5. History—displays a running log of the audio codes that have been received. This information is stored in a log file. When a new session begins, a new log file is automatically generated. For information on where the log file is stored or changing its location, see Editing Preferences.
  - **SID**—specifies the Source Identification number assigned to the programmer by Nielsen.
  - **Type**—specifies the audio code type. For information on changing the color, see Editing Preferences.
    - Program Content (PC) is indicated by a user-defined color.
    - Final Distributor (FD) is indicated by a user-defined color.
  - **Audio Code Time Stamp**—specifies the date and time stamp for the corresponding SID.
  - **DST**—specifies whether DST is in effect or not.
    - **S** indicates that the time stamp is set for Standard Time.
    - **D** indicates that the time stamp is set for DST.
  - **Log Time Stamp**—specifies the date and time the code was monitored.



## Troubleshooting Tips

If...	Try this:
Audio level is too low.	On the Tool menu, select Recording Control and adjust the audio level of the Line input, so that the audio signal is within the green lines.
No audio on either channel.	<ul style="list-style-type: none"> <li>▪ Ensure that the physical connection is connected into the Line input jack.</li> <li>▪ On the Tool menu, select Recording Control and ensure that the Line input is selected.</li> </ul>
Audio on one channel only.	<ul style="list-style-type: none"> <li>▪ Ensure that you have audio input for the left channel.</li> <li>▪ Ensure that the RCA plugs are properly plugged into both the audio source and the PC running NACAT.</li> </ul>
No Nielsen Codes detected.	<ul style="list-style-type: none"> <li>▪ Ensure that the station being monitored is NAES encoded.</li> <li>▪ Ensure the audio signal is between the green lines.</li> <li>▪ Ensure the Stop button appears in the upper right corner of the main window. If the Start button appears, click it to start monitoring.</li> <li>▪ Ensure that the left channel is receiving an audio signal.</li> </ul>
NACAT application does not launch.	<ul style="list-style-type: none"> <li>▪ Ensure that your system meets the minimum system requirements.</li> <li>▪ NACAT system files may be corrupted. Uninstall and reinstall the NACAT application.</li> </ul>
Not receiving a "No FD code audio alert".	<p>On the Tool menu, select Setup and ensure the following:</p> <ul style="list-style-type: none"> <li>▪ That you have not been receiving an FD code longer than the setting in the "No FD code warning delay (minutes)" field.</li> <li>▪ That a working WAV audio file is selected in the "No FD code audio file (WAV)" field.</li> </ul>