

3 – LIGHTING SYSTEM

- **INTERIOR LIGHTING**

- The interior lighting system consists of:
 - Cockpit Lights;
 - Cabin Lights, &
 - Baggage Compartment Lights.

Cockpit Lighting (**COCKPIT LIGHTS** *Control Panel* (Aft end Overhead Console):

- Back up (Standby Instruments / DC Ess.);
- Instrument panel (MFD bezel, AFCS, Clock / #2 DC Prim.);
- Console Side (#1 DC Prim.);
- Console Overhead (#2 DC Prim);
- Console Lower (#2 DC Prim.);
- P/B Dimmer (Batt & #2 DC Prim.), &
- Flood light (Batt.)
- Utility Lights (red/white) with coiled cords (Left & Right overhead) (Batt.)

Notes:

- **P/B Dimmer rheostat:**
 1. Fire Ext Test;
 2. Flotation Panel;
 3. Life Raft Panel;
 4. **Master Warning / Caution Panels;**
 5. Fire Detection Panel;
 6. Back up ATT switches;
 7. #1 & #2 MSP;
 8. AFCS Control Panel;
 9. Landing Gear;
 10. ELB Panel;
 11. Customized items (i.e. WX radar, etc...)
- **P/B LAMP TEST switch**
 1. Fire Detector Test status lights;
 2. Flotation armed / test lights;
 3. Life rafts armed / test lights;
 4. Master Warning/Caution panels lights;
 5. Fire bottle arming pushbuttons;
 6. B/U ATT. Indicator test lights;
 7. MSP's lights;
 8. AFCS pushbuttons lights;
 9. L/G position lights;
 10. Associated ELB panel lights, &
 11. Other Customized items (i.e. Wx radar, etc.)

Cabin Lighting (**INT LIGHT** *Control Panel*, Overhead Right):

- *Overhead Lights* (4), **OVHD** switch with **OFF**, **BRT** or **DIM** position (#1 & #2 DC Prim.)
- *Passenger Advisory Lights*, **SEAT BELT & NO SMOKE** (#1 DC Prim.)
- *Passenger Reading Lights*, **PASS READ** (#1 DC Prim.)


Baggage Compartment Lights (**INT LIGHT** *Control Panel*, Overhead Right):

- **BAG COMPT** switch with **OFF**, **ON** or **CREW** position (Batt.) (2nd switch on the *Crew Ramp Control Panel*)

- **EXTERIOR LIGHTING**

- The exterior lighting system consists of: (**EXT LIGHTS** *Control panel*, Overhead Left):
 - *Anti-Collision Lights* (2), (rotating beacon or strobe) **UPPER & LOWER** (DC Ess.); (40-100 flashes/min.)

- *Position Lights* **POSN**, (DC Ess);
- *Landing Lights* **LANDING** (450 watt), **#1**(#1 DC Prim.) & **#2** (DC Ess.);
- *Cargo Loading Light* **CARGO LOAD**, illuminate the area under the tail cone, aft of the cargo ramp. (2nd switch on the *Crew Ramp Control Panel* (Batt.);
- *Rotor Head Inspection Light* (droop stops) (#2 DC Prim.);
- *Controllable Searchlight* (450 watt), 3 position switch located on the both collective stick grip. **ON**, **OFF** or **STOW** position. (#2 DC Prim.)
The maximum elevation angle is **120°** (full forward) from the stowed position. The *search light* is located under the right side of the nose section.



• **EMERGENCY LIGHTING**

- The emergency lighting system consists of 12 power supplies (PS) (standard aircraft version)

Interior Emergency Lights (EMERG LTS Control Panel, Overhead Right)

- **OFF, ARM, ON** position.
 - **HEELS** Helicopter Emergency Egress Lighting System (4PS), (#2 DC Prim.);
 - **CABIN** Cabin Emergency Lights (1PS), (DC Ess.);
 - **FLOOR** Floor Emergency Lights (2PS), (#1 DC Prim.);
 - **EXIT** Exit Emergency Lights (3PS), (#1 DC Prim.);

Note: Cougar aircraft version: **HEELS & CABIN** switches only

- **OFF, ARM, ON** position
 - **HEELS** Helicopter Emergency Egress Lighting System (HEELS) (4PS), (#2 DC Prim.). Capable of operating under water for 10 min.
 - **CABIN** Cabin Emergency Lights (1PS), (DC Ess.).

Note: 2nd control switch for **CABIN & HEELS** (**ON & OFF** position) located *R/H avionics rack* (HUMS card) (*Cabin Emergency Lights Control Panel*). At any time, placing either switch to the **ON** position will activate the lights

Exterior Emergency Lights (EXT LIGHTS Control panel, Overhead Left)

- **OFF, ARM, ON** position
 - 6 exterior lights (4 @ the main cabin emergency exits, & 2 cargo ramp area) (2PS) (DC Ess.)

Note: 2nd control switch **EXTERIOR** (**ON & OFF** position) located *R/H avionics rack* (HUMS card) (*Cabin Emergency Lights Control Panel*). At any time, placing either switch to the **ON** position will activate the lights

Note: When "*Battery power*" only, the following lights are available:

- Cockpit Flood light;
- 2 Cockpit Utility lights
- P/B lamp Test switch;
- P/B Dimmer rheostat;
- Baggage compartment light;
- Cargo Load light

NOTES:

NOTES: