



HP TOUCHPAD ENABLING

On the laptop touchpad, there will be an LED located in the upper left corner. If the LED is off, the touchpad is enabled (functions as usual). If the LED is on (orange or blue), the touchpad is disabled. Note: This is only applicable to HP Elitebook 840 G4 and older laptop models.

METHOD 1

- 01 Quickly double tap the LED to enable or disable the touchpad.

METHOD 2

- 01 Using the pointing stick (isometric joystick between letters G, H, and B) and the touchpad mouse buttons, click on the Synaptics icon located at the bottom right corner of the screen in the menu bar.
- 02 Click on the tab labeled **TouchPad**. Then, click on the checkbox labeled **Double Tap To Enable or Disable TouchPad** to add a checkmark. Lastly, click on **Apply**.