




SolarSystem 550 communication command protocol



Communication protocol:

RS232 Serial command via RJ11 jack.

9600 Baud, 8-N-1 (MAY CHANGE TO 1200 BAUD FOR HIGHER NOISE TOLERANCE)

One way communication: Controller transmits, SS550 receives and echos command to the next fixture.

Serial Command format (String Format)

AA:BB:NextLevel:01:02:03:04

“AA:BB:” preamble. Ignored by the SS550

“NextLevel:” tells the SS550 this is a command to go to the next set of light levels.

“01”: 00-99 value of RED channel

“02”: 00-99 value of WHT channel

“03”: 00-99 value of BLU channel

“04”: 00-99 value of UVB register <Reserved for now, not used by the SS550>