

Overview

This pin detect HID example supports the mouse device.

The application prints the operation information when the mouse device is attached or plugged in to the PC host.

System Requirement

Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for a specific device
- Personal Computer

Software requirements

- The project files are in:
 <SDK_Install>/boards/<board>/usb_examples/usb_pin_detect_hid_mouse/<rtos>/<toolchain>.

Getting Started

Hardware Settings

Since FRDM-K66 have no USB Vbus control gpio, need user switch the jump setting to control USB Vbus manually, otherwise the USB pin detect example can't detect some low speed device if an adapter cable with a low speed mouse connected.

- The Jumper settings:
 J21 1-2 OFF and J16 1-2 OFF when switch to device mode.
 J21 1-2 ON or J16 1-2 ON after switch to host mode.

For detailed instructions, see the appropriate board User's Guide.

Prepare the example

1. Download the program to the target board.
2. Power off the target board and power on again, or press the reset button on your board.

Note

For detailed instructions, see the appropriate board User's Guide.

Run the example

1. Connect the board UART to the PC and open the COM port in a terminal tool.
2. Run the pin_detect_hid_mouse example. The board now acts as an USB device mouse, and a USB switch to device mode information is displayed.
3. Plug in a mouse to the test board. The board acts as an USB host. The stack switches to host mode and some device attached information is printed out.
4. When the mouse is moved, the relevant information is output to the screen, such as: When the mouse moved up, "UP" is displayed on the screen. When the mouse moved down, "DOWN" is displayed on the screen.

5. Unplug the mouse with the cable. The board now acts as a USB device mouse. The mouse is detached and the USB switches to the device mode information.
6. Plug in the mouse device into the PC. An HID-compliant mouse is enumerated in the Device Manager.
7. The mouse arrow is moving on the PC screen in a rectangular rotation.

The following figures shows a pin detect HID mouse information for the pin detect HID mouse demo.

```
host init done  
hid mouse attached:pid=0x4d15vid=0x461 address=1  
mouse attached  
  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
Right UP  
  
mouse detached  
host deinit done  
USB device HID mouse demo
```

Figure 1: Pin detect hid mouse demo