

GUIDE 04 #raspiSerie:

Raspberry Pi - Setting Up a VNC On Your Pi - 04 #raspSerie

Here are 10 steps:

1 - Download VNC VIEWER from <https://www.realvnc.com/download/viewer/>;

2 - On terminal of RASPBERRY PI:

```
sudo apt-get update
```

3 - Install remote desktop console version:

```
sudo apt-get install vino dconf-editor
```

4 - Navegate to System > DConfig Editor:

Head over org > gnome > desktop > remote-access and uncheck:

```
prompt-unable  
require-encryption
```

5 - Make vino automatically start with your session:

```
cd ~/.config  
mkdir autostart  
cd autostart  
nano vino.desktop
```

6 - Paste this piece of code:

```
[Desktop Entry]  
Encoding=UTF-8  
Type=Application  
Name=Vino  
Comment=  
Exec=/usr/lib/vino/vino-server  
StartupNotify=false  
Terminal=false  
Hidden=false
```

7- type CRTL + X , Y and hit Enter;

8 - sudo reboot

9 - Run VNCViewer on Windows, pop your Pi address;

10 - You can play at ease with your pi!!!

Last updated on 2016-08-25 at 20.27.11 PM

Published on 2016-08-25 at 20.31.55 AM

Thanks to Novaspirit Tech!!!