

Note: Power off. Do not just pull the power cord.

Instead move the Field/home switch to the opposite side from where it was when booted for the current session. Then watch the green LED inside the case. Wait for it to do an even spaced 9 blinks. Then you can remove the power. Doing otherwise can corrupt the SD card. The switch must be held in the other position for at least 6 seconds before the shutdown sequence will st