

TR-206

Development Document

Version 0.4_100326

Preliminary

[Globalsat Technology Corporation](#)

16F., No. 186, Jian-Yi Road, Chung-Ho City, Taipei Hsien 235, Taiwan

Tel: 886-2-8226-3799/ Fax: 886-2-8226-3899

E-mail: service@globalsat.com.tw

Website: www.globalsat.com.tw

Version	Description
0.1	Document creation
0.2	1. Delete: parking mode, sleeping mode, simple command 2. Add: 12.3 SMS format 1 3. Move “8. emergency” to 7.1

CONTENT

1 Introduction	4
2 Protocol Summary	5
2.1 General Format.....	5
2.2 Setup Format	6
2.2.1 Server -> Device	6
2.2.2 Device -> Server	6
2.3 Geo-fence Format.....	6
2.3.1 Server -> Device	6
2.3.2 Device -> Server	6
2.3.3 Geo-fence area definition format	7
2.4 Command Format.....	7
2.5 Report Messages Format.....	8
2.6 Parameters of Report Messages	9
2.7 Configuration Parameters.....	12
2.8 Command's Codeword.....	29
2.9 Report Media.....	31
2.10 Checksum.....	32
3 Configuration	33
3.1 Read parameters of configuration	33
3.2 Set parameters of configuration	34
4 GSM & GPRS	36
4.1 GPRS Setting	36
4.2 Acknowledgement.....	37
4.2.1 Receive Acknowledgement from Server.....	38
4.2.2 Respond Acknowledgement to Server	39
5 GPS	41
6 Tracking.....	44
6.1 Ping	44
6.2 Periodic Mode	46
6.3 On-Line Mode.....	48
6.4 Motion Mode.....	51
7. Alert.....	55
7.1 Emergency.....	55
7.2 Speed Limits.....	56

7.2.1 Enable Speed Limit Alert	57
7.2.2 Disable Speed Limit Alert	59
7.3 Geo-fence	61
7.3.1 Setup Geo-fence	62
7.3.2 Enter Geo-fence Alert	68
7.3.3 Dismiss Geo-fence Alarm	69
7.3.4 Stop Geo-fence Alert	70
8 Voice Monitor	71
9 Timer	72
9.1 Timer 0	72
9.2 Timer 1~3	72
10 Alarm Clock	74
11 Other Function	77
12 Report Messages	78
12.1 Format 0 of Report Messages	78
12.2 Format 1 of Report Messages	80
12.3 Format 1 of SMS	82
13 Data Log	85
14 Buffer Storage	88
15 Cell ID	89

1 Introduction

TR-206 is a tracker that can track the location of the elderly, children, pets, and vehicles.

It can apply for fleet management, looking for lost children, elderly care, and lost pets.

This document describes the communication protocol between TR-206 tracker and server, the built-in behavior modes of TR-206, and the function of each parameter.

It helps system integration developer to develop back-end system in the shortest time.

2 Protocol Summary

2.1 General Format

GS _x ,IMEI,[_T , _S ,]Field1,Field2,.....,FieldN*Checksum!		
Format	Description	Note
GS_x	“GS _S ” :Write setting to device “GS _s ” :Report setting from device “GS _G ” :Write Geo-fence parameter to device “GS _g ” :Report Geo-fence parameter from device “GS _C ” :Action command “GS _r ” :Position and status report (format 0) “GS _h ” :Position and status report (format 1) “GS _d ” : Cell ID and status report (format 2)	Command head
IMEI	(The IMEI number)	GSM device ID
T	‘0’ : Middle of message ‘1’ : Start of message ‘2’ : End of message ‘3’ : Start and End of message, i.e., only one packet for message	Message packet control
S	‘0’,‘1’,‘2’,‘3’,...,‘9’,‘10’,‘11’,...,‘99’	Sequence number
Field	Field 1 ~ Field N	Refer to “TR-206 configure parameters” for details
*	*	End of field
Checksum	The checksum value is derived by the same method of NMEA standard. It is calculated by ‘exclusive OR’ the 8 data bits of each character before “*” in the sentence, but excluding “*”. The hexadecimal value of the most significant and least significant 4 bits of the result are converted to two ASCII characters (0-9, A-F) for transmission. The most significant character is transmitted first.	

!	!	Message delimiter
---	---	-------------------

2.2 Setup Format

2.2.1 Server -> Device

GS**S**,IMEI,T,S,x1=y1,x2=y2,x3=y3,.....*Check Sum!

x1,x2,x3... are code words for configuration parameters.
y1,y2,y3... are their respective settings.

2.2.2 Device -> Server

GS**S**,IMEI,T,S,x1=y1,x2=y2,x3=y3,.....*Check Sum!

2.3 Geo-fence Format

2.3.1 Server -> Device

GS**G**,IMEI,T,S,1=(type,upper_left_Lon,upper_left_Lat,right_bottom_Lon,right_bottom_Lat[,startTime,endTime,weekday]),2=(...),3=(...),...*Check sum!

2.3.2 Device -> Server

GS**G**,IMEI,T,S,1=(type,upper_left_Lon,upper_left_Lat,right_bottom_Lon,right_bottom_Lat[,startTime,endTime,weekday]),2=(...),3=(...),...*Check sum!

2.3.3 Geo-fence area definition format

(type,upper_left_Lon,upper_left_Lat,right_bottom_Lon,right_bottom_Lat[,gxxx][,startTime,endTime,weekday])

type	0=disable the area 1=get in area 2=get out of area 3=cross over the boundary 4=stay in area 5=stay out of area
upper_left_Lon,upper_left_Lat,right_bottom_Lon,right_bottom_Lat	Coordinate of specified area
startTime,endTime,weekday	Optional field which specify the effective time frame of this geo-fence area. Start Time and end Time are in seconds. Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.

2.4 Command Format

GSC,IMEI,c1(option1),c2(option2),.....*checksum!

c1,c2...are code words of commands.

option1, option2... are their respective parameters. Please refer to 2.7.

2.5 Report Messages Format

There are two types of report message format, “format 0” and “format 1”.
(Refer to “12. Report” for detail definition)

Example:

TR-206 -> Server (format 0)

GSr,IMEI,Device_Mode,Report_Type,Alarm_Status,Geofence_status,GPS_Fix,UTC_Date,UTC_Time,Longitude,Latitude,Altitude,Speed,Heading,Number_of_Satellites,HDOP,Battery_capacity*checksum!

TR-206 -> Server (format 1)

GS^h, IMEI,Alarm_Status,GPS_Fix,Battery_capacity*checksum!

2.6 Parameters of Report Messages

Parameters of Report Message		
Codeword	Parameters	Description
A	GPS fixing status	1=not fix 2=2D fix 3=3D fix
B	UTC Date, Time	ddmmyy,hhmmss
C	Local Date, Time	ddmmyy,hhmmss
1	Longitude	(E or W)ddd.dddddd
2	Longitude	(E or W)dddm.mmmm
3	Longitude	(+ or -)ddddddddd unit: 0.000001 degree
6	Latitude	(N or S)dd.dddddd
7	Latitude	(N or S)ddm.mmmm
8	Latitude	(+ or -)ddddddddd unit: 0.000001 degree
G	Altitude	xxxxx.x Unit: meter
H	Speed	xxx.xx unit: knots (1.852km/hr)
I	Speed	xxx unit: km/hr
J	Speed	xxx unit: mile/hr
K	Heading	xxx unit: degree
L	Number of satellite in use	xx
M	HDOP	xx.x
N	Battery capacity	xx unit: percent capacity
O	Operation mode	2=Periodic 3=On-line 4=Motion 7=Standby

		8=Off
P	Alarm status	xx(hex digits) bit0=SOS alarm bit4=Geo-fence alarm bit5=Speed alarm bit7=Battery low alarm
Z	Geo-fence status	Empty field: no geo-fence alarm lxxx: get in area xxx Oxxx: get out area xxx
Q	Report Media	xx(hex digits) bit0=SMS bit1=TCP bit2=UDP bit6=Acton[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
R	Report type	1=Ping report 2=Periodic mode report 3=On-line mode report 4=Motion mode static report 5=Motion mode moving report 6=Motion mode static to moving report 7=Motion mode moving to static report G=Geo-fence alarm report I=SOS alarm report J=Low battery alarm report K=Speed alarm report L=Timer 0 report M=Timer 1 report N=Timer 2 report O=Timer 3 report P=L4 report Q= Power on report

		R= Power off report
S	IMEI	
T	Device ID	
U	Checksum	The checksum value is derived by the same method of NMEA standard. It is calculated by 'exclusive OR' the 8 data bits of each character before "*" in the sentence, but excluding "*". The hexadecimal value of the most significant and least significant 4 bits of the result are converted to two ASCII characters (0-9, A-F) for transmission. The most significant character is transmitted first.
#		
*		
?		
!	!	Message delimiter

2.7 Configuration Parameters

Most behaviors of TR-206 could be changed by Configuration Parameters. You could change the setting of configuration parameters by the following methods.

1. Connect TR-206 to personal computer via USB cable and then set the configuration parameters by “TR206 Config Tool.”
2. Send the “GSS,....!” setting with the configuration parameters to TR-206
3. Send the “GSC,....!” command with the configuration parameters to TR-206

All the settings or commands could be sent by SMS or TCP or UDP.

You could also send L1 command to read the present setting of TR-206.

Configure Parameters

		Code words	Parameters	Type	Description
Main	Device	O5	Device ID	char(16)	
		O7	Firmware Version	char(28)	Read only
		O6	Time Zone Offset	s32, in seconds	-43200 ~ 46800
		O4	Power on operating mode	u8	2=Periodic 3=On-line 4=Motion 7=Standby Default=7
		B2	IMEI code	char(16)	Read only
	SIM	B0	PIN code	char(4)	
		B1	Phone number of SIM card	char(20)	
	Vibrator	I2	Enable/ disable TR-206 to vibrate after pressing SOS key	1/0	0=disable 1=enable

	Battery	J0	The power capacity for sending out battery low alarm report	u8, percent	15 ~ 100
		J1	The power capacity for power off TR-206	u8, percent	10 ~ 100
		J6	Battery low alarm report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		J7	The power capacity for clear battery low alarm flag	u8, percent	10 ~ 100
		J8	Enable/disable TR-206 to automatically power on when power capacity is charged to the capacity of J1	1/0	0=disable 1=enable
	Data logger	O2	Data logger interval	u16, in seconds	1 ~ 65535 Default=60
		OH	Data logger distance	u32, in meters	0 ~ 86400 0=disable
	Other setting	O1	Motion sensor sensitivity	u16	0 ~ 100 Default=5
		O3	Report format 0	char(32)	Default=SORPZAB27GHKLMN*U!
		ON	Report format 1	char(32)	Default=SARN*U!
		OG	Enable/ disable data buffer function	1/0	Default=1
		O8	Enable/ disable	1/0	Default=0.

			TR-206 to report “cell ID” if it does not get GPS fix		The report format will automatically switch from format 0 to format 2 when TR-206 does not get GPS fix.
		OO	Report media for reading configuration	Media type	bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		OV	Send power on/off report	1/0	0=disable 1=enable Default =0
		OW	Report media of power on/off report	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		OX	Enable/disable data logger function	1/0	0=disable 1=enable Default =0
GPS	GPS	C0	GPS always on	1/0	0=disable 1=enable Applicable to all modes except Off mode
		C1	The time for starting to get GPS fix before the next report time if TR-206 does not get GPS fix in last report, or got GPS fix for 1 hour ago	u16, in seconds	60 ~ 600 Note: TR-206 will send out the report whether it gets GPS fix or not when C1 time ends.
		C2	The time for starting	u16, in	10 ~ 120

			to get GPS fix before the next report time if TR-206 got GPS fix within 1 hour	seconds	Note: TR-206 will send out the report whether it gets GPS fix or not when C2 time ends.
		C3	GPS fix time before sending out the first report	u16, in seconds	0 ~ 600 If "C3"=0, disable first report message.
		C7	Choose to use C8 or C9+CA	1/0	0=use C8 1=use C9+CA Applicable for standby, periodic and on-line mode
		C8	Interval for starting to get GPS fix	u16, in seconds	0 ~ 65535 Applicable if C7=0
		C9	Interval for starting to get GPS fix when speed is lower than 10 KM/H	u16, in seconds	0 ~ 65535 Applicable if C7=1 and speed<10 Km/H
		CA	Interval for starting to get GPS fix when speed is higher than 10 KM/H	u32	0 ~ 86400 Applicable if C7=1 and speed>=10 Km/H You have to take the value to divide the speed to get the interval. For example, if you set the value as 54000 and the speed is 60 KM/H. The interval will be 54000/60=900 seconds
Communication	GPRS	D1	APN	char(32)	
		D2	User Name	char(32)	
		D3	Password	char(32)	
		D4	DNS 1	char(32)	
		D5	DNS 2	char(32)	
		D8	GPRS mode for L4 command	Media type	02=TCP 04=UDP
		OR	Shortly click SOS key to make TR-206 connect to server	1/0	0=disable 1=enable
		E0	Host IP or domain	char(32)	

SMS			name		
		E1	Host Port number 1	u16	
		F0	SMS return phone number	char(20)	
		F2	SMS format	1/0	0= Same as GPRS format 1= Text format
		Fa	SMS format 1 report string for ping	char(96)	
		Fb	SMS format 1 report string for SOS alarm	char(96)	
		Fc	SMS format 1 report string for main battery low	char(96)	
		Fd	SMS format 1 report string for geo-fence alarm	char(96)	
		Fe	SMS format 1 report string for periodic mode	char(96)	
		Ff	SMS format 1 report string for online mode	char(96)	
		Fg	SMS format 1 report string for static state of motion mode	char(96)	
		Fh	SMS format 1 report string for moving state of motion mode	char(96)	
		Fi	SMS format 1 report string for changing from static to moving state	char(96)	
		Fj	SMS format 1 report string for changing from moving to static state	char(96)	

		Fk	SMS format 1 report string for high speed alarm	char(96)	
		Fl	SMS format 1 report string for low speed alarm	char(96)	
		Fm	SMS format 1 report string for timer 0	char(96)	
		Fn	SMS format 1 report string for timer 1	char(96)	
		Fo	SMS format 1 report string for timer 2	char(96)	
		Fp	SMS format 1 report string for timer 3	char(96)	
		Fq	SMS format 1 report string for power on	char(96)	
		Fr	SMS format 1 report string for power off	char(96)	
		A0	Send confirmation to server after receiving command from server	1/0	0=disable 1=enable Confirmation message="ACK\r\n"
		A1	Wait confirmation from server after sending message to server	1/0	0=disable 1=enable Confirmation message="ACK\r"
		A2	Timeout of waiting confirmation from server	u8	0~255
		A3	Device Ack with ID string	1/0	0=disable 1=enable
		A4	ID string is IMEI or device ID	1/0	0=Device ID 1=IMEI Available when A3=1
		A5	Enable Simple	1/0	0=disable

			Command		1=enable
Function		F4	Date format (LCD)	u8	dd/mm/yy or mm:dd:yy
		F5	Time format (LCD)	u8	0=12 hour 1=24 hour
		F6	Daylight saving	1/0	1=enable 0=disable
		F7	Auto key lock	1/0	1=enable 0=disable
		F8	Vibrator/beep type	u8	0=vibrator + beep 1=beep 2=vibrator 3=off
		FB	Volume level of ring tone	u8	0=minimum 1=medium 2=maximum 3=progressive Default=1
		FC	Volume level of alarm clock	u8	0=minimum 1=medium 2=maximum 3=progressive Default=1
		FD	Volume level of phone call (headset)	u8	0~6 Default=6
		FE	Melody of ring tone	u8	Default=2
		FF	Power-on melody	u8	Default=1
		OU	Password of simple command and PC utility	Char(16)	
Ⓢ	Ⓢ	G0	SMS Phone number 1	char(20)	

		G1	SMS Phone number 2	char(20)	
		G2	SMS Phone number 3	char(20)	
		G3	SMS Phone number 4	char(20)	
		G4	SMS Phone number 5	char(20)	
		G5	SMS Phone number 6	char(20)	
		H0	Report media	Media Type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		H1	Number of SMS report	u16	1 ~ 65535
		H2	report interval	u16, in seconds	0 ~ 65535 Default=30
		H3	Number of GPRS report	u8	0 =continue sending SOS alarm report till receive stop command
Voice monitor	V4	Voice Monitor call in phone number for voice monitor command	char(20)	G0~G5 are also call in phone number for voice monitor command	
	V5	Allowed interval for call in TR-206 after receiving voice monitor command	u16, in seconds	0 ~ 65535	
	Speed Limit	OI	Upper limit of speed alarm	u8, in Km/h	0 ~ 255 0=disable
		OJ	Lower limit of speed alarm	u8, in Km/h	0 ~ 255 0=disable
		OP	Hysteresis for speed alarm	u8, in Km/h	0 ~ 255
		OL	Report Media for speed alarm	Media type	bit0=SMS bit1=TCP

					bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
	Geo-fence	K0	Geo-fence enable	1/0	0=disable 1=enable
		K3	Geo-fence alarm report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
K4		Report media for reading Geo-fence data	Media type	bit1=TCP bit2=UDP	
Tracking	Ping	OD	Report media for ping	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		OS	GPS fix time between receiving ping command and sending out ping report	u16, in seconds	For N1 command. If OS=0, GPS fix time=C3

	Periodic	P0	Report interval	u32, in seconds	0 ~ 86400
		P2	Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		P3	Traveled distance for sending report	u32, in meters	0 ~86400 0=disable
	On-line	Q0	Report interval	u32, in seconds	0 ~ 86400
		Q2	Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		Q3	Traveled distance for sending report	u32, in meters	0 ~ 86400 0=disable
		E4	Interval in on-line state for disconnecting and then re-connecting	u16, in seconds	0=disable
		E5	Interval for checking if GPRS connection is on-line. If GPRS connection is cut, TR-206 will try to connect to server for one time.	u16, in seconds	0=disable

		E6	Enable/disable TR-206 to send “OK” to server after GPRS connection is re-built.	1/0	0=disable 1=enable Available when E5 is not 0
	Motion	R0	Report interval in static state	u32, in seconds	0 ~ 86400
		R1	Report interval in motion state	u32, in seconds	0 ~ 86400
		R2	Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
		R3	Traveled distance for sending report	u32, in meters	0 ~ 86400 0=disable
		R7	Automatic change from motion mode to on-line mode	1/0	0=disable 1=enable
		R9	Minimum distance to be judged as moving state	u16, in meters	0 ~ 65535
		RB	Keep GPRS on-line in static state	1/0	0=disable 1=enable
		RC	Keep GPRS on-line in moving state	1/0	0=disable 1=enable
		E4	Interval in on-line state for disconnecting and then re-connecting	u16, in seconds	0=disable
		E5	Interval for checking if GPRS connection is on-line. If GPRS	u16, in seconds	0=disable

			connection is cut, TR-206 will try to connect to server for one time.		
		E6	Enable/disable TR-206 to send “OK” to server after GPRS connection is re-built.	1/0	0=disable 1=enable Available when E5 is not 0
		RD	Interval for switching from validation to static state if no motion detected	u16, in seconds	0=Interval is the same with R1
		RE	Traveled distance to be judged as keep in moving state	u16, Unit: meter	
		RF	Interval for switching from moving to static state if no motion detected	u16, in seconds	0=Interval is the same with R1
		RG	Check GPS off time setting (C7, C8, C9, CA	1/0	0=disable 1=enable
		RH	GPS always on in moving state	1/0	0=disable 1=enable
		RI	Report Media for changing from static to moving	Media type	
		RJ	Report Media for changing from moving to static	Media type	
Timer	Timer 0	W0	Start time	u32, in seconds	0 ~ 86400
		W1	End time	u32, in seconds	0 ~ 86400
		W2	Report interval	u16, in seconds	0 ~ 65535

		W3	Weekday mask	u8, xx(hex digits)	00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
		W4	Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
	Timer 1	X0	Start time	u32, in seconds	0 ~ 86400
		X1	End time	u32, in seconds	0 ~86400
		X2	Report interval	u16, in seconds	0 ~ 65535
		X3	Weekday mask	u8, xx(hex digits)	00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
		X4	Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on

	Timer 2	Y0	Start time	u32, in seconds	0 ~ 86400
		Y1	End time	u32, in seconds	0 ~ 86400
		Y2	Report interval	u16, in seconds	0 ~ 65535
		Y3	Weekday mask	u8, xx(hex digits)	00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
		Y4	Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
	Timer 3	Z0	Start time	u32, in seconds	0 ~ 86400
		Z1	End time	u32, in seconds	0 ~ 86400
		Z2	Report interval	u16, in seconds	0 ~ 65535
		Z3	Weekday mask	u8, xx(hex digits)	00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
		Z4	Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0]

					bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
Alarm Clock	Alarm Clock 1	XA	Melody of alarm clock 1	u8	
		XB	Alarm time of alarm clock 1	u32, in seconds	0 ~ 86400
		XC	Type of alarm clock 1		0=disable 1=once 2=daily 3=weekly (XD must be set)
		XD	Weekday mask of alarm clock 1	u8, xx(hex digits)	Available when XC=3 00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
		XE	Prompt message of alarm clock 1	Char(16)	
	Alarm Clock 2	YA	Melody of alarm clock 2	u8	
		YB	Alarm time of alarm clock 2	u32, in seconds	0 ~ 86400
		YC	Type of alarm clock 2		0=disable 1=once 2=daily 3=weekly (YD must be set)

		YD	Weekday mask of alarm clock 2	u8, xx(hex digits)	Available when ZC=3 00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
		YE	Prompt message of alarm clock 2	Char(16)	
	Alarm Clock 3	ZA	Melody of alarm clock 3	u8	
		ZB	Alarm time of alarm clock 3	u32, in seconds	0 ~ 86400
		ZC	Type of alarm clock 3		0=disable 1=once 2=daily 3=weekly (ZD must be set)
		ZD	Weekday mask of alarm clock 3	u8, xx(hex digits)	Available when ZC=3 00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
		ZE	Prompt message of alarm clock 3	Char(16)	
	Phone	VA~VT	Phone number of phone book	Char(20)	

		Va~Vt	Contacts of phone book	Char(24)	
--	--	--------------	---------------------------	----------	--

Preliminary

2.8 Command's Codeword

Command's Codeword		
Codeword	Parameters	Description
M7	Set Standby Mode	
M2	Set Periodic Mode	
M3	Set On-Line mode	
M4	Set Motion mode	
M8	Set Off mode	
N0	Set Timer	
N1	Ping device	
N2	Trigger vibration	
N4	Enable Voice Monitor	
N6	Enable Geo-fence	
N7	Disable Geo-fence	
N8	Enable Data logger	
N9	Disable Data logger	
Na	Dismiss SOS alarm	
Ne	Dismiss Geo-fence alarm	
Nh	Dismiss low battery alarm	
Ni	Dismiss All alarm	
L1	Read Configuration	Adding up to 1-5 parameters. If parameter=(ALL), then all user configuration data will be reported.
L3	Read Geo-fence	
L4	Make TR-206 connect to Server	
L5	Disconnect from Server	
LA	Restore default configuration	Restore all parameters to factory value (W) for writing current configuration to default setting.

LC	Clear data logger	
LH	Re-Set device	

Preliminary

2.9 Report Media

Report media is the method that TR-206 sends report. No matter you send the command by SMS or TCP or UDP, TR-206 will send the report via the report media.

Report Media	Media type	bit0=SMS bit1=TCP bit2=UDP bit6=Action[0] bit7=Action[1] Action=00: report format 0 Action=01: report format 1 Action=10: GPS on
--------------	------------	---

	Action		Media Type					
bit	7	6	5	4	3	2=UDP	1=TCP	0=SMS
Ex 1: TCP	0	0	0	0	0	0	1	0
Ex 2: UDP	0	1	0	0	0	1	0	0
Ex 3: GPS on	1	0	0	0	0	0	0	0

Example 1: Ask TR-206 to send on-line report with report interval of 5 minutes (Q0=300) and report format 0 to TCP server (Q2=02).

GSC,011412000010789,M3(Q0=300,Q2=02)*07!

Example 2: Ask TR-206 to enter motion mode with static report interval of 7 minutes (R0=420) and moving report interval of 40 seconds (R1=40), report format 1 to UDP server (R2=44).

GSC,011412000010789,M4(R0=420,R1=40,R2=44)*71!

Example 3: Set Timer 1 to turn on GPS without sending report (X4=80), Start time: 09:00 AM (X0=32400), End time: 06:00 PM (X1=64800), Report interval: 1 hour (X2=3600), Report day: from Monday ~Friday (X3=3E)

GSS,011412000012789,3,0,X0=32400,X1=64800,X2=3600,X3=3E,X4=80*53!

2.10 Checksum

The checksum value is derived by the same method of NMEA standard. It is calculated by 'exclusive OR' the 8 data bits of each character before "*" in the sentence, but excluding "*". The hexadecimal value of the most significant and least significant 4 bits of the result are converted to two ASCII characters (0-9, A-F) for transmission. The most significant character is transmitted first.

Example1: set the device whose IMEI is 011412000011274, the APN is internet, the user name and password are not necessary, the server type is TCP, the server IP is 220.128.207.75, the server port number 3000.

The setup command is

GSS,011412000011274,3,1,D1=internet,D2=,D3=,D8=02,E0=220.128.207.75,E1=3000*5E!

The checksum is 5E.

Example2: Set TR-206 periodic report and ask it to report based on traveled distance (P3) of 500 meters

The setup command is

GSC,011412000010789,M2(P3=500)*72!

The checksum is 72.

3 Configuration

You could read or set TR-206 configuration parameters by USB, SMS, TCP, UDP communication protocol.

3.1 Read parameters of configuration

Command's format:

GSC,IMEI,L1(x1,x2,x3,x4,x5)*Checksum!

GSC,IMEI,L1(ALL)*Checksum!

Add up to 1-5 parameters.

If parameter =(ALL), then all user configuration data will be generated.

Report format:

GSs,IMEI,T,S,x1=y1,x2=y2,x3=y3,.....*Checksum!

x1,x2,x3... are code words for configuration parameters.

y1,y2,y3... are their respective settings.

Example 1:

Ask TR-206 report parameters of Motion mode(R0,R1,R2,R3)

GSC,136489586301578,L1(R0,R1,R2,R3)*35!

Report parameters R0,R1,R2 and R3 form TR-206

GSs,136489586301578,3,0,R0=3600,R1=30,R2=02,R3=0*4E!

Example 2:

Ask TR-206 report all parameters

GSC,135485956301257,L1(ALL)*5C!

Report all parameters from TR-206

GSs,135485956301257,1,0,O5=TR206,O7=F-ORT-206-08120421.
0.0.0.0,O6=28800,O4=7,B0=,B1=,B2=,I2=1,J0=20,J1=15,J6=02*0
2!

GSs,135485956301257,0,1,O1=5,O3=STRPAB27GHKLMN*U!,ON
=SPAN*!,OO=02,C0=0,C1=300,C2=30,C3=10*18!

GSs,135485956301257,0,2,D1=,D2=,D3=,D4=,D5=,D6=1,E0=,E1=
5000,F0=,F1=5,A0=1,A1=0,A2=5,A3=0,A4=1*02!

GSs,135485956301257,0,3,G0=,G1=,G2=,G3=,G4=,G5=,H0=02,H
1=3,H2=30,V1=600,V0=1,V4=,V5=300*13!

GSs,135485956301257,0,4,T0=3600,T1=30,T2=02,T3=0,U0=3600,
U1=30,U3=02,OI=100,OJ=60,OL=02,OP=5,OQ=30*2C!

GSs,135485956301257,0,5,K3=02,K4=02,K5=30,OD=02,P0=60,P
2=02,P3=0,Q0=60,Q2=02,Q3=0*0A!

GSs,135485956301257,0,6,R0=3600,R1=180,R2=02,R3=0,W0=0,
W1=86400,W2=60,W3=40,W4=02*0D!

GSs,135485956301257,2,7,Y0=,Y1=,Y2=3600,Y3=,Y4=02,Z0=,Z1=
,Z2=30,Z3=,Z4=02,X4=02,Z0=,Z1=,Z2=30,Z3=,Z4*43!

3.2 Set parameters of configuration

Commands format:

GS**S**,IMEI,T,S,x1=y1,x2=y2,x3=y3,.....,*Checksum!

x1,x2,x3... are code words for configuration parameters.

y1,y2,y3... are their respective settings.

Example 1:

Set parameters of GPRS setting (D1,E0,E1)

Codeword	Parameters	Value
D1	APN	Internet
E0	Host IP 1	201.89.56.207
E1	Host Port number 1	5000

GSS,138785469589531,3,0,D1=internet,E0=201.89.56.207,E1=5000*01!

Example 2:

Set parameters of Timer 1: Start time: 09:00 AM (X0=32400), End time: 06:00 PM (X1=64800), Report interval: 1 hour (X2=3600), Report day: from Monday ~Friday (X3=3E)

GSS,011412000012789,3,0,X0=32400,X1=64800,X2=3600,X3=3E*26!

4 GSM & GPRS

4.1 GPRS Setting

In order to activate the communication between server and device, the GPRS parameter is necessary to set at the beginning. The GPRS parameters are included as the table below. Please contact with your telecom operator for the APN, user name, and password. Please contact your ISP provider for DNS1 and DNS2.

GPRS	D1	APN	char(32)	
	D2	User Name	char(32)	
	D3	Password	char(32)	
	D4	DNS 1	char(32)	
	D5	DNS 2	char(32)	
	D8	GPRS mode for L4 command	Server type	02=TCP 04=UDP
	E0	Host IP 1 or domain name	char(32)	
	E1	Host Port number 1	u16	

Note:

1. If user name and password are not necessary for your telecom operator, please keep D2 and D3 blank.
2. If the value of E0 is IP, you do not have to set D4 and D5. Please skip the fields.

The setup format of GPRS setting is “**GSS,IMEI,T,S,D1=y1,D2=y2,D3=y3,D4=y4, D5=y5, D8=y6,E0=y7,E1=y8,*Checksum!**”

For example, set the device whose IMEI is 011412000010789, the APN is internet, the user name and password are not necessary, the server type is TCP, the server IP is 220.128.207.75, the server port number 5000.

The setup command is

GSS,011412000010789,3,1,D1=internet,D2=,D3=,D8=02,E0=220.128.207.75,E1=5000 *78!

4.2 Acknowledgement

Acknowledgement is the acknowledge receipt used to confirm if server or device receive the command or report from each other.

The following parameters must be set for configuration or sending those parameters by other action command for enable/disable acknowledgement.

Code word	Parameters	Value	Description
A0	Send confirmation to server after receiving command from server	1/0	Confirmation message="ACK\r\n" when A3=0 When A3=1, A4=1, confirmation message="IMEI, ACK\r\n" When A3=1,A4=0, confirmation message="Device ID, ACK\r\n"
A1	Wait confirmation from server after sending message to server	1/0	Confirmation message="ACK\r"
A2	Timeout of waiting confirmation from server	u8	0~255
A3	Device Ack with ID string	1/0	
A4	ID string is IMEI or device ID	1/0	1=IMEI, 0=Device ID Available when A3=1

For example, set A0=1, A1=1, A3=1, A4=1, server sends command to TR-206 whose IMEI is 011412000010789.

After receiving the command, TR-206 will send acknowledgement receipt as "011412000010789,ACK\r\n"

For example, set A0=1, A1=1, A3=1, A4=0, TR-206 whose device ID is Globalsat, sends report to server.


After receiving the command, TR-206 will send acknowledgement receipt as
“Globalsat,ACK\r\n”

For example, set A0=1, A1=1, A3=0, server sends command to TR-206


After receiving the command, TR-206 will send acknowledgement receipt as
“ACK\r\n”

4.2.1 Receive Acknowledgement from Server

Receive ACK from server during “A2” time:




Not receive ACK from server during “A2” time:




4.2.2 Respond Acknowledgement to Server

Receive report commands from server:



Receive other commands from server:



5 GPS

In the general tracking modes, TR-206 will turn on GPS.

There are some conditions that you have to extra make GPS on.

1. Report based on traveled distance in the periodic mode, on-line mode, motion mode
2. Speed limit
3. Geo-fence mode
4. Data Logger

There are two ways for turning on GPS, one is to keep GPS always on by parameter C0, and the other is to use timer. Keep GPS always on will make the power run up within 10 hours.

The recommended method of making GPS on is to use timer.

While using timer, you could set the report media (X4 or Y4 or Z4) as 80, then TR-206 will turn on the GPS according to the report interval (X2 or Y2 or Z2)

Note:

Using timer to turn on GPS, TR-206 does not turn on GPS all the time during the period from Start Time (X0 or Y0 or Z0) to End Time (X1 or Y1 or Z1). GPS is turn on according to the report interval (X2 or Y2 or Z2) during the period from Start Time to End Time.

For the details of setting timer, please refer to chapter “10 Timer.”

Code word	Parameters	Value	Description
C0	GPS always on	1/0	0=disable 1=enable Applicable to all modes except Off mode
C1	The time for starting to get GPS fix before the next report time if TR-206 does not get GPS fix in last report, or got GPS fix	u16, in seconds	60 ~ 600 Note: TR-206 will send out the report whether it gets GPS fix or not when C1 time ends.

	for 1 hour ago		
C2	The time for starting to get GPS fix before the next report time if TR-206 got GPS fix within 1 hour	u16, in seconds	10 ~ 120 Note: TR-206 will send out the report whether it gets GPS fix or not when C2 time ends.
C3	GPS fix time before sending out the first report	u16, in seconds	0 ~ 600 If "C3"=0, disable first report message.
C7	Choose to use C8 or C9+CA	1/0	0=use C8 1=use C9+CA Applicable for standby, periodic and on-line mode
C8	Interval for starting to get GPS fix	u16, in seconds	0 ~ 65535 Applicable if C7=0
C9	Interval for starting to get GPS fix when speed is lower than 10 KM/H	u16, in seconds	0 ~ 65535 Applicable if C7=1 and speed<10 Km/H
CA	Interval for starting to get GPS fix when speed is higher than 10 KM/H	u32	0 ~ 86400 Applicable if C7=1 and speed>=10 Km/H You have to take the value to divide the speed to get the interval. For example, if you set the value as 54000 and the speed is 60 KM/H. The interval will be 5400/60=900 seconds
RH	GPS always on in moving state	1/0	0=disable 1=enable

C7, C8, C9, and CA is for speeding up the time of getting GPS fix if you set a long report interval in stand-by, periodic and on-line mode. Between the long report interval, C7, C8, C9, and CA will make TR-206 get GPS fix. Then TR-206 can speed up the time of getting GPS fix at the next report.

C1 example, the next report time is 10:00 AM and TR-206 does not get GPS fix in last report, C1 is 180 seconds. TR-206 will start to get GPS fix at 9:57 AM and send out report at 10:00

C2 example, the next report time is 10:00 AM and TR-206 got GPS fix within 1 hour, C2 is 20 seconds. TR-206 will start to get GPS fix at 9:59:40 AM and send out report at 10:00

C3 example, C3=120 seconds, TR-206 is in the motion mode. When TR-206 is moved, it will try to get GPS fix for 120 seconds before sending motion moving report.

Preliminary

6 Tracking

6.1 Ping

Ping is for getting the present location of TR-206 immediately. TR-206 will report its present location and concerning information when getting the ping command.

You can ping TR-206 by L4 command or by N1 command.

The parameters of ping:

Code word	Parameters	Value	Description
D8	Report Media for L4	02=TCP 04=UDP	The connecting method for TR-206 to connect to server after receiving "L4" command.
OD	Report media for ping (N1)		Please refer to 2.9 Report media
OS	GPS fix time between receiving ping command and sending out ping report	u16, in seconds	If OS=0, GPS fix time=C3
C3	GPS fix time before sending out the first report	u16, in seconds	0 ~ 600 If "C3"=0, disable first report message.

Commands format:

GSC,IMEI,N1*Checksum!

Command Codeword	Parameters
N1	Ping device
L4	Connect to server

Example 1:

Ping TR-206 location and ask it to report via SMS (Send command via SMS or TCP or UDP)

GSC,135785412249986,N1(OD=01)*2C!

Preliminary

6.2 Periodic Mode

Periodic mode is for setting an interval for TR-206 to regularly report its location according to the interval. When it reaches the report time, TR-206 will turn on GPS and GPRS connection and report the location and concerning information to server. After sending the information, TR-206 will disconnect from server.

Note of Traveled Distance:

You can also set a traveled distance, and then TR-206 will report by the combination of report interval and traveled distance.

For example, the report interval is 60 seconds, the traveled distance is 800 meters, TR-206 sends 1 report at 10:00:00, and then it detects the traveled distance is over 800 meters at 10:00:50, it will send out one report and re-start to count the report interval and the traveled distance. The next report will be sent out at 10:01:50 or when the traveled distance is over 800 meters.

The parameters of periodic mode:

Code word	Parameter	Value	Description
P0	Report interval	1~86400 seconds	
P2	Report Media		Please refer to 2.9 Report media
P3	Traveled distance for sending report	0=disable 1~1000000 Unit: meter	If you want TR-206 to send reports according to traveled distance, you have to extra make GPS on. Please refer to "Chapter 4 GPS."

Commands format:

GSC,IMEI,M2*Checksum!

Command Codeword	Parameter
M2	Set periodic mode

Example 1:

Set TR-206 periodic report and ask it to report based on traveled distance (P3) of 500 meters (Send command via SMS or TCP or UDP), turn on GPS by timer 1: Start time:12:00 AM (X0=0), End time:12:00 AM (X1=86400), Report interval:30 seconds (X2=30), Report time: From Monday to Sunday (X3=7F), GPS on (X4=80)

GSC,011412000010789,M2(P3=500,X0=0,X1=86400,X2=30,X3=7F,X4=80)*7F!

Note: You have to turn GPS on. Please refer to chapter 5 GPS.

Example 2:

Set TR-206 periodic report and ask it to report based on report interval (P0) of 30 seconds

GSC,135785412249986,M2(P0=30)*45!

6.3 On-Line Mode

In On-Line mode, TR-206 will keep GPRS connection. If TR-206 detects the GPRS connection is cut, it will try to connect to server for one time. If it cannot connect to server, it will re-connect to server when the next report time.

Some telecom operator will kick off the continual GPRS connection. So you could make GPRS connection cut and then make the GPRS connection again according to a regular interval by parameter E4. If E4=0, TR-206 will not cut GPRS connection and then connect again. It will keep GPRS connection. You could also make TR-206 to check if GPRS connection is on-line according to a regular interval by parameter E5. If GPRS connection is cut, TR-206 will try to connect to server for one time.

Note of Traveled Distance:

You can also set a traveled distance, and then TR-206 will report by the combination of report interval and traveled distance.

For example, the report interval is 60 seconds, the traveled distance is 800 meters, TR-206 sends 1 report at 10:00:00, and then it detects the traveled distance is over 800 meters at 10:00:50, it will send out one report and re-start to count the report interval and the traveled distance. The next report will be sent out at 10:01:50 or when the traveled distance is over 800 meters.

You can also set a traveled distance, and then TR-206 will report by the combination of report interval and traveled distance.

You could define the content of report and the report interval of on-line mode.

The parameters of On-Line mode:

Code word	Parameters	Value	Description
Q0	Report interval	1~86400 seconds	
Q2	Report Media		Please refer to 2.9

			Report media
Q3	Traveled distance for sending out report	0=disable 1~1000000 Unit: meter	If you want TR-206 to send reports according to traveled distance, you have to extra make GPS on. Please refer to "Chapter 4 GPS."
E4	Interval in on-line state for disconnecting and then re-connecting	u16, in seconds	
E5	Interval for checking if GPRS connection is on-line. If GPRS connection is cut, TR-206 will try to connect to server for one time.	u16, in seconds	0=disable
E6	Enable/disable TR-206 to send "OK" to server after GPRS connection is re-built.	1/0	0=disable 1=enable Available when E5 is not 0

Commands format:

GSC,IMEI,M3*Checksum!

Command Codeword	Parameters
M3	On-line mode

Example 1:

Ask TR-206 on-line report (Send command via SMS or TCP or UDP)

GSC,130158974523157,M3*1A!

Example 2:

**Ask TR-206 set on-line report with interval of 60 seconds and
report by UDP**


GSC,011412000010789,M3(Q0=60,Q2=04)*34!

Preliminary

6.4 Motion Mode

Motion mode is an economic report mode. Under motion mode, TR-206 will report its location with high frequency when TR-206 detects motion (moving state). When TR-206 is static, it will report its location with low frequency (static state). It can save the report-transmission fee. Between the moving state and static state, there is a validation state for TR-206 not to jump to static state as soon as it does not detect motion. You could set TR-206 keep in moving state by setting a traveled distance (RE) within a defined interval (RF).

There are 2 report frequency of motion mode, one is when TR-206 detects motion, and the other is when TR-206 is static. The behavior is as following:



①	Receive command and then enter motion static mode.
②	When TR-206 detects motion, it will enter motion moving mode and send "static to moving" report.
③	Motion Moving Report.
④	When TR-206 is static, it will send "moving to static" report and then return to the motion static mode.
⑤	Re-start timer for motion static interval.
⑥	Motion Static Report.

Note of Traveled Distance:

You can also set a traveled distance, and then TR-206 will report by the combination of report interval and traveled distance.

For example, the report interval is 60 seconds, the traveled distance is 800 meters, TR-206 sends 1 report at 10:00:00, and then it detects the traveled distance is over 800 meters at 10:00:50, it will send out one report and re-start to count the report interval and the traveled distance. The next report will be sent out at 10:01:50 or when the traveled distance is over 800 meters.

You could define the content of report and the report interval of motion mode.

If you want to save the battery power, you could turn off GSM module in static state by making parameter RA=1.

In motion mode, TR-206 will make GPRS connection while sending static or moving report. After sending report, it will cut the GPRS connection. If you want to keep GPRS on-line, you could set RB=1 to keep GPRS on-line in static interval and set RC=1 to keep GPRS on-line in moving interval. Some telecom operator will kick off the continual GPRS connection. So you could make GPRS connection cut and then make the GPRS connection again according to a regular interval by parameter E4. You could also make TR-206 to check if GPRS connection is on-line according to a regular interval by parameter E5. If GPRS connection is cut, TR-206 will try to connect to server for one time.

In order to avoid TR-206 jump to static state as soon as it does not detect motion, you could set TR-206 keep in moving state by setting a traveled distance (RE) within a defined interval (RF).

The parameters of motion mode:

Code word	Parameters	Value	Description
R0	Report interval in static state	1~86400 seconds	
R1	Report interval in moving state	1~86400 seconds	
R2	Report Media		Please refer to 2.9 Report media
R3	Traveled distance for sending report	0=disable 1~1000000 Unit: meter	If you want TR-206 to send reports according to traveled distance, you have to extra make GPS on. Please refer to "Chapter 4 GPS."
R7	Automatic change from	1/0	0=disable

	motion mode to on-line mode when TR-206 does not detect motion		1=enable
R9	Minimum distance to be judged as moving state	u16, Unit: meter	0 ~ 65535
RB	Keep GPRS on-line in static state	1/0	0=disable 1=enable
RC	Keep GPRS on-line in moving state	1/0	0=disable 1=enable
E4	Interval in on-line state for disconnecting and then re-connecting	u16, in seconds	0=disable
E5	Interval for checking if GPRS connection is on-line. If GPRS connection is cut, TR-206 will try to connect to server for one time.	u16, in seconds	0=disable
E6	Enable/disable TR-206 to send "OK" to server after GPRS connection is re-built.	1/0	0=disable 1=enable Available when E5 is not 0
RD	Interval for switching from validation to static state if no motion detected	u16, in seconds	0=Interval is the same with R1
RE	Traveled distance to be judged as keep in moving state	u16, Unit: meter	
RF	Interval for switching from moving to static state if no motion detected	u16, in seconds	0=Interval is the same with R1
RG	Check GPS off time setting (C7, C8, C9, CA)	1/0	0=disable 1=enable
RH	GPS always on in moving state	1/0	0=disable 1=enable

Commands format:

GSC,IMEI,M4*Checksum!

Commands Codeword

Parameters

M4	Set motion mode
----	-----------------

Example 1:

Ask TR-206 set motion report (Send command via SMS or TCP or UDP)

GSC,136639674520921,M4*1E!

Example 2:

Set TR-206 motion mode with report interval of 3600 seconds for static state (R0), report interval of 30 for moving state (R1) and report media (R2) TCP

GSC,130158974523157,M4(R0=3600,R1=30,R2=02)*44!

7. Alert

7.1 Emergency


When SOS (Emergency) button is long pressed, TR-206 will send its location information to 6 sets of phone numbers by SMS or send its location information to server via TCP or UDP.

The parameters emergency:


Code word	Parameters	Value	Description
G0	SMS Phone number 1	char(20)	
G1	SMS Phone number 2	char(20)	
G2	SMS Phone number 3	char(20)	
G3	SMS Phone number 4	char(20)	
G4	SMS Phone number 5	char(20)	
G5	SMS Phone number 6	char(20)	
H0	Report media		Please refer to 2.9 Report media Default: report to GS-TRAQ website and SMS
H1	Number of SMS Report	u16	1 ~ 65535
H2	report interval	0~3600 seconds	
H3	Number of GPRS Report	u8	0=continue sending SOS alarm report till receive stop command

7.2 Speed Limits

High Speed Limit



Low Speed Limit



The parameters of speed alarm:

Code word	Parameters	Value
OI	Upper limit of speed alarm	u8, in Km/H 0 ~ 255 Km/H 0=disable
OJ	Lower limit of speed alarm	u8, in Km/H 0 ~ 255 Km/H 0=disable
OL	Report media for speed alarm	Please refer to 2.9 Report media
OP	Hysteresis of speed alarm	u8, in Km/H 0 ~ 255 Km/H

7.2.1 Enable Speed Limit Alert

Example 1:

Set upper limit of speed alert (Send command via SMS or TCP or UDP)


GSS,10339376540375,3,0,OI=105,OP=5,OL=02*6A!

Command Type	Description
GSS	Write setting to device

Code word	Parameters	Value	Description
OI	Upper limit of speed alarm	105	Set upper limit: 105 Km/h
OL	Report media for speed alarm	02	Report alarm messages via TCP. Alarm messages

			format: Format 0
OP	Hysteresis of speed alarm	5	

The behavior mode is as following:



Example 2:


Set lower limit of speed alert (Send command via SMS or TCP or UDP)

GSS,10339376540375,3,0,OJ=65,OP=5,OL=02,*5E!

Command Type	Description
GSS	Write setting to device

Code word	Parameters	Value	Description
OJ	Upper limit of speed alarm	65	Set lower limit: 65 Km/h
OL	Report media for speed alarm	02	Report alarm messages via TCP. Alarm messages format: Format 0
OP	Hysteresis of speed alarm	5	

The behavior mode is as following:



7.2.2 Disable Speed Limit Alert

Example 1:

Disable upper limit of speed alert (Send command via SMS or TCP or UDP)

GSS,10339376540375,3,0,OI=0*45!

Command Type	Description
GSS	Write setting to device

Code word	Parameters	Value	Description
OI	Upper limit of speed alarm	0	0=disable

Example 2:

Disable lower limit of speed alert (Send command via SMS or TCP or UDP)

GSS,10339376540375,3,0,OJ=0*46!

Command Type	Description
GSS	Write setting to device

Code word	Parameters	Value	Description
OI	Lower limit of speed alarm	0	0=disable

7.3 Geo-fence

Geo-fence is for setting a rectangular area as permissible area or restricted area. When TR-206 gets out of the permissible area or goes in to the restricted area, TR-206 will send its location to the preset mobile phone number via SMS or to server via TCP or UDP.






You can set up to 64 sets of geo-fence areas.

After setting all sets of geo-fence areas, you could change one or several of the geo-fence area setting. You do not have to set all the geo-fence areas again. For example, after you set 10 sets of geo-fence areas. You could change the 7th geo-fence area setting independently.


You could disable any one of the previously set geo-fence area by setting it again and change the alert type to be 0.

The behavior is as following:

The behavior is as following:

Alert type of Geo-fence				
1	2	3	4	5
Get in area	Get out of area	Cross over the boundary	Stay in area	Stay out of area
				

(upper_left_Lon,upper_left_Lat)








(right_bottom_Lon,right_bottom_Lat)

7.3.1 Setup Geo-fence

Command's format for set Geo-fence:

GSG,IMEI,T,S,1=(type,upper_left_Lon,upper_left_Lat,right_bottom_Lon,right_bottom_Lat[,StartTime,EndTime,weekday]),2=(...),3=(...),...*Checksum!

Format	Value	Note
GSG	"GSG" : Write geo-fence parameter command	Command head
IMEI	(The IMEI number)	GSM device ID
T	'0' : Middle of message '1' : Start of message '2' : End of message '3' : Start and End of message, i.e., only one packet for message '5' : Erase all of the previously set geo-fence areas + start of message (when you need to set new geo-fence areas by more than 1 message) '7' : Erase all of the previously set geo-fence areas + start and end of message (when you need to set new geo-fence areas by only 1 message)	Message packet control
S	'0','1','2','3',...,'9','10','11',...,'63'	Sequence number
type	0=disable that area 1=get in area  2=get out of area 	Alert type of Geo-fence

	<p>3=cross over the boundary</p>  <p>4=stay in area</p>  <p>5=stay out of area</p> 	
upper_left_Lon, upper_left_Lat	<p>upper_left_Lon =Lon upper_left_Lat =Lat</p> <p>Lon: (+ or -)ddddddddd unit: 0.000001 degree Lat: (+ or -)ddddddddd unit: 0.000001 degree</p>	The top left coordinates of specified area
right_bottom_Lon, right_bottom_Lat	<p>right_bottom_Lon =Lon right_bottom_Lat =Lat</p> <p>Lon: (+ or -)ddddddddd unit: 0.000001 degree Lat: (+ or -)ddddddddd unit: 0.000001 degree</p> <p>Example: 12129141 12129141 x0.000001 =12.129141degree</p>	The right bottom coordinates of specified area
Start Time	<p>0~86400 sec</p> <p>Example: 00:00:01 = 1 23:59:59 = 86399</p>	Optional field for specifying time frame of this geo-fence area. Start Time and end Time are in seconds.

End Time	0~86400 sec Example: 00:00:01 = 1 23:59:59 = 86399	Optional field for specifying the frame of this geo-fence area. Start Time and end Time are in seconds.
weekday	bit0=Sunday bit1=Monday bit2=Tuesday bit3=Wednesday bit4=Thursday bit5=Friday bit6=Saturday	Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
*	*	End of field
Checksum	The checksum value is derived by the same method of NMEA standard. It is calculated by ‘exclusive OR’ the 8 data bits of each character before “*” in the sentence, but excluding “*”. The hexadecimal value of the most significant and least significant 4 bits of the result are converted to two ASCII characters (0-9, A-F) for transmission. The most	

	significant character is transmitted first.	
!	!	Message delimiter

You can set up to 64 sets of geo-fence areas.

Example 1:

Set up 52nd ~57th sets of geo-fence areas

GSG,130738902846156,1,0,52=(2,121752441,24756536,121752924,24755863),53=(2,121743236,24748254,12174845,24744844)*78!

GSG,130738902846156,0,1,54=(1,121758267,24786053,121760745,24784397),55=(3,160053272,24144678,160056791,2414037)*73!

GSG,130738902846156,2,2,56=(1,160080072,24161526,160080866,24160439),57=(2,160075888,2410602,120722923,2406402)*47!

Disable the 56th set of geo-fence (by setting the alert type to be 0)

GSG,130738902846156,3,0,56=(0,160080072,24161526,160080866,24160439)*61!

Erase 52nd ~57th sets of geo-fence areas and set 2 geo-fence areas

GSG,130738902846156,7,0,1=(1,12146435,25009979,121466711,25008423),2=(1,121471624,25012487,121474736,25010756)*7C!

Erase 52nd ~57th sets of geo-fence areas and set 3 geo-fence areas

GSG,130738902846156,5,0,1=(1,12146435,25009979,121466711,25008423),2=(1,121471624,25012487,121474736,25010756)*7E!

GSG,130738902846156,2,1,3=(1,123479371,28016629,123148068,28015657)*55!

Example 2:

Set up 1st ~10th sets of Geo-fence areas

GSG,132763902812736,1,0,1=(1,121305521,24999088,121308246,24997649,00,86400,7f),2=(1,121302452,25004397,121305285,25002842)*0A!

GSG,132763902812736,0,1,3=(1,121299427,25014101,121302345,25012545),4=(1,121301723,25022909,121305306,25021101)*4F!

GSG,132763902812736,0,2,5=(1,12146435,25009979,121466711,25008423),6=(1,121471624,25012487,121474736,25010756)*54!

GSG,132763902812736,0,3,7=(1,121479371,25016629,12148068,25015657),8=(1,121547295,25043931,121548105,25043547)*7C!

GSG,132763902812736,2,4,9=(1,121536984,25049913,121538894,25048514),10=(1,121539195,25055901,121540675,25054773)*78!

change the 7th set of geo-fence area

GSG,132763902812736,3,0,7=(1,123479371,28016629,123148068,28015657)*5C!

Command's format for read Geo-fence:

GSC,L3(1~64)*Checksum!

Commands Codeword	Parameters
L3	Read Geo-fence

Example 1:

Ask TR-206 report the parameters of 1st ~10th Geo-fence area

The method of marking 1st ~10th geo-fence areas is to write 1~10 in the braces after L3, like L3 (1-10)

GSC,132763902812736,L3(1-10)*04!

Report format for read Geo-fence:

GSg,IMEI,T,S,1=(type,upper_left_Lon,upper_left_Lat, right_bottom_Lon,right_bottom_Lat[,StartTime,EndTime,weekday]),2=(...),3=(...),...*Checksum!

About the parameters of reading geo-fence, please refer to the parameters of setting geo-fence.

Example 1:

Report 1~10 coordinates of Geo-fence

GSg,132763902812736,1,0,1=(1,121305521,24999088,121308246,24997649,00,86400,7F),2=(1,121302452,25004397,121305285,25002842,00,86400,7F)*6D!

GSg,132763902812736,0,1,3=(1,121299427,25014101,121302345,25012545,00,86400,7F),4=(1,121301723,25022909,121305306,25021101,00,86400,7F)*6F!

GSg,132763902812736,0,2,5=(1,12146435,25009979,121466711,25008423,00,86400,02),6=(1,121471624,25012487,121474736,25010756,00,86400,02)*54!

GSg,132763902812736,0,3,7=(1,121479371,25016629,12148068,25015657,00,86400,02),8=(1,121547295,25043931,121548105,25043547,00,86400,02)*5C!

GSg,132763902812736,2,4,9=(1,121536984,25049913,121538894,25048514,00,86400,04),10=(1,121539195,25055901,121540675,25054773,00,86400,04)*58!

7.3.2 Enter Geo-fence Alert

Geo-fence is independent from the other general tracking modes. Sending geo-fence command to TR-206 will not stop the other general tracking modes. TR-206 could execute general tracking mode and geo-fence at the same time

In geo-fence mode, it requires extra to turn on GPS on.

There are two ways for turning on GPS, one is to keep GPS always on by parameter C0, and the other is to use timer. Keep GPS always on will make the power run up within 10 hours.

The recommended method of making GPS on is to use timer.

While using timer, you could set the report media (X4 or Y4 or Z4) as 80, then TR-206 will turn on the GPS.

Code word	Parameters	Value	Description
C0	GPS always on	1/0	Applicable to all modes except Off mode
X0	Start time	u32, in seconds	
X1	End time	u32, in seconds	
X2	Report interval	u16, in seconds	
X3	Weekday mask	u8, xx(hex digits)	
X4	Report Media		Please refer to 2.9 Report media

Command's format for enable Geo-fence:

GS**C**,N6*Checksum!

Commands Codeword	Parameters
N6	Enable Geo-fence

Example 1:

Asking TR-206 enter geo-fence alert state and make GPS always on (C0=1)

GSC, 135097652783615,N6(C0=1)*47!

Example 2:

Asking TR-206 enter geo-fence alert state and use timer 1: Start Time: 12:00AM (X0=0), End Time:11:59PM(X1=86399), Report Interval=0 (X2=0), Weekday: Sunday~ Saturday (X3=7f), Report Media: GPS ON(X4=80)

GSC,011412000010789,N6(X0=0,X1=86399,X2=0,X3=7f,X4=82)
*29!

7.3.3 Dismiss Geo-fence Alarm

TR-206 would send out only one geo-fence alarm report when it violates the geo-fence rule. If you set the alert type of geo-fence as “stay in area” (type 4) or “stay out of area” (type 5), you could dismiss the geo-fence alarm to check if TR-600 still stay in the geo-fence area or stay out of the area. After dismissing the geo-fence alarm, if TR-206 still stay in the geo-fence area or stay out of the area, TR-206 would send out alarm report again.

Command's format for dismiss Geo-fence alarm status:

GSC,Ne*Checksum!

Commands Codeword	Parameters
Ne	Dismiss Geo-fence Alarm

Example 1:

Dismiss TR-206 geo-fence alarm status

GSC,135097652783615,Ne*6A!

7.3.4 Stop Geo-fence Alert

Command's format for disable Geo-fence:

GSC,N7*Checksum!

Commands Codeword	Parameters
N7	Disable Geo-fence

Example 1:

Asking TR-206 disable geo-fence

GSC,135097652783615,N7*38!

8 Voice Monitor

The parameters of voice monitor:

Code word	Parameters	Value	Description
V4	Call in phone number for voice monitor	char(20)	G0~G5 are also call in phone number for voice monitor command
V5	Allowed interval for call in TR-206 after receiving voice monitor command	u16, in seconds	0 ~ 65535

Command format:

GSC,N4*Checksum!

Commands Codeword	Parameters
N4	Enable voice monitor

Example 1:

Make TR-206 wait the phone number +886920886555

(V4=+886920886555) or SOS phone number 1~6" phone number call in within 120 seconds (V5=120) when receive the enable voice monitor command (N4)

GSC,130789246109245,N4(V4=+886920886555,V5=120) *28!

9 Timer

There are four timers for setting specified time report.

For Timer 0, when there is a new event (report), it will re-start to count down the report interval again.

Timer 1 ~ 3 will not count down the report interval when there is a new event.

9.1 Timer 0

The following parameters must be set for configuration or sending those parameters by other action command:

Code word	Parameters	Value	Description
W0	Start time	0~86400	
W1	End time	0~86400	
W2	Report interval	1~3600	
W3	Weekday mask	00~7f	u8, xx(hex digits)
W4	Report Media		Please refer to 2.9 Report media

9.2 Timer 1~3

The following parameters must be set for configuration or sending those parameters by other action command:

("X": Timer 1, "Y": Timer 2, "Z": Timer 3,)

Code word	Parameters	Value	Description
X0	Start time	0~86400	
X1	End time	0~86400	
X2	Report interval	1~3600	
X3	Weekday mask	00~7f	u8, xx(hex digits)

X4	Report Media		Please refer to 2.9 Report media
Y0	Start time	0~86400	
Y1	End time	0~86400	
Y2	Report interval	1~3600	
Y3	Weekday mask	00~7f	u8, xx(hex digits)
Y4	Report Media		Please refer to 2.9 Report media
Z0	Start time	0~86400	
Z1	End time	0~86400	
Z2	Report interval	1~3600	
Z3	Weekday mask	00~7f	u8, xx(hex digits)
Z4	Report Media		Please refer to 2.9 Report media

Preliminary

10 Alarm Clock

There are 3 alarm clocks of TR-206.

("X": Alarm clock 1, "Y": Alarm clock 2, "Z": Alarm clock 3,)

Code word	Parameters	Value	Description
XA	Selecting melody for alarm clock 1	u8	
XB	Alarm time of alarm clock 1	u32, in seconds	0 ~ 86400
XC	Type of alarm clock 1		0=disable, 1=once, 2=daily 3=weekly (XD must be set)
XD	Weekday mask of alarm clock 1	u8, xx(hex digits)	Available when XC=3 00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
XE	Prompt message of alarm clock 1	Char(16)	
YA	Selecting melody for alarm clock 2	u8	
YB	Alarm time of alarm clock 2	u32, in seconds	0 ~ 86400
YC	Type of alarm clock 2		0=disable, 1=once, 2=daily 3=weekly (YD must be set)

YD	Weekday mask of alarm clock 2	u8, xx(hex digits)	Available when YC=3 00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
YE	Prompt message of alarm clock 2	Char(16)	
ZA	Selecting melody for alarm clock 3	u8	
ZB	Alarm time of alarm clock 3	u32, in seconds	0 ~ 86400
ZC	Type of alarm clock 3		0=disable, 1=once, 2=daily 3=weekly (ZD must be set)
ZD	Weekday mask of alarm clock 3	u8, xx(hex digits)	Available when XC=3 00 ~ 7f Weekday is in hex-digit format which specifies applicable day in a week, where bit 0 represents Sunday, bit1 represents Monday, etc.
ZE	Prompt message of alarm clock 3	Char(16)	

Note:

1. XB, YB, ZB starts on A.M. 00:00:00 and ends on P.M. 23:59:59. It is represented in seconds. For example, AM 03:30:45 =12645 second
2. XC, YC, and ZC are the ringing frequencies of the alarm clock. You could de-activate the alarm clock by setting XC, YC, ZC to be 0. If you sets the frequency as weekly (XC or YC or ZC=3), you must also set the weekday mask of alarm clock.
3. XE, YE, ZE are for showing the message on TR-206 LCD when alarm clock rings.

Example 1:

Make TR-206 ring on 04:00:30 (XB=14430) everyday (XC=2) with melody 2 (XA=2) and show message “Get up” (XE=Get up)

GSS,011412000010789,3,1,XA=2,XB=14430,XC=2,XE=Get up*1d!

Example 2:

Make TR-206 ring on 10:00 (YB=36000) from Monday to Friday (YC=3, YD=3e) with melody 1 (YA=1) and show message “Meeting” (YE=Meeting)

GSS, 011412000010789,3,1,YA=1,YB=36000,YC=3,YD=3e,YE=Meeting*48!

11 Other Function

Code word	Parameters	Value	Description
F4	Date format (LCD)	u8	
F5	Time format (LCD)	u8	0=12 hour 1=24 hour
F6	Daylight saving	1/0	1=enable 0=disable
F7	Auto key lock	1/0	1=enable 0=disable
F8	Vibrator/beep type	u8	0=vibrator + beep 1=beep 2=vibrator 3=off
FB	Volume level of ring tone	u8	0=minimum 1=medium 2=maximum 3=progressive Default=1
FC	Volume level of alarm clock	u8	0=minimum 1=medium 2=maximum 3=progressive Default=1
FD	Volume level of headset	u8	0~6 Default=6
FE	Melody of ring tone	u8	Default=2

FF	Power-on melody	u8	Default=1
OU	Password of simple command and PC Utility	Char(16)	

Note:

1. F4 could be dd/mm/yy or mm/dd/yy or yy/mm/dd. The date, month and year could also be separated by:.
2. F7: Make F7 =1 will make TR-206 lock the keys 30 seconds after you do not press any keys.

12 Report Messages

There are two types of message's report format, "format 0" and "format 1". Defined as follows:

12.1 Format 0 of Report Messages

Command's format for set format 0 of report messages:

GSS,IMEI,T,S,O3=y1y2y3....yn,*Checksum!

y1,y2,y3... are their respective parameters of report messages.
(Refer to "2.6. Parameters of Report Messages" for details of parameters' definition)

Parameter's Codeword	Description
O3	Report format 0

Example 1:

Set TR-206 format of report messages for format 0 (Send command via SMS or TCP or UDP)

GSS,135785412249986,3,0,O3=ORPZAB72GHLMN*U!*19!

(Refer to “2.6. Parameters of Report Messages” for details of parameters’ definition)

Report format for format 0 of report messages (report messages via SMS or TCP or UDP)

GSr,IMEI,Device_Mode,Report_Type,Alarm_Status,Geofence_status,GPS_Fix,UTC_Date,UTC_Time,Longitude,Latitude,Altitude,Speed,Heading,Number_of_Satellites,HDOP,Battery_capacity*checksum!

Command’s format for read format of format 0:

GSC,IMEI,L1(O3)*Checksum!

Commands Codeword	Parameters
L1	Read Configure

Example 1:

Ask TR-206 report “format of format 0” (Send command via SMS or TCP or UDP)

GSC,136647890362718,3,0,L1(O3)*6D!

TR-206 received “GSC,IMEI,L1(O3)*Checksum!” and report as below (report via SMS or TCP or UDP)

GSs,136647890362718,3,0,O3=ORPZAB72GHLMN*U!*13!

12.2 Format 1 of Report Messages

Command's format for set format 1 of report messages:

GSS,IMEI,T,S,ON=y1y2y3....yn,*Checksum!

y1,y2,y3... are their respective parameters of report messages.
(Refer to “2.6. Parameters of Report Messages” for details of parameters' definition)

Parameter's Codeword	Description
ON	Report format 1

Example 1:

Set TR-206 format of report message for format 1 (Send command via SMS or TCP or UDP)

GSS,131826789036289,3,0,ON=PAN*U!*46!

(Refer to “2.6. Parameters of Report Messages” for details of parameters' definition)

Report format for format 0 of report messages (report messages via SMS or TCP or UDP)

GSh,IMEI,Alarm_Status,GPS_Fix,Battery_capacity*checksum!

Command's format for read format of format 1:

GSC,IMEI,L1(ON)*Checksum!

Commands Codeword	Parameters
L1	Read Configure

Example 2:

Ask TR-206 report “format of format 1” (Send command via SMS or TCP or UDP)

GSC,131826789036289,3,0,L1(ON)*36!

TR-206 receives “GSC,IMEI,L1(ON)*Checksum!” and report as below (report via SMS or TCP or UDP)

GSs,131826789036289,3,0,ON= PAN*U!*66!

12.3 Format 1 of SMS

You could set the content of SMS to be displayed as text by setting F2=1. You could also edit the content of each report by the following parameters.

Code word	Parameters	Value	Description
F2	SMS format	1/0	0= Same as GPRS format 1= Text format
Fa	SMS format 1 report string for ping	char(96)	"00Ping!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fb	SMS format 1 report string for SOS alarm	char(96)	"00Emergency!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fc	SMS format 1 report string for main battery low	char(96)	"00Power low!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fd	SMS format 1 report string for geo-fence alarm	char(96)	"00Geofence alarm\r\nIMEI:\$S\r\nTime:\$C\r\nArea \$Z\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fe	SMS format 1 report string for periodic mode	char(96)	"00Periodic report!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Ff	SMS format 1 report string for on-line mode	char(96)	"00Online report!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fg	SMS format 1 report string for static state of	char(96)	"00Static report!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"

	motion mode		
Fh	SMS format 1 report string for moving state of motion mode	char(96)	"00Moving report!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fi	SMS format 1 report string for changing from static to moving state	char(96)	"00Start moving!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fj	SMS format 1 report string for changing from moving to static state	char(96)	"00Stop moving!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fk	SMS format 1 report string for high speed alarm	char(96)	"00Over speed!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fl	SMS format 1 report string for low speed alarm	char(96)	"00Under speed!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fm	SMS format 1 report string for timer 0	char(96)	"00Timer 0 alarm!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fn	SMS format 1 report string for timer 1	char(96)	"00Timer 1 alarm!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fo	SMS format 1 report string for timer 2	char(96)	"00Timer 2 alarm!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fp	SMS format 1 report string for timer 3	char(96)	"00Timer 3 alarm!\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"

Fq	SMS format 1 report string for power on	char(96)	"00Device power on\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"
Fr	SMS format 1 report string for power off	char(96)	"00Device power down\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"

Example:

Ping: "00Ping\r\nIMEI:\$S\r\nTime:\$C\r\nGPS \$A\r\n\$6,\$1\r\nSpeed:\$I km/hr\r\nPower:\$N%"

S=IMEI

C=Local date, time

A=GPS fix status

6=latitude

1=longitude

I=speed (km/hr)

N=battery capacity

Note:

For details of each report parameter, please refer to 2.6 Parameters of Report Messages

The received SMS is displayed as

Ping!

IMEI:12345678901234

Time:2009/11/17 04:43:20,

GPS:2

100.314536;21.924598


Speed:18 km/hr

Power:70%

13 Data Log

The function of Data Log is for you to record the location information of TR-206 based on the time interval or traveled distance or the combination of time interval and distance. After recording the location information, you could connect TR-206 to PC by USB cable for downloading the data log.

If you want TR-206 to store position according to traveled distance, you have to extra make GPS on. Please refer to “Chapter 4 GPS.”



①	Under tracking report state
②	When device receives “N8” command and then enable data logger function.
③	Store position according to data logger interval.
④	Tracking report.

The following parameters must be set for configuration or sending those parameters by other action command:


Code word	Parameters	Value	Description
O2	Data logger interval	u16, in seconds	0 ~ 65535 0=disable
OH	Data logger distance	u32, in meters	0 ~ 86400 0=disable

Command's format for enable data logger:

GSC,IMEI,N8(O2)*Checksum!

Commands Codeword	Parameters
N8	Enable Data logger

Under standby mode to store position according to data logger interval



①	Under tracking report state
②	When device received "N8" command and then enable data logger function.
③	Store position in accordance with data logger interval.

The following parameters must be set for configuration or sending those parameters by other action command:

Code word	Parameters	Value	Description
O2	Data logger interval	u16, in seconds	0 ~ 65535 0=disable


Command's format for enable data logger:

GSC,IMEI,N8(O2)*Checksum!

Commands Codeword	Parameters
N8	Enable Data logger

Under standby mode to store position according to data logger distance

If you want TR-206 to store position according to traveled distance, you have to extra make GPS on. Please refer to “Chapter 4 GPS.”



①	Under tracking report state
②	When device received “N8” command and then enable data logger function.
③	Store position in accordance with data logger distance.

The following parameters must be set for configuration or sending those parameters by other action command:

Code word	Parameters	Value	Description
OH	Data logger distance	u32, in meters	0 ~ 86400 0=disable


Command’s format for enable data logger:
GSC,IMEI,N8(OH)*Checksum!

Commands Codeword	Parameters
N8	Enable Data logger

14 Buffer Storage

When TR-206 is carried to the areas without GSM/GPRS signal coverage, TR-206 could not send its location reports to server. In order not to lose the location report, TR-206 will save the location reports during the periods without GSM/GPRS signal to buffer storage. When TR-206 is carried to the areas with GSM/GPRS signal, it will send the location reports in the buffer storage to server. TR-206 could save up to 8000 pieces of location reports to buffer storage.

The behavior mode is as following:



①	Tracking report
②	Enter area without GSM/GPRS signal coverage.
③	Save location report to buffer storage
④	Enter area with GSM/GPRS signal
⑤	Send periodic report
⑥	Send the location report in the buffer storage

The parameter of enable data buffer function is OG.

You could set OG by configuration or sending OG by the other action commands:

Code word	Parameters	Value	Description
OG	Enable/ disable data buffer function	1/0	0=disable 1=enable

15 Cell ID

GSM Cell ID is assisted information to get device location. When TR-206 does not get GPS fix, you could enable TR-206 to report the Cell ID. Then the report format of TR-206 will automatically switch from format 0 to format 2 when TR-206 does not get GPS fix. Report format 1 is not affected.

The parameter of enabling TR-206 to report the Cell ID is O8.

Code word	Parameters	Value	Description
O8	Enable/ disable TR-206 to report “cell ID” if it does not get GPS fix	1/0	0=disable 1=enable

The report format (format 2) of cell ID is

GSd,IMEI,Device_Mode,Report_Type,Alarm_Status,Date,Time,Battery_capacity,
“MCC₁,MNC₁,LAC₁,CID₁,BSIC₁,RSSI₁”, “MCC₂,MNC₂,LAC₂,CID₂,BSIC₂,RSSI₂”,
“MCC₃,MNC₃,LAC₃,CID₃,BSIC₃,RSSI₃”,...*checksum!

MCC=mobile country code, 3 digits

MNC=mobile network code, 2 or 3 digits

LAC=location area code, 4 hexadecimal digits.

CID=cell identifier, 4 hexadecimal digits.

BSIC=base station identity code, 1 digit or 2 digits.

RSSI=received signal strength indicator, 1 digit or 2 digits.

The number of set of cell information depends on GSM network environment. The maximum number is 5.