

Service adjustments

Fuel system

Intake system

Ignition system

- High-tension spark
- Ignition timing & firing order
- Ignition coil
- Ignition amplifier

Engine sensors

Emission control system

Control system



High-tension spark

NOTE: Disconnect injector harness multi-plug before cranking tests, to avoid damage to catalytic converter(s).

Checking - Fig. 22

- Ensure ignition switched OFF.
- Disconnect one high-tension lead from spark plug.
- Connect test spark plug to high-tension lead.
- Using insulated pliers, hold test spark plug 6 mm from suitable earth.
- Briefly crank engine.
- Check for strong blue spark.
- Repeat test for each high-tension lead.
- If no spark is visible: Carry out high-tension circuit component checks. Refer to General Test Procedures.

22



Volkswagen Passat (88-96) 2,0 1990-93
Engine code: 2E

System type: VAG Digifant

Service adjustments

Fuel system

Intake system

Ignition system

High-tension spark

Ignition timing & firing order

Ignition coil

Ignition amplifier

Engine sensors

Emission control system

Control system

23

AD75052

1

2

3

4

↓

Ignition timing & firing order

Checking and adjustment - Fig. 23 & Fig. 24

Technical Data

Basic ignition timing - BTDC	6±1°/2250 rpm
Firing order	1-3-4-2

• Ensure high-tension leads are connected correctly Fig. 23.

• Ensure engine is at normal operating temperature.

• Passat 90-93: Disconnect engine coolant temperature (ECT) sensor multi-plug.

• Start engine. Allow to idle.

• Except Passat 90-93: Initiate basic setting using suitable diagnostic equipment.

• Increase rpm to specified value.

• Check basic ignition timing Fig. 24.

• Adjust by turning distributor.

F1

F2

F3

F4

F5

F6

F7

F9

F11

Ctrl+F4

Ctrl+F8

vw_b3 - NetBeans...

Output - Editor

Autodata CD3 - [...]

1.high_tension.jp...

- Service adjustments
- Fuel system
- Intake system
- Ignition system
 - High-tension spark
 - Ignition timing & firing order
 - Ignition coil
 - Ignition amplifier
- Engine sensors
- Emission control system
- Control system

Ignition coil

NOTE: Incorporates ignition amplifier.

Checking primary resistance - Fig. 25

Technical Data	
Terminals	Resistance
1 & 15	0,5-0,7 Ω



- Ensure ignition switched OFF.
- Disconnect ignition coil multi-plug.
- Disconnect ignition coil high-tension lead.
- Open cover of low-tension terminals.
- Check resistance between ignition coil low-tension terminals.

Checking secondary resistance - Fig. 26

Technical Data	
Terminals	Resistance
15 & HT	3000-4000 Ω

- Ensure ignition switched OFF.
- Disconnect ignition coil multi-plug.
- Disconnect ignition coil high-tension lead.
- Open cover of low-tension terminals.
- Check resistance between one ignition coil low-tension terminal and the high-tension connection.

25



- Service adjustments
- Fuel system
- Intake system
- Ignition system
 - High-tension spark
 - Ignition timing & firing order
 - Ignition coil
 - Ignition amplifier
- Engine sensors
- Emission control system
- Control system

Ignition amplifier

NOTE: Incorporated in ignition coil.

Checking earth connection - Fig. 27

Technical Data	
Terminals	Resistance
1 & earth	Zero

- Ensure ignition switched OFF.
- Disconnect ignition coil multi-plug.
- Check resistance between harness multi-plug terminal and earth.
- If resistance not as specified: Check wiring.

Checking supply voltage - Fig. 27

Technical Data	
Terminals	Voltage
1 & 3	Battery voltage


- Ensure ignition switched OFF.
- Disconnect ignition coil multi-plug.
- Switch ignition ON.
- Check voltage between harness multi-plug terminals.
- If voltage not as specified: Check wiring.

Checking signal - Fig. 28


Technical Data	
Terminals	LED
2 & 3	Flashing

NOTE: Disconnect injector harness multi-plug before cranking tests, to avoid damage to catalytic converter(s).

- Ensure ignition switched OFF.
- Disconnect ignition coil multi-plug.
- Connect LED test lamp between harness multi-plug terminals.
- Briefly crank engine.
- Check that LED flashes.



AD81978



Service adjustments

Fuel system

Intake system

Ignition system

- High-tension spark
- Ignition timing & firing order
- Ignition coil
- Ignition amplifier

Engine sensors

Emission control system

Control system

Technical Data	
Terminals	Voltage
1 & 3	Battery voltage

- Ensure ignition switched OFF.
- Disconnect ignition coil multi-plug.
- Switch ignition ON.
- Check voltage between harness multi-plug terminals.
- If voltage not as specified: Check wiring.

Checking signal - Fig. 28

Technical Data	
Terminals	LED
2 & 3	Flashing

NOTE: Disconnect injector harness multi-plug before cranking tests, to avoid damage to catalytic converter(s).

- Ensure ignition switched OFF.
- Disconnect ignition coil multi-plug.
- Connect LED test lamp between harness multi-plug terminals.
- Briefly crank engine.
- Check that LED flashes.

Checking operation - Fig. 29

Technical Data		
Terminals	Condition	LED
1 & 15	Ignition ON	ON for 1-2 secs.
1 & 15	Engine cranking	Flashing

NOTE: Disconnect injector harness multi-plug before cranking tests, to prevent engine from starting.

- Ensure ignition switched OFF.
- Access ignition coil low-tension terminals.
- Connect LED test lamp between ignition coil low-tension terminals.
- Switch ignition ON.
- Check that LED illuminates for 1-2 seconds.
- Briefly crank engine.
- Check that LED flashes.
- If LED does not flash: Suspect faulty ignition amplifier.

