

Service adjustments
Fuel system
Intake system <ul style="list-style-type: none">Throttle position (TP) sensorVolume air flow (VAF) sensorIntake air temperature (IAT) sensorIdle air control (IAC) valve
Ignition system
Engine sensors
Emission control system
Control system

Throttle position (TP) sensor

Checking earth connection - Fig. 16

Technical Data	
Terminals	Resistance
3 & earth	Zero

- Ensure ignition switched OFF.
- Disconnect TP sensor multi-plug.
- Check resistance between harness multi-plug terminal and earth.
- If resistance not as specified: Check wiring.

Checking supply voltage - Fig. 16


Technical Data	
Terminals	Voltage
1 & 3	5 V approx.

- Ensure ignition switched OFF.
- Disconnect TP sensor multi-plug.
- Switch ignition ON.
- Check voltage between harness multi-plug terminals.

Checking - Fig. 17

Technical Data		
Terminals	Condition	Voltage
2 & 3	Throttle closed	0,3-1,7 V approx.
2 & 3	Throttle fully open	3-5 V approx.

- Ensure ignition switched OFF.
- Do not disconnect multi-plug. Access TP sensor multi-plug terminals.
- Switch ignition ON.
- Check voltage between multi-plug terminals.
- Operate throttle valve while checking voltage between terminals 2 and 3.
- Voltage change should be smooth.



Service adjustments

Fuel system

Intake system

- Throttle position (TP) sensor
- Volume air flow (VAF) sensor
- Intake air temperature (IAT) sensor
- Idle air control (IAC) valve

Ignition system

Engine sensors

Emission control system

Control system

Volume air flow (VAF) sensor

NOTE: Incorporates intake air temperature (IAT) sensor.

Checking operation - Fig. 18

- Ensure ignition switched OFF.
- Disconnect intake air trunking from VAF sensor Fig. 18 [1].
- Operate sensor flap over full extent of travel.
- Check for smooth operation.
- Clean off any gummy deposits with solvent, if necessary.

Checking resistance - Fig. 18

Technical Data		
Terminals	Condition	Resistance
2 & 3	Flap closed	610 Ω approx.
2 & 4	Flap closed	60 Ω approx.
2 & 3	Flap fully open	280 Ω approx.
2 & 4	Flap fully open	780 Ω approx.

- Ensure ignition switched OFF.
- Disconnect intake air trunking from VAF sensor Fig. 18 [1].
- Disconnect VAF sensor multi-plug Fig. 18 [2].
- Check resistance between VAF sensor terminals.
- Operate sensor flap over full extent of travel.
- Check resistance between VAF sensor terminals.
- Resistance change should be smooth.


Checking earth connection - Fig. 18 & Fig. 19

Technical Data	
Terminals	Resistance
4 & earth	Zero

- Ensure ignition switched OFF.
- Disconnect VAF sensor multi-plug Fig. 18 [2].
- Check resistance between harness multi-plug terminal and earth Fig. 19.

Checking supply voltage - Fig. 18 & Fig. 19

18



Service adjustments

Fuel system

Intake system

- Throttle position (TP) sensor
- Volume air flow (VAF) sensor
- Intake air temperature (IAT) sensor
- Idle air control (IAC) valve

Ignition system

Engine sensors

Emission control system

Control system

- Check resistance between VAF sensor terminals.
- Resistance change should be smooth.

Checking earth connection - Fig. 18 & Fig. 19

Technical Data	
Terminals	Resistance
4 & earth	Zero

- Ensure ignition switched OFF.
- Disconnect VAF sensor multi-plug Fig. 18 [2].
- Check resistance between harness multi-plug terminal and earth Fig. 19.

Checking supply voltage - Fig. 18 & Fig. 19

Technical Data	
Terminals	Voltage
3 & 4	5 V approx.


- Ensure ignition switched OFF.
- Disconnect VAF sensor multi-plug Fig. 18 [2].
- Switch ignition ON.
- Check voltage between harness multi-plug terminals Fig. 19.

Checking signal - Fig. 18

Technical Data		
Terminals	Condition	Voltage
2 & 4	Engine idling	0,9 V approx.
2 & 4	2000 rpm	1,5 V approx.
2 & 4	4000 rpm	2,2 V approx.

- Ensure ignition switched OFF.
- Do not disconnect multi-plug. Access VAF sensor multi-plug terminals.
- Start engine.
- Allow to idle.
- Check voltage between multi-plug terminals.
- Increase rpm to specified values.
- Check voltage between multi-plug terminals.
- Voltage change should be smooth.

18



Service adjustments

Fuel system

Intake system

- Throttle position (TP) sensor
- Volume air flow (VAF) sensor
- Intake air temperature (IAT) sensor
- Idle air control (IAC) valve

Ignition system

Engine sensors

Emission control system

Control system

Intake air temperature (IAT) sensor

NOTE: Incorporated in volume air flow (VAF) sensor.

Checking resistance - Fig. 18 & Fig. 19


Technical Data		
Terminals	Temperature	Resistance
1 & 4	0°C	5000-6500 Ω
1 & 4	10°C	3250-4500 Ω
1 & 4	20°C	2200-3000 Ω
1 & 4	30°C	1500-2000 Ω
1 & 4	40°C	1000-1400 Ω
1 & 4	50°C	725-925 Ω
1 & 4	60°C	535-675 Ω
1 & 4	70°C	400-500 Ω
1 & 4	80°C	275-375 Ω

- Ensure ignition switched OFF.
- Disconnect VAF sensor multi-plug Fig. 18 [2].
- Check ambient air temperature.
- Check resistance between VAF sensor terminals Fig. 19.

Checking supply voltage - Fig. 18 & Fig. 19

Technical Data	
Terminals	Voltage
1 & 4	5 V approx.

- Ensure ignition switched OFF.
- Disconnect VAF sensor multi-plug Fig. 18 [2].
- Switch ignition ON.
- Check voltage between harness multi-plug terminals Fig. 19.



Service adjustments

Fuel system

Intake system

- Throttle position (TP) sensor
- Volume air flow (VAF) sensor
- Intake air temperature (IAT) sensor
- Idle air control (IAC) valve

Ignition system

Engine sensors

Emission control system

Control system

Idle air control (IAC) valve

Checking resistance - Fig. 20

Technical Data	
Terminals	Resistance
1 & 3	2-10 Ω

- Ensure ignition switched OFF.
- Disconnect IAC valve multi-plug.
- Check resistance between IAC valve terminals.

Checking supply voltage - Fig. 21

Technical Data	
Terminals	Voltage
1 & earth	Battery voltage

- Ensure ignition switched OFF.
- Disconnect IAC valve multi-plug.
- Switch ignition ON.
- Check voltage between harness multi-plug terminal and earth.
- If voltage not as specified: Check wiring and fuses.

20

