

Sys DIV

↳ 4-127 VALUE (n)

(n) = USED TO CONFIGURE THE PLL
AT DIFF SPEEDS FOR SYSTEM BUS

$$n = 4$$

$$\rightarrow \frac{400}{n+1} = \frac{400}{5} = \boxed{80 \text{ MHz}}$$