



Figure 4-2 *The Windowed *r* Registers*

In Figure 4-1, NWINDOWS = 8. The 8 *globals* are not illustrated. The register sets are indicated in bold face. CWP = 0 and WIM[7] = 1. If the procedure using window w0 executes a RESTORE, window w1 will become the current window. If the procedure using window w0 executes a SAVE, a window_overflow trap will occur. The overflow trap handler uses the w7 *locals*.