

blhost User's Guide



Contents

Chapter 1 Introduction.....	4
Chapter 2 Overview.....	5
Chapter 3 MCU bootloader.....	6
Chapter 4 blhost Utility application.....	7
4.1 <i>blhost</i> Options.....	7
4.1.1 -? (Help menu).....	7
4.1.2 -v (Version).....	7
4.1.3 -i <name>[,<address>,<speed>] (Connect over I2C).....	8
4.1.4 -p <name>[,<speed>] (Connect over UART).....	8
4.1.5 -s <name>[,<speed>,<polarity>,<phase>, lsb msb] (Connect over SPI).....	9
4.1.6 -u [[<vid>,<pid>]][<path>]] (Connect over USB).....	9
4.1.7 -b (BusPal).....	11
4.1.8 -l(LPCUSBSIO).....	11
4.1.9 -V (Verbose).....	11
4.1.10 -d (Debug).....	12
4.1.11 -j (JSON output type).....	12
4.1.12 -n (No ping).....	12
4.1.13 -t (Timeout).....	12
4.2 <i>blhost</i> Commands.....	12
4.2.1 reset.....	13
4.2.2 get-property <tag>[<memoryID>]	13
4.2.3 set-property <tag> <value>[<memoryID>].....	14
4.2.4 flash-erase-region <addr> <byte_count>[memoryID].....	15
4.2.5 flash-erase-all[memoryID].....	15
4.2.6 flash-erase-all-unsecure.....	15
4.2.7 read-memory <addr> <byte_count> [<file>][memoryID].....	16
4.2.8 write-memory <addr> [<file> {{<hex-data>}}][memoryID].....	16
4.2.9 fill-memory <addr> <byte_count> <pattern> [word short byte].....	16
4.2.10 receive-sb-file <file>.....	16
4.2.11 execute <address> <arg> <stackpointer>.....	17
4.2.12 call <address> <arg>.....	17
4.2.13 flash-security-disable <key>.....	17
4.2.14 flash-program-once <index> <byteCount> <data>.....	17
4.2.15 flash-read-once <index> <byteCount>.....	18
4.2.16 efuse-program-once <index> <data>.....	18
4.2.17 efuse-read-once <addr>.....	18
4.2.18 flash-read-resource <addr> <byteCount> <option> [<file>].....	18
4.2.19 configure-memory <memoryID> <addr>.....	18
4.2.20 flash-image <file> [erase][memoryID].....	18
4.2.21 reliable-update <addr>.....	18
4.2.22 generate-key-blob <dek_file> <blob_file> [key_sel].....	19
4.2.23 key-provisioning <operation> [arguments...].....	19
4.2.24 load-image <file>.....	19
4.2.25 program-aeskey <file>.....	20

Chapter 5 MCU bootloader properties.....	21
5.1 Current version.....	21
5.2 Available peripherals.....	21
5.3 Available commands.....	21
 Chapter 6 Revision history.....	 23
 Appendix A Bootloader operation.....	 24
 Appendix B Updating a bootloader image.....	 25
B.1 Introduction.....	25
B.2 Checklist.....	25
B.3 Procedure.....	25
B.4 Example.....	25
 Appendix C BusPal: Bus-friendly blhost companion tool.....	 30
C.1 Introduction.....	30
C.2 Supported platforms and features.....	30
C.2.1 FRDM-KL25Z.....	30
C.2.2 TWR-KV46F150M.....	30
C.2.3 TWR-K65F180M.....	31
C.3 Usage with blhost.....	31
C.4 Pinmux and configurations.....	31
C.4.1 FRDM-KL25Z Freedom development platform.....	31
C.4.2 TWR-KV46F150M Tower System module.....	32
C.4.3 TWR-K65F180M Tower System module.....	33
C.5 Build the BusPal project.....	34
C.6 Platform setup.....	34
 Appendix D LPC USB Serial I/O: A Bus bridge for LPC Link2 tool.....	 35
D.1 Introduction.....	35
D.2 Usage with blhost.....	35
D.3 USB parameters.....	35
D.4 SPI parameters.....	35
D.5 I2C parameters.....	36
D.6 How to check if LPC Link2 supports LPC USB Serial I/O.....	36

Chapter 1

Introduction

This document describes the usage of the blhost application. The blhost application is used on a host computer to issue commands to an NXP platform running an implementation of the MCU bootloader. The blhost application with the MCU bootloader, allows a user to program a firmware application onto the MCU device without a programming tool.

NOTE

1. When flash security is enabled, blhost cannot read, write, or erase the flash. See [Section 4.2.13, flash-security-disable <key>](#), for how to disable the flash security.
 2. blhost cannot connect to the ROM or flash-resident bootloader if the application is running on the device. It is possible to get back into the bootloader by pressing the boot pin if that pin is enabled in the BCA. See the *MCU Bootloader Demo Applications User's Guide* (document MBOOTDEMOUG) for more information on boot pins and the platforms supported.
-

Chapter 2

Overview

This user's guide describes how to interface with the MCU bootloader using blhost application. There is a brief introduction of the MCU bootloader followed by detailed descriptions of blhost options and commands. A description of the MCU bootloader operation, as it relates to blhost application, is provided in Appendix A, Appendix B, Appendix C, and Appendix D.

Chapter 3

MCU bootloader

The MCU bootloader is intended to be the standard bootloader for all MCU devices. It provides a standard interface to the device using any of the peripherals supported by the bootloader on a given NXP MCU device.

MCU bootloader implementations include:

- ROM-based bootloader
- one-shot flash memory programming aid (referred to as a flashloader)
- flash-resident bootloader

The MCU bootloader is available as source code for customer and flash-based implementations. There are example applications in the package which demonstrates how to interface with the MCU bootloader.

Chapter 4

blhost Utility application

The blhost application is a command-line utility used on the host computer to initiate communication and issue commands to the MCU bootloader. The application only sends one command per invocation.

The blhost application supports multi-platforms, including Windows, Linux (X86-based), MACOSX, and Linux (Arm-based).

The blhost application can communicate directly with the MCU bootloader over the host computer's UART (Serial Port) or USB connections.

MCU bootloader typically supports other peripherals such as I2C, SPI, and CAN. However, the blhost application cannot interface with the MCU bootloader over these transports without external hardware (except Arm Linux version).

See Appendix C for the description of BusPal embedded software. The BusPal acts as a bus translator running on selected platforms. BusPal assists blhost in carrying out commands and responses from the target device through an established connection with blhost over UART, and the target device over I2C, SPI, or CAN.

See Appendix D for the description of LPC USB Serial I/O (LPCUSBSIO), a firmware built in LPC Link2. The LPCUSBSIO acts as a bus translator, and establishes connection with blhost over USB-HID, and the MCU bootloader device over I2C and SPI.

The arguments for blhost consist of a set of options followed a command description. The options and the command are separated with a '--'.

Ex. blhost [options] -- [command]

The following sections describe all of blhost options and commands.

4.1 *blhost* Options

blhost utility provides an easy to use command line interface. The syntax of the usage text is:

```
blhost.exe [-?|--help] [-v|--version] [-p|--port <name>[,<speed>]]
           [-i|--i2c <name>[,<address>,<speed>]]
           [-s|--spi <name>[,<speed>,<polarity>,<phase>,lsb|msb]]
           [-b|--buspal spi[,<speed>,<polarity>,<phase>,lsb|msb] |
           i2c[,<address>,<speed>] | can[,<speed>,<txid>,<rxid>] | sai[,<speed>]]
           [-l|--lpcusbsio spi[,<port>,<pin>,<speed>,<polarity>,<phase>]
           | i2c[,<address>,<speed>]]
           [-u|--usb [[[[<vid>,<pid>] | [<path>]]]] [-V|--verbose]
           [-d|--debug] [-j|--json] [-n|--noping] [-t|--timeout <ms>]
           -- command <args...>
```

4.1.1 -? (Help menu)

The below commands can be used to get "help" guide. This guide lists all the options and commands supported by blhost utility.

blhost -?

blhost -h

blhost --help

4.1.2 -v (Version)

This below command prints the version of the blhost application.

blhost -v

blhost --version

4.1.3 -i <name>[,<address>,<speed>] (Connect over I2C)

The below command can be used to connect to MCU bootloader over I2C. **This option is valid for Arm-Linux blhost.** This option can have one or three arguments.

blhost -i <name> -- command

blhost --i2c <name> -- command

blhost -i <name>[,<address>,<speed>] -- command

name: I2C port.

address: I2C slave address(default 0x10, if not specified)

speed: I2C baud rate/frequency(default 100 kbps, if not specified)

Table 1. Command usage in different operating systems

	Windows	Linux	MAC	Arm Linux
Obtaining the port number	—	—	—	Use the command \$dmesg grep i2c, or \$ls /dev grep i2c
Example	—	—	—	\$sudo ./blhost -i /dev/ i2c-1,0x10,100 – command
Administrative rights required for this operation.	—	—	—	Yes

4.1.4 -p <name>[,<speed>] (Connect over UART)

The below command can be used in Windows platform to connect to MCU bootloader over UART. This option has two arguments.

blhost -p <name>[,<speed>] -- command

name: serial port

speed: baud rate (default - 57600, if not specified)

blhost -p COMx -- command

blhost -- port COMx -- command

Table 2. Command usage in different operating systems

	Windows	Linux	Mac
Obtaining the port number	Check in the Device Manager	Use the command \$dmesg grep tty	Use the command \$ ls /dev/{tty,cu}.*
Example	blhost - port COM1 --command	\$ sudo ./blhost -p /dev/ ttyACM0 -- command	\$ sudo ./blhost - p /dev/cu.usbmodemFA121 -- command
Administrative rights required for this operation	No	Yes	Yes

4.1.5 -s <name>[,<speed>,<polarity>,<phase>, lsb|msb] (Connect over SPI)

The below command can be used to connect to MCU bootloader over SPI. **This option is valid for Arm-Linux blhost.** This option can have one, two, or five arguments.

blhost -s <name> -- command

blhost --spi <name> -- command

blhost -s <name>,<speed> -- command

blhost -s <name>[,<speed>,<polarity>,<phase>, lsb|msb] -- command

name: SPI port.

speed: SPI baud rate/frequency(default 100kpbs, if not specified)

polarity: SPI polarity, 0 for active high, 1 for active low (default)

phase: SPI phase, 0 for rising edge sampling, 1 for falling edge sampling (default)

lsb/msb: SPI sequence endian, "lsb" or "msb" (default)

Table 3. Command usage in different operating systems

	Windows	Linux	MAC	Arm Linux
Obtaining the port number	—	—	—	Use the command \$dmesg grep spi, or \$ls /dev grep spi
Example	—	—	—	\$sudo ./blhost -s /dev/ spidev0.0,100,1,1,msb --command
Administrativerights required for this operation.	—	—	—	Yes

4.1.6 -u [[<vid>,<pid>]][<path>]] (Connect over USB)

The below command can be used to connect to MCU bootloader over USB HID. This option can have one or two arguments.

blhost -u [[<vid>,<pid>]] -- command

blhost --usb [[<vid>,<pid>]] -- command

blhost -u [<path>] -- command

vid: Specify USB vendor ID of device

pid: Specify USB product ID of device

path: Specify USB path of device

NOTE

- The default vid,pid is -u 0x15a2,0x0073. Hence this command can also be used as blhost -u -- command
- --u and --usb can be used interchangeably in this command

Table 4. Command usage in different operating systems

	Windows	Linux	Mac
Obtaining VID and PID	Check in the Device Manager	Use the command \$ lsusb	Click Apple logo at top left > About This Mac > System Report... > USB
Example	blhost -u HID\VID_15A2&PID_0073\9&14A67 53&0&0000 -- command	\$ sudo ./blhost -u /dev/ hidraw1 -- command	\$ sudo ./blhost -u 0x15a2,0x0073 -- command
Path	Check in the Device Manager	Use the command \$dmesg	similar to Linux
Administrative rights required for this operation	No	Yes	Yes





Figure 1. Device Manager



4.1.7 -b (BusPal)

See Appendix C on the usage of blhost with BusPal.

blhost -b

blhost --buspal

4.1.8 -l(LPCUSBSIO)

See Appendix D on the usage of blhost with LPC USB Serial I/O

blhost -l

blhost --lpcusbsio

4.1.9 -V (Verbose)

The below command prints detailed log information.

blhost -V

blhost --verbose

4.1.10 -d (Debug)

The below command prints every byte sent and received from the MCU bootloader. The bytes sent to the bootloader are denoted as [xx] and bytes received from the bootloader are denoted as <xx>.

```
blhost -d
```

```
blhost --debug
```

4.1.11 -j (JSON output type)

The below command prints output in JSON format to aid automation.

All output other than the JSON formatted command response is suppressed. For example:

```
>blhost -p COM23 -j -- get-property 1
{
  "command" : "get-property",
  "response" : [ 1258423808 ],
  "status" : {
    "description" : "0 (0x0) Success.",
    "value" : 0
  }
}
```

4.1.12 -n (No ping)

Skip the initial ping of a serial target. By default, blhost sends an initial ping before every command. The initial ping is used by the UART peripheral to automatically establish the baud rate of the UART. If sending successive commands to a UART, subsequent commands can use the -n option to skip the ping because the baud rate has already been established. Also, the ping can safely be suppressed when using I2C, SPI, or CAN transports. Sending a ping before every command does not cause an issue.

```
blhost -n
```

```
blhost --noping
```

4.1.13 -t (Timeout)

The below command sets serial read timeout in milliseconds. This value allows blhost to timeout when waiting on data from the MCU bootloader over a serial transport.

The default is 5000 milliseconds.

Example : blhost -u -t 50000 -- flash-erase-all

4.2 blhost Commands

The "help" guide of blhost lists all of the options and commands supported by the blhost utility.

All commands are not supported on all MCU bootloader platforms. If a command is not supported by the MCU bootloader, it returns *k_StatusUnknownCommand*.

When flash security is enabled, only the get-property, set property, reset, flash-security-disable, and flash-erase-all-unsecure commands are supported. The MCU bootloader returns *kStatus_SecurityViolation* if a command is received that is not supported due to flash security settings.

4.2.1 reset

This command resets the device. A response packet is sent prior to resetting the device.

The reset command is used to reset the device. It passes the control to the user application. After the device boots from flash and user image is programmed successfully using ROM bootloader. After issuing the reset command, allow 5 seconds for the user application to start running from flash.

Command: `--reset`

Usage: `blhost -u --reset`

4.2.2 get-property <tag>[<memoryID>]

This command is used to query the bootloader about various properties and settings. Each supported property has a unique integer *tag* value.

Example: `-- get-property 10`

tag:

- 0x01 The Current Version of the MCU bootloader
- 0x02 A mask of the Available Peripherals
- 0x03 The starting address of the on-chip flash
- 0x04 The size of the on-chip flash
- 0x05 The size in bytes of one sector of program flash. This is the minimum erase size
- 0x06 The number of blocks in the on-chip flash
- 0x07 A mask of the Available Commands
- 0x08 Status code from the last CRC check operation. Available only if the CRC check feature is supported
- 0x09 Reserved for future use
- 0x0a Verify Writes Flag - Boolean controlling whether the bootloader verifies writes to flash. A value of 0 means no verification is done, a value of 1 enables verification. This feature is enabled by default
- 0x0b The maximum supported packet size for the currently active peripheral interface
- 0x0c Reserved Regions - List of memory regions reserved by the bootloader. Returned as value pairs (<start-address-of-region>, <end-address-of-region>). If HasDataPhase flag is not set, response packet parameter count indicates number of pairs. If HasDataPhase flag is set, second parameter is the number of bytes in the data phase
- 0x0e The starting address of the on-chip RAM
- 0x0f The size in bytes of the on-chip RAM
- 0x10 The value of the Kinetis System Device Identification register
- 0x11 Flash Security Enabled Flag - Boolean indicating whether flash security is enabled. 0 means disabled, 1 means enabled
- 0x12 The values of the Device Unique ID. The number of ID words is indicated by the parameter count in the response packet
- 0x13 FAC Supported Flag - Boolean indicating whether Flash Access Control (FAC) module is supported. 0 means not supported, 1 means supported
- 0x14 The number of bytes per FAC segment
- 0x15 The number of segments available in the FAC
- 0x16 The flash read margin setting. A value of 0 indicates Normal read margin, a value of 1 indicates User read margin, and a value of 2 indicates Factory read margin. The default is User
- 0x17 Reserved for future use

- 0x18 Target Version - the target build version number
- 0x19 External Memory Attributes - memoryId is required. the table below lists the details on memoryID. For additional information on memoryID, refer to MCU Bootloader reference manual or ROM chapter in device's reference manual
- 0x1a Reliable update status - the status of the reliable update operation.
- 0x1b Flash page size - Size of flash page, <index> is required.
- 0x1c IRQ notifier pin - The pin selected as nIRQ pin.
- 0x1d FFR key store update operation - The selected operation for FFR keystore update.
- 0x1e Byte Write Timeout(ms) - The timeout value for outgoing packet bytes.

NOTE

Not all properties are supported by all target. To check the supported properties, see the target's user manual or the reference manual.

Table 5. Memory ID

Internal Memory	Device internal memory space
0	Internal Memory (Default selected memory)
16 (0x10)	Execute-only region on internal flash (Only used for flash-erase-all)
Mapped External Memory	The memories that are remapped to internal space, and must be accessed by internal addresses. (IDs in this group are only used for flash-erase-all and configure-memory, and ignored by write-memory, read-memory, flash-erase-region and flash-image(use default 0))
1	QuadSPI Memory
8	SEMC NOR Memory
9	FlexSPI NOR Memory
10 (0xa)	SPIFI NOR Memory
Unmapped External Memory	Memories which cannot be remapped to internal space, and only can be accessed by memories' addresses. (Must be specified for all commands with <memoryId> argument)
256 (0x100)	SEMC NAND Memory
257 (0x101)	SPI NAND Memory
272 (0x110)	SPI NOR/EEPROM Memory
273 (0x111)	I2C NOR/EEPROM Memory
288 (0x120)	uSDHC SD Memory
289 (0x121)	uSDHC MMC Memory

4.2.3 set-property <tag> <value>[<memoryID>]

Example: `-- set-property 10 0`

This command changes properties and options in the bootloader. The command accepts the same property tags used with the get-property command; however, only some properties are writable. If an attempt to write a read-only property is made, an error is returned indicating the property is read-only and cannot be changed.

Properties that can be changed all have 32-bit values.

tag:

- 0x0a Verify Writes Flag - Boolean controlling whether the bootloader verifies writes to flash. A value of 0 means no verification is done, a value of 1 enables verification. This feature is enabled by default.
- 0x16 - The flash read margin setting. A value of 0 indicates Normal read margin, a value of 1 indicates User read margin, and a value of 2 indicates Factory read margin. The default is User.
- 0x1c IRQ notifier pin - The pin selected as nIRQ pin.

Table 6. Definition of the <value> word for set-property 0x1c

[Bit]	[31]	[30:16]	[7:0]
Field	Enable nIRQ pin, 0: disable, 1: enable	GPIO port index	GPIO pin index

- 0x1d FFR key store update operation - The selected operation for FFR keystore update 0 for Keyprovisioning; 1 for write-memory.
- 0x1e Byte Write Timeout (ms) - The timeout value for outgoing packet bytes.

NOTE

Not all properties are supported by all target. To check the supported properties, see the target's user manual or the reference manual.

4.2.4 flash-erase-region <addr> <byte_count>[memoryID]

Example: `-- flash-erase-region 0xa000 1024`

Erases one or more sectors of flash memory specified by memoryID. The default memoryID is 0 if the memory parameter is not provided.

The start address and count must be a multiple of the word size. The entire sector(s) containing the start and end address is erased.

If the VerifyWrites property is enabled, the command performs a flash verify erase operation.

4.2.5 flash-erase-all[memoryID]

Example: `-- flash-erase-all`

Performs an erase of the entire flash memory specified by memoryID. The default memoryID is 0 if the memoryID parameter is not provided.

If any flash regions are protected, the command fails with an error. If any flash regions are reserved by the bootloader, they are ignored (not erased).

If the VerifyWrites property is enabled, the flash-erase-all command performs a flash verify erase all operation, or multiple flash verify erase options if decomposed due to reserved regions.

4.2.6 flash-erase-all-unsecure

Example: `-- flash-erase-all-unsecure`

This command is only supported in new versions of the flash controller. Most MCU devices do not support this command, and the bootloader sends a *kStatus_UnknownCommand* error in response.

Performs a mass erase of the flash memory, including protected sectors and any reserved regions in flash. Flash security is immediately disabled if it was enabled and the FSEC byte in the Flash Configuration Field at address 0x40C is programmed to 0xFE.

The Mass Erase Enable option in the FSEC field is honored by this command. If mass erase is disabled, then this command fails. This command is only useful and only present in ROM configurations of the bootloader because it erases reserved regions in flash.

4.2.7 read-memory <addr> <byte_count> [<file>][memoryID]

Example: `-- read-memory 0x3c0 32 myConfigData.dat`

Read memory specified by MemoryID and write to file or stdout if no file specified. The default MemoryID is 0 if the memoryID parameter is not provided.

Returns the contents of memory at the given address, for a specified number of bytes. This command can read any region of memory accessible by the CPU and not protected by security. This includes flash, RAM, and peripheral registers. Note that the minimum profile does not support reading the peripheral register space.

4.2.8 write-memory <addr> [<file> | {{<hex-data>}}][memoryID]

Example: `-- write-memory 0x3c0 myConfigData.dat`

Example: `-- write-memory 0xa000 "{{aa bb cc dd ee ff 00 01 02 03 04}}"` (spaces require quotes)

Example: `-- write-memory 0xa000 {{aabbccddeeff0001020304}}`

Write memory specified by memoryID at *addr* from *file* or string of hex values. The default memoryID is 0 if the memoryID parameter is not provided.

Writes a provided buffer to a specified range of bytes in memory. Can write to all accessible memory, including flash, RAM, and peripheral registers. However, if flash protection is enabled, writes to protected sectors fails. Data specified by *file* is treated as binary data.

Any flash sector written to must be previously erased with either a *flash-erase-all*, *flash-erase-region*, or *flash-erase-all-unsecure* command.

Writing to flash requires the start address to be word aligned. The byte count is rounded up to a multiple of the word size, and trailing bytes are filled with the flash erase pattern (0xff).

Word and halfword-aligned and sized writes to RAM and peripheral registers use appropriately sized writes. This enables writing to registers larger than a byte in a single bus transaction. Note that the minimum profile does not support writing to the peripheral register space.

If the VerifyWrites property is enabled, writes to flash performs a flash verify program operation.

4.2.9 fill-memory <addr> <byte_count> <pattern> [word | short | byte]

Example: `-- fill-memory 0x3c0 32 0xff byte`

Fill memory with pattern; size is word (default), short or byte. To fill 32-bit memory words with a repeating byte pattern, specify a byte-sized pattern argument followed by the 'byte' keyword. To fill memory words with a repeating 16-bit pattern, specify a short-sized pattern followed by the 'short' keyword.

Follows the same rules as the *write-memory* command.

4.2.10 receive-sb-file <file>

Example: `-- receive-sb-file mySecureImage.sb`

Receive a file in Secure Binary (SB) format. An SB file is an encapsulated, binary stream of bootloader commands that can be optionally encrypted. The SB file format is described in the document *elftosb User's Guide* (document MCUELFTOSBUG) and can be created using the elftosb tool.

Note that if the SB file contains a JUMP command, the receive-sb-file command is aborted at the point of the jump, and a status of *kStatus_AbortDataPhase* is returned.

4.2.11 execute <address> <arg> <stackpointer>

Example: `-- execute 0x6000 0x21 0x1fff8400`

Jumps to code at the provided *address* and does not return to the bootloader. The system is returned to reset state prior to the jump. The function *arg* parameter is passed in R0 to the called code. The main stack pointer and process stack pointer registers are set to the *stackpointer* parameter, which can be zero. If set to zero, the code being called should set the stack pointer before using the stack.

The effective prototype of the called function is:

```
void function(uint32_t arg);
```

4.2.12 call <address> <arg>

Example: `-- call 0x6000 0x21`

This invokes code at the provided *address* with the expectation that control returns to the bootloader.

The function that is called has the same prototype as for the one called by the execute command.

NOTE

Because the intention is to return to the bootloader after the function executes, the function must not perform any action that would interfere with the bootloader operation. In particular, the following restrictions apply:

- Do not use interrupts because the interrupt vectors are still owned by the bootloader.
- Do not modify any memory locations used by the bootloader (use "get-property 12" to determine reserved regions).
- Do not modify any pin mux or clock settings used by bootloader peripherals.

4.2.13 flash-security-disable <key>

Example: `-- flash-security-disable 0102030405060708`

Performs the flash security disable operation by comparing the provided 8-byte backdoor key against the backdoor key stored in the Flash Configuration Field at address 0x400 in flash.

If the backdoor key comparison fails, further attempts to disable security with this command fails until the system is reset.

Backdoor key access must be enabled by setting the KEYEN bitfield of the FSEC byte in the Flash Configuration Field to 0b10. It is disabled by default. The backdoor key in the Flash Configuration Field must also be set to a value other than all zeros or all ones.

4.2.14 flash-program-once <index> <byteCount> <data>

Example: `-- flash-program-once 0 4 0x01020304`

This writes provided data to a specific program once field.

Special care must be taken when writing to program once field. The program once field only supports programming once.

Any attempts to reprogram a program once field gets an error response. The number of bytes to be written must be 4-byte aligned for non-FAC fields, and be 8-byte aligned for FAC fields.

4.2.15 flash-read-once <index> <byteCount>

Example: `-- flash-read-once 0 4`

Returns the contents of a specific program once field.

4.2.16 efuse-program-once <index> <data>

Example: `--efuse-program-once 6 0x04030201`

This command writes data to a specific efuse word. Each efuse bit can only be programmed once.

4.2.17 efuse-read-once <addr>

Example `--efuse-read-once 6`

Returns the contents of a specific efuse word.

4.2.18 flash-read-resource <addr> <byteCount> <option> [<file>]

Example: `-- flash-read-resource 0 4 1 firmwareID.txt`

Reads the contents of Flash IFR or Flash Firmware ID as specified by *option* and writes result to *file* or stdout if *file* is not specified.

byteCount: The number of bytes to read and returns to the caller. Must be 4-byte aligned.

option: Indicates which area to be read. 0 means Flash IFR, 1 means Flash Firmware ID.

4.2.19 configure-memory <memoryID> <addr>

Example: `-- configure-memory 1 0x20001000`

Apply the configuration block at <addr> to external memory with ID <memoryID>. The specified configuration block must have been previously written to memory using the write-memory command. The format of the configuration block is described in the *MCU Bootloader v2.5.0 Reference Manual* (document MCUBOOTRM).

4.2.20 flash-image <file> [erase][memoryID]

Example: `-- flash-image myImage.s19 erase`

Write the formatted image in <file> to the memory specified by memoryID. Supported file types are S-Record (.srec and .s19), and Hex (.hex). Flash is erased before writing if [erase] is 'erase' or 1. This blhost command does not directly correspond to a bootloader command, but may send multiple bootloader commands to perform the operation.

4.2.21 reliable-update <addr>

For software implementation:

Example: `-- reliable-update 0x105000`

Checks the validity of backup application at <addr>, then copies the contents of backup application from <addr> to main application region.

For hardware implementation:

Example: `-- reliable-update 0xfe000`

Verifies if the provided <addr> is a valid swap indicator address for flash swap system, then checks the validity of backup application resided in upper flash block. After that, it swaps the flash system.

4.2.22 generate-key-blob <dek_file> <blob_file> [key_sel]

Example: `-- generate-key-blob dek.bin blob.bin`

Generate the blob for the given dek key -- dek.bin, and write the blob to the file -- blob.bin. DEK key file is generated by CST tool.

[key_sel] selects the blob key encryption key(BKEK) used to generate the key blob.

For devices with SNVS, the valid options of [key_sel] are:

- 0,1 or "OTPMK" : OTPMK from FUSE or OTP (default)
- 2 or "ZMK": ZMK from SNVS
- 3 or "CMK": CMK from SNVS.

For devices without SNVS, this option is ignored.

4.2.23 key-provisioning <operation> [arguments...]

The key-provisioning command is a pack of several security related commands.

- enroll

Example: `-- key-provisioning enroll`

Enroll key provisioning feature. No argument for this operation.

- set_user_key <type><file>[,<size>]

Example: `-- key-provisioning set_user_key 0xB userKey.bin`

Send the user key specified by <type> to bootloader. <file> is the binary file containing user key plain text. If <size> is not specified, the entire <file> will be sent, otherwise, blhost only sends the first <size> bytes.

- set_key <type> <size>

Example: `-- key-provisioning set_key 0x1 0x100`

Generate <size> bytes of the key specified by <type>.

- write_key_nonvolatile [memoryID]

Example: `-- key-provisioning write_key_nonvolatile 0x110`

Write the key to a nonvolatile memory.

- read_key_nonvolatile [memoryID]

Example: `-- key-provisioning read_key_nonvolatile 0x110`

Load the key from a nonvolatile memory to bootloader.

- write_key_store <file>[,<size>]

Send the key store to bootloader. <file> is the binary file containing key store. If <size> is not specified, the entire <file> will be sent. Otherwise, only send the first <size> bytes.

- read_key_store <file>[,<size>]

Read the key store from bootloader to host(PC). <file> is the binary file to store the key store.

<type> and corresponding <size> are target specific values, and various on different devices. For details, see the ROM chapter in the Reference Manual.

4.2.24 load-image <file>

Example: `-- load-image ivt_application_0x800.bin`

Send a boot image <file> to the device. Only binary file is supported. And the <file> must be a bootable image which contains the boot image header supported by MCU bootloader, for example, IVT and Boot Data.

4.2.25 program-aeskey <file>

Example: `-- program-aeskey aes_key.bin`

Send a raw binary, which contains an aes key, to the devices and program it to the OTP field.

Chapter 5

MCU bootloader properties

5.1 Current version

The value of this property is a 4-byte structure containing the current version of the bootloader. This property is encoded in a one-word value.

Table 7. Bit ranges for version components

Bit	[31:24]	[23:16]	[15:8]	[7:0]
Field	Name	Major version	Minor version	Bugfix version

5.2 Available peripherals

The value of this property is a one-word bitfield that lists the peripherals supported by the bootloader and the hardware on which it is running.

Table 8. Peripheral bits

Bit	5	4	3	2	1	0
Peripheral	Reserved	USB HID	CAN	SPI slave	I2C slave	UART

5.3 Available commands

This property value is a bitfield with bits set corresponding to commands enabled in the bootloader.

The bit number that identifies whether a command is present is the command's tag value minus 1. To get the bit mask for a given command, use this expression.

$$mask = 1 \ll (tag - 1)$$

Table 9. Available commands

Bit	Command
[31:21]	reserved
20	key-provisioning (0x15)
19	reserved
18	generate-key-blob (0x13)
17	reliable-update (0x12)
16	configure-memory (0x11)
15	flash-read-resource (0x10)
14	flash-read-once (0x0f)
13	flash-program-once (0x0e)
12	flash-erase-all-unsecure (0x0d)

Table continues on the next page...

Table 9. Available commands (continued)

Bit	Command
11	set-property (0x0c)
10	reset (0x0b)
9	call (0x0a)
8	execute (0x09)
7	receive-sb-file (0x08)
6	get-property (0x07)
5	flash-security-disable (0x06)
4	fill-memory (0x05)
3	write-memory (0x04)
2	read-memory (0x03)
1	flash-erase-region (0x02)
0	flash-erase-all (0x01)

Chapter 6

Revision history

The following table contains a history of changes made to this user's guide.

Table 10. Revision history

Revision number	Date	Substantive changes
0	12/2014	Initial release
1	07/2015	Kinetis bootloader 1.2.0 updates
2	09/2015	Kinetis bootloader K80 standalone updates
3	04/2016	Kinetis Bootloader v.2.0.0 release
4	03/2018	RT1050 Flashloader 1.1 release
4.1	04/2018	MCU Bootloader v2.5.0 release
5	09/2018	MCU Bootloader v2.6.0 release
6	11/2018	MCU Bootloader v2.7.0 release
7	04/2020	Updated for blhost 2.6.2 release
8	11/2020	Updated for blhost 2.6.5 release

Appendix A

Bootloader operation

The correct use of blhost program requires a connection to a MCU device running the MCU bootloader command interface. The diagram shows a simplified view of the MCU bootloader state machine that shows the states relevant to blhost application.




Figure 1. Simplified MCU bootloader state diagram

Figure 3. Simplified MCU bootloader state diagram

After reset, the bootloader monitors all enabled peripheral devices, UART, I2C, SPI, CAN, USB-HID, and USB-MSC for active communication. After communication is established, all peripherals except the active peripheral are shut down, and the bootloader enters the command processing state.

If the bootloader is in the “Detect Active Peripheral” state, the first use of blhost application establishes the active peripheral and the bootloader transitions to the “Process Commands” state. The active peripheral is established according to the transport used by the initial blhost invocation.

For example, if the `-u` option was successfully used to send the initial command, the USB-HID is the active peripheral and all future commands must use the `-u` option unless the bootloader is reset.

If the `-p COMx` option is used, the UART is the active peripheral and all future commands must use the `-p COMx` option unless the bootloader is reset. For the UART peripheral, the baud rate is automatically determined by the bootloader when processing the initial ping. Therefore, subsequent blhost invocations must specify the same baud rate as was used for the initial invocation unless the bootloader is reset. If the baud rate is not specified using the `-p COMx, <baudrate>` option, the UART baud rate is set to 57600.

NOTE

After the MCU bootloader is in the “Process Commands” state, the device has to be reset to communicate over a different peripheral or at a different baud rate over the same UART peripheral.

Appendix B

Updating a bootloader image

B.1 Introduction

The flash-resident bootloader's main objective upon invocation is to provide a means for the host to update the application image residing on the flash along with the bootloader image.

If the flash-resident bootloader itself requires an upgrade, the MCU bootloader release package contains a solution. The RAM-based flashloader project is available in the release package for supported platforms, and can be used in the manner described below to upgrade the flash-resident bootloader.

B.2 Checklist

The setup and software required for upgrading the bootloader image:

1. Pre-built image for the RAM-based flashloader.
2. New flash-resident bootloader binary. In this example, the bootloader version number in `src/bootloader/bl_version.h` is changed to distinguish the new bootloader image from the current image.
3. Host PC for running blhost software and interfacing over UART/USB to the target device.
4. Target device connected to the host PC with either UART/USB.

B.3 Procedure

These steps explain how to upgrade the bootloader image on the flash:

1. Invoke flash-resident bootloader on the target device.
2. Establish a connection between the bootloader and the host PC over UART or USB.
3. Use the host-side command line tool (blhost) available with the release package on the host PC to start communicating with the bootloader on the target device. See additional information in this users guide for using the blhost command line tool.
4. Download the pre-built image for the RAM-based flashloader into the internal RAM of the target device using the blhost write-memory command.
5. Invoke the blhost execute command to run the RAM-based flashloader on the target device.
6. Use blhost commands to communicate with the RAM-based flashloader, and replace the flash-resident bootloader with the new binary on the flash.
7. Reset the device to boot with the new flash-resident bootloader binary.

B.4 Example

Here is an example of how to update a bootloader for the KV46 32K RAM hardware and software environment:

Kinetis Tower System:

- Tower Serial port module.
- KV46 Rev A Tower System module with the current version of the bootloader and the LED demo application flashed on the device.
- The demo start address is 0xA000.

Detailed procedures:

- Power on the KV46 Tower System module. The LED demo should be running.
- Connect the KV46 Tower System module to host PC through UART port (e.g., COM1).
- Power cycle the KV46 Tower System module and send the following command within 5 seconds, which should enter bootloader mode.

This is an example command sequence for updating a bootloader image:

```
> blhost.exe -p COM1 -- get-property 1
Ping responded in 1 attempt(s)
Inject command 'get-property'
Response status = 0 (0x0) Success.
Response word 1 = 1258423808 (0x4b020600)
Current Version = K2.7.0

>blhost.exe -p COM1 -- get-property 12
Ping responded in 1 attempt(s)
Inject command 'get-property'
Response status = 0 (0x0) Success.
Response word 1 = 0 (0x0)
Response word 2 = 16383 (0x3fff)
Response word 3 = 536862720 (0x1fffe000)
Response word 4 = 536863999 (0x1fffe4ff)
Reserved Regions = Region0: 0x0-0x3FFF (16 KB)
Region1: 0x1FFFE000-0x1FFFE4FF (1.250 KB)
```

Load the prebuilt RAM-based flashloader into RAM and execute from the flashloader. The example assumes the RAM start address is 0x1fffe600, entry address is 0x1fffea11, and stack pointer is 0x20001718. Confirm this by reading the first 8 bytes in bin file.

```
> blhost.exe -p COM1 -- write-memory 0x1fffe600 <path>flashloader.bin
Ping responded in 1 attempt(s)
Inject command 'write-memory'
Preparing to send 11360 (0x2c60) bytes to the target.
Successful generic response to command 'write-memory'
Successful generic response to command 'write-memory'
Response status = 0 (0x0) Success.
Wrote 11360 of 11360 bytes.

>blhost.exe -p COM1 -- execute 0x1fffea11 0 0x20001718
Ping responded in 1 attempt(s)
Inject command 'execute'
Successful generic response to command 'execute'
Response status = 0 (0x0) Success.
```

The flashloader should now be running. By checking the reserved area <get-property 12> you should see the RAM reserved area is different (much bigger) compared with the bootloader.

```
>blhost.exe -p COM1 -- get-property 12

Ping responded in 1 attempt(s)

Inject command 'get-property'

Response status = 0 (0x0) Success.

Response word 1 = 0 (0x0)

Response word 2 = 0 (0x0)

Response word 3 = 536864256 (0x1fffe600)

Response word 4 = 536876823 (0x20001717)

Reserved Regions = Region0: 0x0-0x0 (0 bytes)

Region1: 0x1FFFE600-0x20001717 (12.273 KB)
```

Erase the flash memory by using the flash-erase-all or flash-erase-region commands. If you want to update the bootloader and erase the application at the same time, use the flash-erase-all command. Otherwise, use the flash-erase-region command in order to protect your application from being erased.

Erase entire flash memory command:

```
>blhost.exe -p COM1 -- flash-erase-all

Ping responded in 1 attempt(s)

Inject command 'flash-erase-all'

Successful generic response to command 'flash-erase-all'

Response status = 0 (0x0) Success.
```

Confirm if the flash memory has been erased by using the read-memory command.

```
>blhost.exe -p COM1 -- read-memory 0 32

Ping responded in 1 attempt(s)

Inject command 'read-memory'

Successful response to command 'read-memory'

ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff
ff ff ff ff ff ff ff ff ff ff ff ff ff ff ff

Successful generic response to command 'read-memory'

Response status = 0 (0x0) Success.

Response word 1 = 32 (0x20)

Read 32 of 32 bytes.
```

Write the new bootloader into the flash area and confirm if the writing is properly done by reading memory.

```
>blhost.exe -p COM1 -- write-memory 0 <path>new_tower_bootloader.bin

Ping responded in 1 attempt(s)

Inject command 'write-memory'

Preparing to send 12924 (0x327c) bytes to the target.
```

```
Successful generic response to command 'write-memory'
Successful generic response to command 'write-memory'
Response status = 0 (0x0) Success.
Wrote 12924 of 12924 bytes.

>blhost.exe -p COM1 -- read-memory 0 32
Ping responded in 1 attempt(s)
Inject command 'read-memory'
Successful response to command 'read-memory'
00 e5 ff 1f 01 08 00 00 37 0f 00 00 11 14 00 00
13 14 00 00 15 14 00 00 17 14 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 37 0f 00 00
37 0f 00 00 00 00 00 00 37 0f 00 00 a7 0b 00 00
67 13 00 00 67 13 00 00 67 13 00 00 67 13 00 00
67 13 00 00 67 13 00 00 67 13 00 00 67 13 00 00
67 13 00 00

Successful generic response to command 'read-memory'
Response status = 0 (0x0) Success.
Response word 1 = 100 (0x64)
Read 100 of 100 bytes.
```

Reset. Try to get the version and you should be able to run under a new version of the bootloader by checking the revision number (2.7.0)

```
>blhost.exe -p COM1 -- reset
Ping responded in 1 attempt(s)
Inject command 'reset'
Successful generic response to command 'reset'
Response status = 0 (0x0) Success.

>blhost.exe -p COM1 -- get-property 1
Ping responded in 1 attempt(s)
Inject command 'get-property'
Response status = 0 (0x0) Success.
Response word 1 = 1258423808 (0x4b020600)
Current Version = K2.7.0
```

Now that the bootloader update is complete, you can use it to flash new or original applications into it.

```
>blhost.exe -p COM1 -- write-memory 0xa000 <path>led_demo.bin
Ping responded in 1 attempt(s)
Inject command 'write-memory'
```

```
Preparing to send 2004 (0x7d4) bytes to the target.  
Successful generic response to command 'write-memory'  
Successful generic response to command 'write-memory'  
Response status = 0 (0x0) Success.  
Wrote 2004 of 2004 bytes.
```

After reset and a short wait, you should see that the LED demo running.

```
>blhost.exe -p COM1 -- reset  
Ping responded in 1 attempt(s)  
Inject command 'reset'  
Successful generic response to command 'reset'  
Response status = 0 (0x0) Success.
```

Warnings and exceptions:

- If you have only 16K RAM on the chip, you need to ensure the flashloader is able to fit into the RAM range supported by the original bootloader.
- If you only want to update the bootloader but preserve the existing application on the flash, you should not use the '-- flash-erase-all command'. Use the '-- flash-erase-region' command to only erase the original bootloader flash area.


Appendix C

BusPal: Bus-friendly blhost companion tool

C.1 Introduction

BusPal is an embedded software tool that is available as a companion to blhost. The tool acts as a bus translator with an established connection with blhost over UART and with the target device over I2C, SPI, or CAN, and assists blhost in carrying out commands and responses from the USB target device. The BusPal is available for selected platforms. The source code for BusPal is provided with the MCU bootloader release, and can be customized to run on other platforms.

The diagram below illustrates the role BusPal plays in blhost communication with the target device.



C.2 Supported platforms and features

BusPal software is currently supported for selected platforms. The entire source code is available with the MCU bootloader release, and can be easily customized for any other platform of the customer's choice.

C.2.1 FRDM-KL25Z

The FRDM-KL25Z NXP Freedom development platform is available for order on the NXP website. The BusPal supports low speed I2C and SPI peripherals to interface with the target device, and the UART to communicate with blhost running on host PC.

C.2.2 TWR-KV46F150M

The TWR-KV46F150M NXP Tower System module is available for order on the NXP website. The BusPal supports high-speed I2C, SPI, and CAN peripherals to interface with the target device. The TWR-SER Tower System module is required for UART connection to the blhost running on a host PC.

C.2.3 TWR-K65F180M

The TWR-K65F180M Tower System module is available for order at www.nxp.com. The BusPal supports high-speed I2C, SPI, and CAN peripherals to interface with the target device. The TWR-SER Tower System module can be used for UART connection to the blhost running on a host PC. The K65 version of BusPal also supports communication with the host PC over USB-HID.

C.3 Usage with blhost

The BusPal assists blhost in sending a command to the target device over I2C, SPI, or CAN interface, and collects responses from the peripheral and provides feedback to the blhost.

The blhost command line provides a way to make blhost aware of the BusPal. The `-b` or `--buspal` command-line options of blhost are used for this purpose. The peripheral and its connection parameters are required following the `-b` or `--buspal` option. This is the syntax of the blhost command for using BusPal:

```
blhost.exe -p COMi [-b|--buspal spi[,<speed>,<polarity>,<phase>,lsb|msb] | i2c[,<address>,<speed>]
| can,<speed>,<txid>,<rxid>]
```

- SPI parameters:

- Speed: 100 kHz (default)
- Polarity: 1 - ActiveLow (default), 0 - Active High
- Phase: 1 - Falling edge (default), 0 - Rising edge
- lsb or msb: "msb" (default), "lsb"

- I2C parameters:

- Address: Slave I2C node (7 bit address -- default is 0x10)
- Speed: 100 - 100 K (default)

- CAN parameters:

- Speed: 0 - 125 K, 1 - 250 K, 2 - 500 K, 4 - 1 M (default)
- TxId: Standard Format 11 bits only ID (default is 0x321)
- RxId: Standard Format 11 bits only ID (default is 0x123)

C.4 Pinmux and configurations

The following sections describe the Pinmux configuration used in BusPal software for each peripheral of the supported platforms.

C.4.1 FRDM-KL25Z Freedom development platform

Table 11. UART0

Signal name	Pin name	ALT mode
UART0_RX	PTA1	ALT2
UART0_TX	PTA2	ALT2

Table 12. SPI0

Signal name	Pin name	ALT mode	Signal name on target
SPI0_PCS0	PTD0	ALT2	SPI_PCS0

Table continues on the next page...

Table 12. SPI0 (continued)

Signal name	Pin name	ALT mode	Signal name on target
SPI0_SCK	PTD1	ALT2	SPI_SCK
SPI0_MOSI	PTD2	ALT2	SPI_MOSI
SPI0_MISO	PTD3	ALT2	SPI_MISO

Table 13. I2C0

Signal name	Pin name	ALT mode	Signal name on target
I2C0_SCL	PTC8	ALT2	I2C_SCL
I2C0_SDA	PTC9	ALT2	I2C_SDA

Note that there are no pull-up resistors on PTC8 and PTC9 pins.

C.4.2 TWR-KV46F150M Tower System module

Because the TWR-KV46F150M Tower System module only has one OpenSDA USB port, use the COM1 port on the TWR-SER Tower System module to communicate with the TWR-KV46F150M BusPal.

Table 14. UART1

Signal name	Pin name	ALT mode	Signal name on target
UART1_RX	PTE0	ALT3	TWR-SER
UART1_TX	PTE1	ALT3	TWR-SER

Table 15. DSPI0

Signal name	Pin name	ALT mode	Signal name on target
SPI0_PCS0	PTA14	ALT2	Elev B46
SPI0_SCK	PTA15	ALT2	Elev B48
SPI0_MOSI	PTA16	ALT2	Elev B45
SPI0_MISO	PTA17	ALT2	Elev B44

Table 16. I2C0

Signal name	Pin name	ALT mode	Signal name on target
I2C0_SCL	PTC14	ALT3	Elev A7
SPI0_SCK	PTC15	ALT3	Elev A8

Table 17. FlexCAN0

Signal name	Pin name	ALT mode	Signal name on target
CAN0_TX	PTA12	ALT2	J13 1
CAN0_RX	PTA13	ALT2	J13 2

FlexCAN support speed:

The maximum speed supported on the current FlexCAN IP is 1 MHz.

The speedIndex value is 0, 1, 2, and 4, and represents the real speed as follows:

- 0 - 125 kHz
- 1 - 250 kHz
- 2 - 500 kHz
- 4 - 1 MHz (default)

C.4.3 TWR-K65F180M Tower System module

The COM1 port on the TWR-SER board is used to communicate with the K65 BusPal. The USB MINIAB port on the TWR-SER board is used for BusPal over USB.

Table 18. UART4

Signal name	Pin name	ALT mode	Signal name on target
UART4_RX	PTE25	ALT3	Elev A47
UART4_TX	PTE24	ALT3	Elev A48

UART connections:

- Elev A47 - TWR-SER J17 - 1
- Elev A48 - TWR-SER J19 - 1

Table 19. DSPI0

Signal name	Pin name	ALT mode	Signal name on target
SPI0_PCS0	PTD11	ALT2	Elev B46
SPI0_SCK	PTD12	ALT2	Elev B48
SPI0_MOSI	PTD13	ALT2	Elev B45
SPI0_MISO	PTD14	ALT2	Elev B44

Table 20. I2C0

Signal name	Pin name	ALT mode	Signal name on target
I2C0_SDA	PTE18	ALT4	Elev A8
I2C0_SCL	PTE19	ALT4	Elev A7

Table 21. FlexCAN0

Signal name	Pin name	ALT mode	Signal name on target
CAN0_TX	PTA30	ALT2	TWR-SER J7 - 3
CAN0_RX	PTA31	ALT2	TWR-SER J7 - 1

FlexCAN support speed:

The maximum speed supported on the current FlexCAN IP is 1 MHz.

The speedIndex value is 0, 1, 2, and 4, and represents the real speed as follows:

- 0 - 125 kHz

- 1 - 250 kHz
- 2 - 500 kHz
- 4 - 1 MHz (default)

FlexCAN connections:

- Elev A47 - TWR-SER J17 - 1
- Elev A28 - TWR-SER 19 - 1

C.5 Build the BusPal project

The BusPal source code is available in the `apps\bus_pal` directory in NXP_Kinetis_Bootloader_2.0.0 package on www.nxp.com/MCUBOOT.

C.6 Platform setup

As illustrated in Figure 4, "Role of BusPal in interfacing blhost and target device", the supported platform (FRDM-KL25Z/TWR-KV46F150M/TWR-K65F180M) should be connected to host PC via UART (USB-HID is also supported on K65). The BusPal image should be running on the platform, and blhost should be running on the host PC. The target platform runs the bootloader image.

The connection between the target platform and BusPal platform hardware depends on what peripheral is being used to interface with the bootloader. For example, if the I2C peripheral is used for interfacing with the bootloader, the I2C probe pins for SCL and SDA available on the boards for BusPal and target platforms should be physically connected using fly-wires. The connection should be well secured for reliable data transfers.

Appendix D

LPC USB Serial I/O: A Bus bridge for LPC Link2 tool

D.1 Introduction

The LPC USB Serial I/O (LPCUSBSIO) is a firmware, which can communicate with serial I/O devices connected to LPC Link2. The LPCUSBSIO contains two parts. One, named LPC USB Serial I/O Library, is a generic API provided to PC application. This part is built in the blhost. The other one is named LPC Serial I/O port is a firmware, which receives USB messages and transfers to devices using I2C, SPI and GPIO interfaces. This part is build in the LPC Link2.

For details on LPC Link2, see [LPC Link2](#).

For details on LPC USB Serial I/O, see [LPCUSBSIO](#).

D.2 Usage with blhost

Currently, blhost supports I2C and SPI interfaces of LPCUSBSIO.

To use LPCUSBSIO, The `-l/--lpcusbsio` command-line options must be provided.

The peripheral type and parameters are required following the `-l/--lpcusbsio` option.

This is the syntax of the blhost command for using LPCUSBSIO.

```
blhost.exe [-u [<vid>,<pid>] | [<path>]] -l/--lpcusbsio spi[,<port>,<pin>,<speed>,<polarity>,<phase>]
| i2c,<address>,<speed>]
```

D.3 USB parameters

`[-u]`: Optional. LPCUSBSIO can only use USB to communicate with the host.

`<vid>,<pid>`: Optional. If the LPC Link2 doesn't use the default VID(0x1fc9) and PID(0x0009), user can specify the `<vid>` and `<pid>` arguments to overwrite them.

`[<path>]`: Reserved option for LPCUSBSIO. Current LPCUSBSIO Library does not support multiple of LPC Link2 connected to the host. Reserved for extension in the future.

D.4 SPI parameters

`spi`: Must be specified if using SPI to communicate with MCU bootloader.

`<port>` and `<pin>`: Selects the GPIO[port][pin] on the LPC Link2 MCU to act as SPI.nCS. Default is port 0, pin 0.

NOTE

This is the GPIO on LPC Link2 MCU, but not the GPIO on the device running MCU bootloader.

`<speed>`: SPI baud rate/frequency(default 100 kpbs, if not specified)

`<polarity>`: SPI polarity, 0 for active high, 1 for active low (default)

`<phase>`: SPI phase, 0 for rising edge sampling, 1 for failing edge sampling (default)

NOTE

LPCUSBSIO only supports MSB for SPI data transmission.

D.5 I2C parameters

I2C: Must be specified if using I2C to communicate with MCU bootloader.

<address>: I2C slave address(default 0x10, if not specified).

<speed>: I2C baud rate/frequency(default 100kbps, if not specified).

D.6 How to check if LPC Link2 supports LPC USB Serial I/O

Not all LPC Link2 contains the LPC Serial I/O port. User can check using the Device Manager (Windows) or the `$dmesg` command (Linux, MAC).




Figure 5. Device manager

Three HID devices, one for debugger, one for CDC UART, and one for LPC Serial I/O port.

```
[2977091.406301] usb 3-3: new high-speed USB device number 13 using xhci_hcd
[2977091.555111] usb 3-3: New USB device found, idVendor=1fc9, idProduct=0090, b
cdDevice= 1.00
[2977091.555116] usb 3-3: New USB device strings: Mfr=1, Product=2, SerialNumber
=3
[2977091.555118] usb 3-3: Product: LPC-LINK2 CMSIS-DAP V5.361
[2977091.555120] usb 3-3: Manufacturer: NXP Semiconductors
[2977091.555122] usb 3-3: SerialNumber: BRARBQER
[2977091.559092] hid-generic 0003:1FC9:0090.000A: hiddev0 hidraw0: USB HID v1.00
Device [NXP Semiconductors LPC-LINK2 CMSIS-DAP V5.361] on usb-0000:00:14.0-3/in
put0
[2977091.560445] hid-generic 0003:1FC9:0090.000B: hiddev1 hidraw1: USB HID v1.00
Device [NXP Semiconductors LPC-LINK2 CMSIS-DAP V5.361] on usb-0000:00:14.0-3/in
put4
[2977091.560916] cdc_acm 3-3:1.1: ttyACM0: USB ACM device
[2977091.563264] hid-generic 0003:1FC9:0090.000C: hiddev2 hidraw2: USB HID v1.11
Device [NXP Semiconductors LPC-LINK2 CMSIS-DAP V5.361] on usb-0000:00:14.0-3/in
put3
```

Figure 6. Command prompt

How To Reach Us

Home Page:

nxp.com

Web Support:

nxp.com/support

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

While NXP has implemented advanced security features, all products may be subject to unidentified vulnerabilities. Customers are responsible for the design and operation of their applications and products to reduce the effect of these vulnerabilities on customer's applications and products, and NXP accepts no liability for any vulnerability that is discovered. Customers should implement appropriate design and operating safeguards to minimize the risks associated with their applications and products.

Security — Customer understands that all NXP products may be subject to unidentified or documented vulnerabilities. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP. NXP has a Product Security Incident Response Team (PSIRT) (reachable at PSIRT@nxp.com) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, Altivec, CodeWarrior, ColdFire, ColdFire+, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, Tower, TurboLink, EdgeScale, EdgeLock, eIQ, and Immersive3D are trademarks of NXP B.V. All other product or service names are the property of their respective owners. AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamIQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-ME, ULINK-PLUS, ULINKpro, µVision, Versatile are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© NXP B.V. 2014-2020.

All rights reserved.

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: salesaddresses@nxp.com

Date of release: 11 November 2020
Document identifier: MCUBLHOSTUG



