

Reset
SCK
MISO
Vcc

ICSP for 16U2
USB interface

(I2C) SCL
(I2C) SDA

SPI
is
not
here

Interrupt 1

Interrupt 5
Interrupt 4
Interrupt 3
Interrupt 2

Reset
SCK
MISO

GND
MOSI
Vcc

USB
to computer

7 to 12V
DC input,
center
positive

use for
analog ground

not I2C
not I2C
UNO shields
can cover up

reset

