



NOTES:

1. INSTALL JUMPER WIRE BETWEEN TERMINAL 11 & 12 IF STARTING 2ND PUMP @ HIGH LEVEL IS REQUIRED. IF THIS IS DONE, THEN FLOAT SWITCH FS3 MUST BE OF THE DIFFERENTIAL TYPE TO OBTAIN PUMPING. OTHERWISE PUMP WILL START AND STOP REPEATEDLY AND WILL DAMAGE PUMP AND PANEL.
2. PUMP INTERNAL THERMAL OVERLOAD IS REQ'D

CONTROL PANEL MAX RATING:
MAX HP=2 @ 230V, 1HP @ 115VAC
MAX AMPS=16

* DIVERSIFIED ALTERNATOR

SCHEMATIC DIAGRAM
1226

REVISION
CP-1226
2/24/06