

dummy_e.ebe

Attributes

```
ebe name=dummy_e
Jacobian: constant
nodes: a
state_vars:
aux_vars:
aux_vars_startup:
x_vars:
iparms:
sparms:
rparms:
stparms:
igparms:
outparms:
```

Description

dummy_e.ebe is used only by the GSEIM schematic capture GUI, and not by the solver.

If wire1 is connected to a dummy_e.ebe element with name XYZ, and wire2 is connected to another dummy_e.ebe element with the same name, then wire1 and wire2 are considered to be a single node.

In some situations, dummy_e.ebe elements are useful in reducing clutter in the schematic diagram.