

Get_Offset_Value Method

Collapse All Language Filter: All

FUTEK_USB_DLL Assembly > FUTEK_USB_DLL Namespace > USB_DLL Class : Get_Offset_Value Method

Gets the offset value stored in the EEPROM of the microcontroller.

Syntax

Visual Basic C#

'Declaration

Public Function Get_Offset_Value(_
 ByVal DeviceHandle As IntPtr, _
 Optional ByVal ChannelNumber As Byte _
) As String

'Usage

Dim instance As USB_DLL
Dim DeviceHandle As IntPtr
Dim ChannelNumber As Byte
Dim value As String

value = instance.Get_Offset_Value(DeviceHandle, ChannelNumber)

Parameters

DeviceHandle
Type: [System.IntPtr](#)
The handle associated with the USB device.

ChannelNumber
Type: [System.Byte](#)
The channel number associated with the USB device.

Return Value

Type: [System.String](#)
A value between -16,777,216 and 16,777,215; otherwise **Error**

Remarks

Requirements

Target Operating System: Windows XP SP3, Windows Vista SP1, Windows 7 SP1, Windows 8 or Windows 8.1

Target Framework: .NET Framework 4.0 or later

See Also

Reference

[USB_DLL Class](#)

