

# Study of ROS topics, nodes, messages and the ROS graph for running the Velodyne Lidar VLP16

For ROS Indigo, Ubuntu 14.04

Guilherme Nunes Guimarães

Upon connecting the Lidar to the computer (following the Lidar VLP16 Setup tutorial) and running the commands

```
roslaunch velodyne_pointcloud VLP16_points.launch  
roslaunch rviz rviz -f velodyne
```

with the command

```
rostopic list
```

we can see that ROS creates the following set of topics:

```
/clicked_point  
/diagnostics  
/initialpose  
/move_base_simple/goal  
/rosout  
/rosout_agg  
/tf  
/tf_static  
/velodyne_nodelet_manager/bond  
/velodyne_nodelet_manager_cloud/parameter_descriptions  
/velodyne_nodelet_manager_cloud/parameter_updates  
/velodyne_nodelet_manager_driver/parameter_descriptions  
/velodyne_nodelet_manager_driver/parameter_updates  
/velodyne_packets  
/velodyne_points
```

The following packages contain message types that get published and subscribed to within these topics:

actionlib  
actionlib\_msgs  
actionlib\_tutorials  
beginner\_tutorials  
bond  
control\_msgs  
diagnostic\_msgs  
driver\_base  
dynamic\_reconfigure  
gazebo\_msgs  
geometry\_msgs  
map\_msgs  
nav\_msgs  
pcl\_msgs  
roscpp  
rosgraph\_msgs  
rospy\_tutorials  
sensor\_msgs  
shape\_msgs  
simplelessons  
smach\_msgs  
std\_msgs  
stereo\_msgs  
tf  
tf2\_msgs  
theora\_image\_transport  
trajectory\_msgs  
turtle\_actionlib  
turtlesim  
velodyne\_msgs  
visualization\_msgs

The following parameters are available for configuration:

/velodyne\_nodelet\_manager\_cloud/calibration  
/velodyne\_nodelet\_manager\_cloud/max\_range  
/velodyne\_nodelet\_manager\_cloud/min\_range

/velodyne\_nodelet\_manager\_cloud/view\_direction  
/velodyne\_nodelet\_manager\_cloud/view\_width  
/velodyne\_nodelet\_manager\_driver/device\_ip  
/velodyne\_nodelet\_manager\_driver/frame\_id  
/velodyne\_nodelet\_manager\_driver/model  
/velodyne\_nodelet\_manager\_driver/pcap  
/velodyne\_nodelet\_manager\_driver/port  
/velodyne\_nodelet\_manager\_driver/read\_fast  
/velodyne\_nodelet\_manager\_driver/read\_once  
/velodyne\_nodelet\_manager\_driver/repeat\_delay  
/velodyne\_nodelet\_manager\_driver/rpm  
/velodyne\_nodelet\_manager\_driver/time\_offset

The nodes that generate velodyne's operation are all clustered inside velodyne\_nodelet\_manager\_ , velodyne\_nodelet\_manager\_cloud and velodyne\_nodelet\_manager\_driver

To change any of the parameters available above, you have to call the service set\_parameter:

`rosservice call /velodyne_nodelet_manager_cloud/set_parameters`

and then use tab completion in order for an YAML dictionary containing the parameter settings to appear.

The nodes running during the operation of the VLP16 Lidar are:

/rosout  
/rviz\_1485536641964020449  
/velodyne\_nodelet\_manager  
/velodyne\_nodelet\_manager\_cloud  
/velodyne\_nodelet\_manager\_driver

The services available are:

/rosout/get\_loggers  
/rosout/set\_logger\_level  
/rviz\_1485536641964020449/get\_loggers  
/rviz\_1485536641964020449/reload\_shaders  
/rviz\_1485536641964020449/set\_logger\_level

```


/velodyne_nodelet_manager/get_loggers
/velodyne_nodelet_manager/list
/velodyne_nodelet_manager/load_nodelet
/velodyne_nodelet_manager/set_logger_level
/velodyne_nodelet_manager/unload_nodelet
/velodyne_nodelet_manager_cloud/get_loggers
/velodyne_nodelet_manager_cloud/set_logger_level
/velodyne_nodelet_manager_cloud/set_parameters
/velodyne_nodelet_manager_driver/get_loggers
/velodyne_nodelet_manager_driver/set_logger_level
/velodyne_nodelet_manager_driver/set_parameters

```

We can call anyone of them using the command

**rosservice call**

The rqt\_graph tool show the ROS graph that is connecting the nodes during the operation of the VLP16:



The map image that appears is broadcasted by the rviz node is generated by the velodyne\_nodelet\_manager node, which publishes messages on the topic velodyne\_points. The publishing rate can be evaluated with the

command

```
rostopic hz /velodyne_points
```

It oscillates between 9.9 Hz and 10 Hz.