







Microsmt PNP frame Installation diagram

www.microsmt.com.cn


Ver 1.7











STEP 7













































STEP 26



8-M3*10
































STEP 38

Lock these screws after
adjusting the accuracy

