



## FSi Series

### “C” Function Setting – Australia Trade Version

Key Function	Display	NMI Settings	Description		
With the scale turn off press & hold CAL & ZERO key press the ON/OFF key	Software ver.eg P-2.03				
Press PRINT/ENTER key	d-dsp				
Press Unit key	test				
Press Unit key	init				
Press Unit key	Func				
Press PRINT/ENTER key	C01-				
Press PRINT/ENTER key	C01-X	<b>0</b>	Calibration	0: Enable	1: Disable
Press ZERO key	C02-X	<b>0: 6kg 1: 15kg 2: 30kg</b>	Capacity		
Press ZERO key	C03-X	<b>0</b>	Unit	0: Metric	1: Imperial
Press ZERO key	C04-X	<b>0</b>	Power on zero range	0: $\pm 10\%$	1: $\pm 50\%$
Press ZERO key	C05-X	<b>0</b>	Sri Lanka spec.	0: Inactive	1: Active
Press ZERO key	C06-X	<b>0</b>	Decimal Point	0: “.” (dot)	1: “,” (comma)
Press ZERO key	C07-X	<b>0</b>	Tare clear at NET by Zero key	0: Disable	1: Enable
Press ZERO key	C08-X	<b>1</b>	Tare indication	0: Display Count	1: Internal Count
Press ZERO key	C09-X	<b>1</b>	Preset Tare	0: Disable	1: Enable
Press ZERO key	C10-X	<b>0</b>	(lb-oz) Display	0: Disable	1: Enable
Press ZERO key	C11-X	<b>0</b>	Unit	0: $\pm 2\%$	1: Unlimited
Press ZERO key	C12-X	<b>1</b>		0: by F2 2: 1/6000 Fixed	1: 1/3000 Fixed 3: 1/12000 Fixed
Press PRINT/ENTER key	End then Short 0				
Press ON/OFF key to exit mode					